


User Manual

Nu-X Drum System **DIGITAL DRUM KIT** **DM-2**



NUX



Cherub Technology Co.,Ltd
www.nuxefx.com

USING THE UNIT SAFELY

INSTRUCTIONS FOR THE PREVENTION OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS

About WARNING and CAUTION Notices

About the Symbol

 WARNING	Used for instructions intended to alert the user to the risk of death or severe injury should the unit be used improperly.	 CAUTION	Used for instructions intended to alert the user to the risk of injury or material damage should the unit be used improperly. * Material damage refers to damage or other adverse effects caused with respect to the home and all its furnishings, as well to domestic animals or pets.
--	--	--	--

ALWAYS OBSERVE THE FOLLOWING

WARNING

- Before using this unit, make sure to read the instructions below and the Owner's Manual.
- Do not open (or modify in any way) the unit or its AC adaptor.
- Do not attempt to repair the unit, or replace parts within it (except when this manual provides specific instructions directing you to do so). Refer all servicing to your retailer, the nearest Cherub Service Center.
- Never use or store the unit in places that are: Subject to temperature extremes (e.g., direct sunlight in an enclosed vehicle, near a heating duct, on top of heat-generating equipment); or are Damp (e.g., baths, washrooms, on wet floors); or Are Humid; Exposed to rain; Dusty; Subject to high levels of vibration.
- This unit may be installed on a stand using a Clamp.
- When installing the unit on a stand with a clamp, the stand must not be placed in an unstable location or on an incline, but in a level and stable position. Even if a stand is not used, make sure that the unit is placed in a stable location.

WARNING

- Be sure to use only the AC adaptor supplied with the unit. Also, make sure the line voltage at the installation matches the input voltage specified on the AC adaptor's body. Other AC adaptors may use a different polarity, or be designed for a different voltage, so their use could result in damage, malfunction, or electric shock.
- Do not excessively twist or bend the power cord, nor place heavy objects on it. Doing so can damage the cord, producing severed elements and short circuits. Damaged cords are fire and shock hazards!
- This unit, either alone or in combination with an amplifier and headphones or speakers, may be capable of producing sound levels that could cause permanent hearing loss. Do not operate for a long period of time at a high volume level, or at a level that is uncomfortable. If you experience any hearing loss or ringing in the ears, you should immediately stop using the unit, and consult an Audiologist.
- Do not allow any objects (e.g., flammable material, coins, pins); or liquids of any kind (water, soft drinks, etc.) to penetrate the unit.

WARNING

- Immediately turn the power off, remove the AC adaptor from the outlet, and request servicing by your retailer, the nearest Cherub Service Center.

The AC adaptor or the power-supply cord has been damaged; or
If smoke or an unusual odor occurs
Objects have fallen into, or liquid has been spilled onto the unit; or
The unit has been exposed to rain (or otherwise has become wet); or
The unit does not appear to operate normally or exhibits a marked change in performance.

- In households with small children, an adult should provide supervision until the child is capable of following all the rules essential for the safe operation of the unit.

- Protect the unit from strong impact. (Do not drop it!)

- Do not force the unit's power-supply cord to share an outlet with an unreasonable number of other devices. Be especially careful when using extension cords. The total power used by all devices you have connected to the extension cord's outlet must never exceed the power rating (watts/amperes) for the extension cord. Excessive loads can cause the insulation on the cord to heat up and eventually melt through.

- Before using the unit in a foreign country, consult with your retailer, the nearest Cherub Service Center.

CAUTION

- The unit and the AC adaptor should be located so their location or position does not interfere with their proper ventilation.

- Always grasp only the output plug or the body of the AC adaptor when plugging into, or unplugging from, this unit or an outlet.

- Any accumulation of dust between the AC adaptor and the power outlet can result in poor insulation and lead to fire. Periodically wipe away such dust with a dry cloth. Also, disconnect the power plug from the power outlet whenever the unit is to remain unused for an extended period of time.

- Try to prevent cords and cables from becoming entangled. Also, all cords and cables should be placed so they are out of the reach of children.

- Never climb on top of, nor place heavy objects on the unit.

- Never handle the AC adaptor body, or its output plugs, with wet hands when plugging into, or unplugging from, an outlet or this unit.

- If you need to move the instrument, take note of the precautions listed below. Make sure to have a firm grip, to protect yourself from injury and the instrument from damage. Check to make sure that the clamp that fixes the unit to the stand has not become loose. Fasten them again securely whenever you notice any loosening. Disconnect the power cord. Disconnect all cords coming from external devices.

- Before cleaning the unit, turn off the power and unplug the AC adaptor from the outlet.

- Whenever you suspect the possibility of lightning in your area, disconnect the AC adaptor from the outlet.


- Should you remove security screws, make sure to put them in a safe place out of children's reach, so there is no chance of them being swallowed accidentally.

CONTENTS

Panel and Interface	4
Top Panel	4
Front Panel	5
Mounting and Connection	6
Connection	6
Mounting the DM-2 on the Stand	7
Screen Display	8
Ready to play	9
Turning ON/OFF the Power	9
Performance Techniques	10
Drum Kit Operation	12
Selecting a Drum Kit	12
Setting the Drum Kit	12
Pad Settings	13
Setting Effects in a Drum Kit	14
Naming a Drum Kit	15
Saving a Drum Kit	15
Metronome Function	16
Recording and Playback Function	17
Coach Function	18
System Settings	20
Pad settings	20
Restoring the Factory Settings	22
Basic Settings	22
Importing wav File from Computer	23
USB-MIDI Function	23
Specifications	24
MIDI Implementation Chart	25
Voice List	26

PANEL AND INTERFACE

Top Panel



- 1.VOICE Button**
Press the voice button to adjust the pad's voice.
- 2.VOLUME Button**
Press the volume button to adjust the pad's volume.
- 3.POWER Switch**
Turn the power on/off.
- 4.COACH Button**
Press the COACH button to train your basic skill and your rhythm balance.
- 5.CLICK Button**
Turn on/off the metronome.
- 6.KIT ▲ and KIT ▼ Buttons**
Press ▲ ▼ buttons to switch drum kits.
- 7.SONG Button**
Select the demo songs.
- 8.EFFECTS Button**
The main switcher for sound effect.
- 9.VOL Knob**
Adjust the volume of the OUTPUT and Headphone jacks.
- 10.HEADPHONE Jack**
- 11.AUX IN Jack**
For connecting an external audio source such as MP3 or CD player. All sound input here is also sent from the OUTPUT and headphone jacks.
- 12.PLAY Button**
Play what you recorded, and the demo songs.
- 13.REC Button**
Press REC button to record your playing.
- 14.OUTPUT Jack (L/MONO, R)**
These are the main stereo outputs. If you only output mono signal, use only the L/MONO jack.
- 15.LCD Display**
This shows the drum kit name, song's name and other information. During editing, this shows the contents of the settings.
- 16.USB Port**
- 17.DC IN Jack**
Connect the 9V DC adaptor here.
- 18.MENU Button.**
Press MENU button to enter the main menu.

19.OK Button

Use this to confirm a value you've edited.

20.VALUE Knob

Adjust the parameter you are editing.


21.▲ and ▼Buttons

Choose the menu item you want to edit.

22.Drum Pad Buttons

Press the drum pad button to choose it and make a corresponding sound.


Rear Panel



23.SD Card Slot


For inserting the SD card.

CONNECTION




NOTE:
To prevent malfunction and/or damage to speakers or other devices, always turn down the volume, and turn off the power on all devices before making connections.

MOUNTING THE DM-2 ON THE STAND




1. Attach the included sound module mounting plate to the DM-2. Use included wing bolts to attach the plate as shown in the illustration.




2. Attach the DM-2 (with the sound module mounting plate installed) to your drum stand.


3. Connect the included cable to the DM-2's TRIGGER IN connector, and connect your pads and pedals.



Labels indicating the pad to be connected are attached to the cable.




Connect the pads and pedals as shown in the illustration.



NOTE:
To protect device, when connect to device, please power off.

SCREEN DISPLAY



- A. Strength of the pad strike displayed in 8 levels.
- B. SONG indicator
- C. Drum kit number or DEMO number
- D. Drum kit indicator
- E. SD card indicator
- F. USB connection indicator


- F. USB connection indicator
- G. Dot matrix area
- H. ▲ and ▼ indicator
- I. Pad name display
- J. SYSTEM setting indicator
- K. COACH function indicator

READY TO PLAY

Turning ON/OFF the Power


*Turn on the power

1. Turn the VOL knob to the minimum.
2. Close the volume of the connected amp or audio system.
3. Turn the power switch to ON.



*Turn off the power

1. Turn the volume of DM-2 and external equipments to the minimum.
2. Power off the external equipment.
3. Turn the power switch to OFF.



*You may still hear some sound when the power is switched on, this is normal, and does not indicate a malfunction.

After power on, LCD will display drum kit number and name.



NOTE: *Preset indicate preset Drum Kit;
User indicate user Drum kit*


4. Power on the external amp or audio system.
5. While hitting a pad, gradually turn the VOL knob toward the right to adjust the volume.

Performance Techniques

*Snare


Head Shot

Hit only the head of the pad.



Open Rim Shot


Strike the rim of the pad.



*Tom

Head Shot


Hit only the head of the pad.



*Kick

Head Shot


Hit only the head of the pad.



*Cymbals (Crash Ride)


Bow Shot

Hit the middle area of the cymbal.




Edge Shot

Strike the edge with the shoulder of the stick.



Choke a Cymbal

Pinch the cymbal's edge immediately after hitting the cymbal will choke the sound, just like with a real cymbal. The Choke function only works when you grasp in the sensing area.




*Hi-Hat

Open/Closed

The hi-hat sound will change smoothly between open and closed depending on pressure applied to the hi-hat control pedal. Foot closed and foot splash sounds are possible.


Bow Shot

Hit the middle area of the hi-hat pad.




Choke a Cymbal

Choke the cymbal's edge with the hand immediately after hitting the cymbal will mute or choke the sound, just like with a real cymbal. The choke function only works when you grasp in the area.



*Hi-Hat Control Pedal



Open Hi-Hat

Strike the hi-hat without pressing the pedal.

Closed Hi-Hat

Strike the hi-hat with the pedal pressed.


DRUM KIT OPERATION

Selecting a Drum Kit

When you turn on the DM-2, you are in drum kit mode. A drum kit is a combination of the sounds and settings for each pad and pedal, as well as ambience.




1. Press the KIT ▲ and ▼ buttons to select drum kit.




2. Press the KIT ▲ and ▼ buttons under any mode will get back to DRUM KIT mode.

Setting the Drum Kit


1. Use the KIT ▲ and ▼ buttons to select the drum kit that you want to edit.
2. Press the MENU button so it's lit.



3. Use the ▲ and ▼ buttons to select the desired menu.




4. Turn the VALUE dial to select the pad which you want to edit. (You also can select the pad through striking the pad you want to edit)



5. When you've selected the desired menu, press the OK button.


Example: PAD SET MENU



6. When you've finished making settings, press the MENU button; you'll return to the DRUM KIT screen.

Pad Settings

1. In the menu screen, choose "PAD SET" and press the OK button.




2. Use the ▲ and ▼ buttons to select a parameter.
3. Strike a pad to select the pad whose settings you want to edit.
4. Use the VALUE dial to edit the setting.
5. Press the OK button to return to the "MENU" screen.

Screen Display	Parameter	Value	Description
	TONE	SNARE1-SNARE33	Selects instrument type
	VOLUME	0-127	Specifies the instrument volume
	PAN	L64-CENTER-R63	Specifies Instrument pan position
	CURVE	LINEAR LOG EXP LOUD	Adjusts the curve of volume change in response to your playing velocity


LINEAR

The standard setting. This produces the most natural correspondence between playing dynamics and volume change.




EXP

Compared to LINEAR, strong dynamics produce a greater change.




LOG

Compared to LINEAR, a soft playing produces a greater change.




LOUD

Very little dynamic response, making it easy to maintain strong volume levels. If using drum triggers, these settings help maintain stable levels.



Setting Effects in a Drum Kit

1. In the menu screen, choose "EFX SET" and press the OK button.




2. Use the ▲ and ▼ buttons to select a parameter.
3. Use the VALUE dial to edit the setting.
4. Press the OK button to return to the "MENU" screen.

Screen Display	Parameter	Value	Description
	REVERB STYLE	ROOM HALL EARLY CHAMBER	Selects reverb type
	REVERB LEVEL	OFF/1-99	Adjusts reverb level
	CHORUS STYLE	ROTOR WIDE ST WIDE SPACE	Selects chorus type
	CHORUS LEVEL	OFF/1-99	Adjusts chorus level
	LIMITER	ON/OFF	Turns ON/OFF limiter
	HIGH EQ	-12db—+12db	Adjusts the high frequency
	MID EQ	-12db—+12db	Adjusts the middle frequency
	BASS EQ	-12db—+12db	Adjusts the bass frequency

Naming a Drum Kit

1. In the menu screen, choose "3-KIT NAME" and press the OK button.




2. Press the ▲ and ▼ button to move the cursor to the character that you want to edit.
3. Use the VALUE dial to change the character.



4. Press the OK button to return to the "MENU" screen.

Playing DEMO

1. In the drum kit mode, press SONG button to enter into the DEMO mode.



NOTE: Preset indicate DEMO in the device
User indicate user record.
SD indicate DEMO in SD card

Saving a Drum Kit

1. In the menu screen, choose "4-KIT SAVE" and press the OK button.



2. Use the VALUE dial to choose the drum kit number.




3. Press the OK button to execute the save operation.
4. When operation is completed, you'll be returned to the drum kit screen automatically.


NOTE: Each demo song has their own tempo.

METRONOME FUNCTION


Press the CLICK button. The metronome starts and the screen will indicate the tempo.









1. In the menu screen, choose "5-CLICK" and press the OK button.



2. Press the ▲ and ▼ button to select a parameter.
3. Use the VALUE dial to adjust the parameter value.




4. Press the OK button to return the MENU.

Screen Display	Parameter	Value	Description
	TEMPO	40-220	Specifies the tempo of the metronome.
	BEAT	1-9	Specifies the time signature of the metronome.
	RHYTHM		Specifies the note value that will be sounded by the metronome.
	VOLUME	0-127	Specifies the volume of the metronome.
	SOUND	Click, Cowbell	Specifies the sound of the metronome.

NOTE: The parameter will be saved automatically when exiting this mode.

RECORDING AND PLAYBACK FUNCTION

Please first select the drum kit that you want to use for recording.



1. Press the REC button, and the DM-2 will enter recording-standby mode.
2. Hit any pad/pedal and recording begins.



NOTE:

1. when recording, if no drum signal input for more than 4s, it will stop recording and displays COMPLETE!
2. when recording, if memory is full, it will stop recording and display MEMFULL!


3. To stop recording, press the REC button again. If you exceed the maximum recording time, recording stops automatically.
4. Press the PLAY button to PLAYBACK you recorded.
5. Press SONG button to turn on the demo song, so you can record your play with backing track. (when SONG light is lit, it means the demo song is playing while recording at the same time.)

COACH FUNCTION

1. Under Drum Kit Mode, press COACH button to turn on Coach function.



2. Press Up/Down to select the training function and press OK to enter, or press CLICK button start training.




•TIME CHECK

You can train your timing under this mode.



- 1) In TIME CHECK mode, press CLICK button to start practicing.

NOTE: During practicing, you can change the tempo by turning the VALUE knob.



- 2) The LCD shows if your timing matches the metronome. The triangle on the LCD moving towards S means you are slow compared to the metronome; towards F means you are fast. It also shows the percentage of your accuracy.

- 3) In TIME CHECK mode, press MENU button to set parameters.

Use Up/Down buttons to select the parameter item that you want to edit; Turn the VALUE knob to change the value.



•TEMPO CHECK

Under this mode, you can practice in a consistent tempo.




- 1) In TEMPO CHECK mode, press CLICK button to start practicing.

NOTE: During practicing, you can change the tempo by turning the VALUE knob.

- 2) Sync the tempo of the pads and the metronome.

NOTE: The more accurate you play, the less volume the metronome sounds. The LCD also shows the percentage of your accuracy.



- 3) In TEMPO CHECK mode, press MENU button to set parameters.

Use Up/Down buttons to select the parameter item that you want to edit;

Turn the VALUE knob to change the value.



COACH FUNCTION

● QUIET COUNT


Under this mode, the metronome sound will be alternately on and off for you to train your timing.




1) In QUIET COUNT mode, press CLICK to start practicing.

NOTE: During practicing, you can change the tempo by turning the VALUE knob.


2) The metronome will play for a few bars, and the LCD will display "Ready" at the last bar.



3) When the metronome sound is off (metronome still counting internally), the LCD will display "Quiet". You keep playing in accordance to the tempo in your memory.




4) When the metronome sound comes back again, the LCD will display the accuracy of your playing during the time when the metronome sound was off.



5) In QUIET COUNT mode, press MENU button to set parameters.

Use Up/Down buttons to select the parameter item that you want to edit;

Turn the VALUE knob to change the value.




● AUTO UPDOWN




1) In AUTO UP DOWN mode, press CLICK to start practicing.

NOTE: During practicing, you can change the tempo by turning the VALUE knob.

2) Sync the tempo of the pads and the metronome.




The tempo of the metronome will change between the first tempo and the second tempo. You accuracy will be display on the LCD.ill synchronize with the pads.



3) In QUIET COUNT mode, press MENU button to set parameters.

Use Up/Down buttons to select the parameter item that you want to edit;


Turn the VALUE knob to change the value.



SYSTEM SETTINGS

Pad settings

1. In the menu screen, choose "TRIGGER" and press the OK button.



2. Use the VALUE knob to choose the pad you want to edit.


3. Press the UP and DOWN button to select a parameter item.

4. Use the VALUE knob to change the parameter value.

5. Press the OK button to return the MENU.


Screen Display	Parameter	Value	Description
	SENSITIVE	0.1-3.2	You can adjust the sensitivity of the pads to accommodate your personal playing style. Higher sensitivity allows the pad to produce a loud volume even when played softly. Lower sensitivity will keep the pad producing a low volume even when played forcefully.
	THRESHOLD	0-16	This setting allows a trigger signal to be received only when the pad is above a determined dynamic level(velocity). This can be used to prevent a pad from sounding because of vibrations from other pads.


Example: B will sound but A and C will not sound. When set to a higher value, no sound is produced when the pad is struck lightly. Gradually raise the "Threshold" value while striking to pad. Check this and adjust accordingly. Repeat this process until you get the perfect setting for your playing style.




	Scan Time	2ms-12ms	Specifies the detection time for the trigger signal. Since the rise time of the trigger signal waveform may differ slightly depending on the characteristics of each pad or acoustic drum trigger(drum pickup), you may notice that identical hits(velocity) may produce sound at different volumes. If this occurs, you can adjust the "Scan Time" so that your way of playing can be detected more precisely.
--	-----------	----------	---

While repeatedly hitting the pad at a constant force, gradually raise the Scan Time value from 2 ms, until the resulting volume stabilizes at the loudest level. At this setting, try both soft and loud strikes, and make sure that the volume changes appropriately. As the value is set higher, the time it takes for the sound to be played increases. Set this to the lowest value possible.




	Mask Time	4ms-64ms	<p>This setting prevents double triggering. When playing a kick trigger, the beater can bounce back and hit the head a second time immediately after the intended note—with acoustic drums sometimes the beater stays against the head—is causes a single hit to "double trigger"). The Mask Time setting helps to prevent this. Once a pad has been hit, any additional trigger signals occurring within the specified 4-64 msec) will be ignored. Adjust the "Mask Time" value while playing the pad.</p>
---	-----------	----------	---


When using a kick trigger, try to let the beater bounce back and hit the head very quickly, then raise the "Mask Time" value until there are no more sounds made by the beater rebound.




* When set to a high value, it will be difficult to play very quickly. Set this to as low a value as you can.


	Retrig-cancel	0-16	<p>This setting prevents spurious re-triggering. Important if you are using acoustic drum triggers. Such triggers can produce altered waveforms, which may also cause inadvertent sounding at Point A in the figure (Re-trigger). This occurs in particular at the decaying edge of the waveform. Retrig Cancel detects such distortion in and prevents re-triggering from occurring.</p>
---	---------------	------	---

While repeatedly striking the pad, raise the Retrig Cancel value until re-triggering no longer occurs.



* Although setting this to a high value prevents retriggering, it then becomes easy for sounds to be omitted when the drums played fast (roll etc.). Set this to the lowest value possible while still ensuring that there is no retriggering.

	X-Talk cancel	0-80%	<p>This setting cancels crosstalk which means that when you play one pad you hear a sound coming from another pad. This can happen when two pads are installed on the same stand. In some cases you can prevent crosstalk by increasing the distance between the two mounted pads.</p>
---	---------------	-------	--


	Rim Gain	0.1-3.2	<p>You can adjust the relation between your playing velocity (force) on the rim/edge and the resulting volume level. Higher value allows the rim/edge to produce a loud volume even when played softly. Lower value will keep the rim/edge producing a low volume even when played forcefully.</p>
---	----------	---------	--

NOTE: The parameter will be saved automatically when exiting this mode.

	MIDI NOTE	0-127	<p>Specifies the MIDI note numbers transmitted by the pads.</p>
---	-----------	-------	---


Restoring the Factory Settings

- In the MENU, choose OPTIONS to enter the setting interface. Press ▲▼ key to choose the FAC RESET item, Press OK button to enter the interface of FAC RESET menu.




- Press ▲ and ▼ to choose the options you want to restore:


- Restoring the system data such as trigger, song, click etc.



- Restore all data of drum kit.




- Restore all data.






- Press the OK button to return the MENU.

Basic Settings

- In the MENU choose "9-OPTIONS" and press the OK button.




- Press ▲ and ▼ to choose the options you want to edit.
- Use the VALUE dial to change the parameter value.
- Press the OK button to return the MENU.

Screen Display	Parameter	Value	Description
	LCD Contrast	1-10	Adjusts the LCD Contrast.
	LCD brightness	1-10	Adjusts the LCD brightness.
	Edition	V1.0	Shows firmware edition of the machine.


Importing wav File from Computer

1. In the MENU, choose "USER SET" and press the OK button.




2. Put the SD card into the slot of the DM-2. you can load your own sound library from SD card. Download software from our website to make your own sound library.

3. Press OK button again to import sound library.



4. Don't take out the SD card when you are importing sound library from SD card.

5. it will return to the DRUM KIT mode after importing is finished.



Display information are following:

OK! import sound library finished (after finished, DM-2 will be restarted automatically).

NO SD! no SD card.


NO FILE! no File on the SD card.

FAIL! import sound library failed.

ERROR0-ERROR-5! there are some error when importing sound library.

USB-MIDI Function

The DM-2 is equipped with a USB connector. When connected to your computer, the USB ICON will be lit on the LCD and start to transmit the MIDI IN/OUT.



NOTE: Before you connect the USB to computer, please close all software about USB-MIDI.

SPECIFICATIONS

Maximum Polyphony: 22

Display: Custom (backlit LCD)

Instruments : 361

Drum Kits: 40 (User: 20, Factory: 20)

Songs: 20 (MIDI :Only percussion track supported)

Recording: 10

Click Sound: Editable (Sound, Tempo, Rhythm Type, Beat, Volume)

MIDI Functions: USB-MIDI

Capacity: SD card (MIDI Playing, MIDI Format 0/Format 1 Supported)

Triggers: Tomx3, Snare, Hi-Hat, Crash, Ride, Kick

Interfaces: Headphones, USB MIDI, SD card, AUX IN, OUTPUTS

Power Supply: DC 9V (⊖→⊕)

MIDI Implementation Chart

Function		Transmitted	Recognized	Remarked
Basic default		10	10	
Channel changed		No	No	
Note		0-127	0-127	
Velocity:	Note on	Yes	Yes	
	Note off	No	Yes	
After Key's		No	No	
Touch Channel's		No	No	
Control change:	0	No	No	Bank select
	1	No	No	Modulation
	5	No	No	Portamento time
	7	No	No	Volume
	10	No	No	Pan
	11	No	No	Expression
	64	No	No	Sustain pedal
	65	No	No	Portamento on/off
	66	No	No	Sostenuto pedal
	67	No	No	Soft pedal
	120	No	No	All sound off
121	No	No	Reset all controllers	
123	No	No	All note off	
Program change		No	No	
System exclusive		No	No	

Voice List

SNARE		
No.	Name	LCD
1	ROCK1 SNARE	SNARE1
2	Funk SNARE	SNARE2
3	Jazz SNARE	SNARE3
4	Soul One SNARE	SNARE4
5	Rock 2 SNARE	SNARE5
6	Dragon SNARE	SNARE6
7	Dub Remix SNARE	SNARE7
8	Nein Oh Nein SNARE	SNARE8
9	Nupop SNARE	SNARE9
10	Tight SNARE	SNARE10
11	Basic SNARE	SNARE11
12	Multi Mic SNARE	SNARE12
13	Multi Stick SNARE	SNARE13
14	Vintage SNARE	SNARE14
15	Garrage SNARE	SNARE15
16	Harsh SNARE	SNARE16
17	Elektro Acoustik SNARE	SNARE17
18	Studio Gong SNARE	SNARE18
19	Ate Oh Wait SNARE	SNARE19
20	Hessy Eye Drum SNARE	SNARE20
21	ROCK1 SNARE Rim	SNARER1
22	Funk SNARE Rim	SNARER2
23	Jazz SNARE Rim	SNARER3
24	Soul One SNARE Rim	SNARER4
25	Rock 2 SNARE Rim	SNARER5
26	Dragon SNARE Rim	SNARER6
27	Dub Remix SNARE Rim	SNARER7
28	Nein Oh Nein SNARE Rim	SNARER8
29	Nupop SNARE Rim	SNARER9
30	Tight SNARE Rim	SNARER10
31	Basic SNARE Rim	SNARER11
32	Multi Mic SNARE Rim	SNARER12
33	Multi Stick SNARE Rim	SNARER13
34	Vintage SNARE Rim	SNARER14
35	Garrage SNARE Rim	SNARER15
36	Harsh SNARE Rim	SNARER16
37	Rock 2 SNARE Rim	SNARER17
38	Studio Gong SNARE Rim	SNARER18
39	Ate Oh Wait SNARE Rim	SNARER19
40	Hessy Eye Drum SNARE Rim	SNARER20

CRASH		
No.	Name	LCD
1	ROCK1 CRASH	CRASH1
2	Funk CRASH	CRASH2
3	Jazz CRASH	CRASH3
4	Soul One CRASH	CRASH4
5	Rock 2 CRASH	CRASH5
6	Dragon CRASH	CRASH6
7	Dub Remix CRASH	CRASH7
8	Nein Oh Nein CRASH	CRASH8
9	Nupop CRASH	CRASH9
10	Tight CRASH	CRASH10
11	Basic CRASH	CRASH11
12	Multi Mic CRASH	CRASH12
13	Multi Stick CRASH	CRASH13
14	Vintage CRASH	CRASH14
15	Garrage CRASH	CRASH15
16	Harsh CRASH	CRASH16
17	Elektro Acoustik CRASH	CRASH17
18	Studio Gong CRASH	CRASH18
19	Ate Oh Wait CRASH	CRASH19
20	Hessy Eye Drum CRASH	CRASH20
21	ROCK1 CRASH Rim	CRASHR1
22	Funk CRASH Rim	CRASHR2
23	Jazz CRASH Rim	CRASHR3
24	Soul One CRASH Rim	CRASHR4
25	Rock 2 CRASH Rim	CRASHR5
26	Dragon CRASH Rim	CRASHR6
27	Dub Remix CRASH Rim	CRASHR7
28	Nein Oh Nein CRASH Rim	CRASHR8
29	Nupop CRASH Rim	CRASHR9
30	Tight CRASH Rim	CRASHR10
31	Basic CRASH Rim	CRASHR11
32	Multi Mic CRASH Rim	CRASHR12
33	Multi Stick CRASH Rim	CRASHR13
34	Vintage CRASH Rim	CRASHR14
35	Garrage CRASH Rim	CRASHR15
36	Harsh CRASH Rim	CRASHR16
37	Elektro Acoustik CRASH Rim	CRASHR17
38	Studio Gong CRASH Rim	CRASHR18
39	Ate Oh Wait CRASH Rim	CRASHR19
40	Hessy Eye Drum CRASH Rim	CRASHR20

Voice List

RIDE		
No.	Name	LCD
1	ROCK1 RIDE	RIDE1
2	Funk RIDE	RIDE2
3	Jazz RIDE	RIDE3
4	Soul One RIDE	RIDE4
5	Rock 2 RIDE	RIDE5
6	Dragon RIDE	RIDE6
7	Dub Remix RIDE	RIDE7
8	Nein Oh Nein RIDE	RIDE8
9	Nupop RIDE	RIDE9
10	Tight RIDE	RIDE10
11	Basic RIDE	RIDE11
12	Multi Mic RIDE	RIDE12
13	Multi Stick RIDE	RIDE13
14	Vintage RIDE	RIDE14
15	Garrage RIDE	RIDE15
16	Harsh RIDE	RIDE16
17	Elektro Acoustik RIDE	RIDE17
18	Studio Gong RIDE	RIDE18
19	Ate Oh Wait RIDE	RIDE19
20	Hessy Eye Drum RIDE	RIDE20
21	ROCK1 RIDE Rim	RIDER1
22	Funk RIDE Rim	RIDER2
23	Jazz RIDE Rim	RIDER3
24	Soul One RIDE Rim	RIDER4
25	Rock 2 RIDER Rim	RIDER5
26	Dragon RIDER Rim	RIDER6
27	Dub Remix RIDE Rim	RIDER7
28	Nein Oh Nein RIDE Rim	RIDER8
29	Nupop RIDE Rim	RIDER9
30	Tight RIDE Rim	RIDER10
31	Basic RIDE Rim	RIDER11
32	Multi Mic RIDE Rim	RIDER12
33	Multi Stick RIDE Rim	RIDER13
34	Vintage RIDE Rim	RIDER14
35	Garrage RIDE Rim	RIDER15
36	Harsh RIDE Rim	RIDER16
37	Elektro Acoustik RIDE Rim	RIDER17
38	Studio Gong RIDE Rim	RIDER18
39	Ate Oh Wait RIDE Rim	RIDER19
40	Hessy Eye Drum RIDE Rim	RIDER20

Hi Hat		
No.	Name	LCD
1	ROCK1 HH PEDAL	HH1
2	Funk HH PEDAL	HH2
3	Jazz HH PEDAL	HH3
4	Soul One HH PEDAL	HH4

5	Rock 2 HH PEDAL	HH5
6	Dragon HH PEDAL	HH6
7	Dub Remix HH PEDAL	HH7
8	Nein Oh Nein HH PEDAL	HH8
9	Nupop HH PEDAL	HH9
10	Tight HH PEDAL	HH10
11	Basic HH PEDAL	HH11
12	Multi Mic HH PEDAL	HH12
13	Multi Stick HH PEDAL	HH13
14	Vintage HH PEDAL	HH14
15	Garrage HH PEDAL	HH15
16	Harsh HH PEDAL	HH16
17	Elektro Acoustik HH PEDAL	HH17
18	Studio Gong HH PEDAL	HH18
19	Ate Oh Wait HH PEDAL	HH19
20	Hessy Eye Drum HH PEDAL	HH20
21	ROCK1 OPEN HH	HHO1
22	Funk OPEN HH	HHO2
23	Jazz OPEN HH	HHO3
24	Soul One OPEN HH	HHO4
25	Rock 2 OPEN HH	HHO5
26	Dragon OPEN HH	HHO6
27	Dub Remix OPEN HH	HHO7
28	Nein Oh Nein OPEN HH	HHO8
29	Nupop OPEN HH	HHO9
30	Tight OPEN HH	HHO10
31	Basic OPEN HH	HHO11
32	Multi Mic OPEN HH	HHO12
33	Multi Stick OPEN HH	HHO13
34	Vintage OPEN HH	HHO14
35	Garrage OPEN HH	HHO15
36	Harsh OPEN HH	HHO16
37	Elektro Acoustik OPEN HH	HHO17
38	Studio Gong OPEN HH	HHO18
39	Ate Oh Wait OPEN HH	HHO19
40	Hessy Eye Drum OPEN HH	HHO20
41	ROCK1 CLOSED HH	HHC1
42	Funk CLOSED HH	HHC2
43	Jazz CLOSED HH	HHC3
44	Soul One CLOSED HH	HHC4
45	Rock 2 CLOSED HH	HHC5
46	Dragon CLOSED HH	HHC6
47	Dub Remix CLOSED HH	HHC7

Hi Hat		
No.	Name	LCD
1	Nein Oh Nein CLOSED HH	HHC8
2	Nupop CLOSED HH	HHC9
3	Tight CLOSED HH	HHC10
4	Basic CLOSED HH	HHC11

Voice List

5	Multi Mic CLOSED HH	HHC12
6	Multi Stick CLOSED HH	HHC13
7	Vintage CLOSED HH	HHC14
8	Garrage CLOSED HH	HHC15
9	Harsh OPEN HH	HHC16
10	Ele Acoustik CLOSED HH	HHC17
11	Studio Gong CLOSED HH	HHC18
12	Ate Oh Wait CLOSED HH	HHC19
13	Hessy Eye CLOSED HH	HHC20

TOM		
No.	Name	LCD
1	ROCK1 TOMH	TOMH1
2	Funk TOMH	TOMH2
3	Jazz TOMH	TOMH3
4	Soul One TOMH	TOMH4
5	Rock 2 TOMH	TOMH5
6	Dragon TOMH	TOMH6
7	Dub Remix TOMH	TOMH7
8	Nein Oh Nein TOMH	TOMH8
9	Nupop TOMH	TOMH9
10	Tight TOMH	TOMH10
11	Basic TOMH	TOMH11
12	Multi Mic TOMH	TOMH12
13	Multi Stick TOMH	TOMH13
14	Vintage TOMH	TOMH14
15	Garrage TOMH	TOMH15
16	Harsh TOMH	TOMH16
17	Elektro Acoustik TOMH	TOMH17
18	Studio Gong TOMH	TOMH18
19	Ate Oh Wait TOMH	TOMH19
20	Hessy Eye Drum TOMH	TOMH20
21	ROCK1 TOMM	TOMM1
22	Funk TOMM	TOMM2
23	Jazz TOMM	TOMM3
24	Soul One TOMM	TOMM4
25	Rock 2 TOMM	TOMM5
26	Dragon TOMM	TOMM6
27	Dub Remix TOMM	TOMM7
28	Nein Oh Nein TOMM	TOMM8
29	Nupop TOMM	TOMM9
30	Tight TOMM	TOMM10
31	Basic TOMM	TOMM11
32	Multi Mic TOMM	TOMM12
33	Multi Stick TOMM	TOMM13
34	Vintage TOMM	TOMM14
35	Garrage TOMM	TOMM15
36	Harsh TOMM	TOMM16
37	Elektro Acoustik TOMM	TOMM17

38	Studio Gong TOMM	TOMM18
39	Ate Oh Wait TOMM	TOMM19
40	Hessy Eye Drum TOMM	TOMM20
41	ROCK1 TOML	TOML1
42	Funk TOML	TOML2
43	Jazz TOML	TOML3
44	Soul One TOML	TOML4
45	Rock 2 TOML	TOML5
46	Dragon TOML	TOML6
47	Dub Remix TOML	TOML7
48	Nein Oh Nein TOML	TOML8
49	Nupop TOML	TOML9
50	Tight TOML	TOML10
51	Basic TOML	TOML11
52	Multi Mic TOML	TOML12
53	Multi Stick TOML	TOML13
54	Vintage TOML	TOML14
55	Garrage TOML	TOML15
56	Harsh TOML	TOML16
57	Elektro Acoustik TOML	TOML17
58	Studio Gong TOML	TOML18
59	Ate Oh Wait TOML	TOML19
60	Hessy Eye Drum TOML	TOML20

KICK		
No.	Name	LCD
1	ROCK1 KICK	KICK1
2	Funk KICK	KICK2
3	Jazz KICK	KICK3
4	Soul One KICK	KICK4
5	Rock 2 KICK	KICK5
6	Dragon KICK	KICK6
7	Dub Remix KICK	KICK7
8	Nein Oh Nein KICK	KICK8
9	Nupop KICK	KICK9
10	Tight KICK	KICK10
11	Basic KICK	KICK11
12	Multi Mic KICK	KICK12
13	Multi Stick KICK	KICK13
14	Vintage KICK	KICK14
15	Garrage KICK	KICK15
16	Harsh KICK	KICK16
17	Elektro Acoustik KICK	KICK17
18	Studio Gong KICK	KICK18
19	Ate Oh Wait KICK	KICK19
20	Hessy Eye Drum KICK	KICK20

Voice List

GM		
No.	Name	LCD
1	High Q	Gm1
2	Slap	Gm2
3	Scratch Push	Gm3
4	Scratch Pull	Gm4
5	Sticks	Gm5
6	Square Click	Gm6
7	Metronome Click	Gm7
8	Metronome Bell	Gm8
9	STD1 Kick2	Gm9
10	STD1 Kick1	Gm10
11	Side Stick	Gm11
12	STD1 Snare1	Gm12
13	Hand Clap	Gm13
14	Snare Drum 2	Gm14
15	Low Floor Tom	Gm15
16	Closed Hi Hat	Gm16
17	High Floor Tom	Gm17
18	Pedal Hi-Hat	Gm18
19	Low Tom	Gm19
20	Open Hi-Hat	Gm20
21	Low-Mid Tom	Gm21
22	Hi Mid Tom	Gm22
23	Crash Cymbal 1	Gm23
24	High Tom	Gm24
25	Ride Cymbal 1	Gm25
26	Chinese Cymbal	Gm26
27	Ride Bell	Gm27
28	Tambourine	Gm28
29	Splash Cymbal	Gm29
30	Cowbell	Gm30
31	Crash Cymbal 2	Gm31
32	Vibraslap	Gm32
33	Ride Cymbal 2	Gm33
34	Hi Bongo	Gm34
35	Low Bongo	Gm35
36	Mute Hi Conga	Gm36
37	Open Hi Conga	Gm37
38	Low Conga	Gm38
39	High Timbale	Gm39
40	Low Timbale	Gm40
41	High Agogo	Gm41
42	Low Agogo	Gm42
43	Cabasa	Gm43
44	Maracas	Gm44
45	Short Whistle	Gm45
46	Long Whistle	Gm46
47	Short Guiro	Gm47

GM		
No.	Name	LCD
48	Long Guiro	Gm48
49	Claves	Gm49
50	Hi Wood Block	Gm50
51	Low Wood Block	Gm51
52	Mute Cuica	Gm52
53	Open Cuica	Gm53
54	Mute Triangle	Gm54
55	Open Triangle	Gm55
56	Shaker	Gm56
57	Jingle Bell	Gm57
58	Belltree	Gm58
59	Castanets	Gm59
60	Mute Surdo	Gm60
61	Open Surdo	Gm61

Voice List

OTHER		
No.	Name	LCD
1	Other1	OT1
2	Other2	OT2
3	Other3	OT3
4	Other4	OT4
5	Other5	OT5
6	Other6	OT6
7	Other7	OT7
8	Other8	OT8
9	Other9	OT9
10	Other10	OT10
11	Other11	OT11
12	Other12	OT12
13	Other13	OT13
14	Other14	OT14
15	Other15	OT15
16	Other16	OT16
17	Other17	OT17
18	Other18	OT18
19	Other19	OT19
20	Other20	OT20
21	Other21	OT21
22	Other22	OT22
23	Other23	OT23
24	Other24	OT24
25	Other25	OT25
26	Other26	OT26
27	Other27	OT27
28	Other28	OT28
29	Other29	OT29
30	Other30	OT30
31	Other31	OT31
32	Other32	OT32
33	Other33	OT33
34	Other34	OT34
35	Other35	OT35
36	Other36	OT36
37	Other37	OT37
38	Other38	OT38
39	Other39	OT39
40	Other40	OT40

THE FCC REGULATION WARNING (for U.S.A.)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CE mark for European Harmonized Standards

CE Mark which is attached to our company's products of Battery mains the product is in fully conformity with the harmonized standard(s) EN 61000-6-3:2007+A1:2011 & EN 61000-6-1:2007 Under the Council Directive 2004/108/EC on Electromagnetic Compatibility

©2014 Cherub Technology-All rights reserved. No part of this publication may be reproduced in any form without prior written permission of Cherub Technology.



Made in China