

DIGITAL KEYBOARD

OWNER'S MANUAL

EZ-300



Before using the instrument, be sure to read
“PRECAUTIONS” on pages 5-7.



FCC INFORMATION (U.S.A.)

1. IMPORTANT NOTICE: DO NOT MODIFY THIS UNIT!

This product, when installed as indicated in the instructions contained in this manual, meets FCC requirements. Modifications not expressly approved by Yamaha may void your authority, granted by the FCC, to use the product.

2. IMPORTANT:

When connecting this product to accessories and/or another product use only high quality shielded cables. Cable/s supplied with this product MUST be used. Follow all installation instructions. Failure to follow instructions could void your FCC authorization to use this product in the USA.

3. NOTE:

This product has been tested and found to comply with the requirements listed in FCC Regulations, Part 15 for Class "B" digital devices. Compliance with these requirements provides a reasonable level of assurance that your use of this product in a residential environment will not result in harmful interference with other electronic devices. This equipment generates/uses radio frequencies and, if not installed and used according to the instructions found in the users manual, may cause interference harmful to the operation of other electronic devices. Compliance with FCC regulations does not guarantee

that interference will not occur in all installations. If this product is found to be the source of interference, which can be determined by turning the unit "OFF" and "ON", please try to eliminate the problem by using one of the following measures:

Relocate either this product or the device that is being affected by the interference.

Utilize power outlets that are on different branch (circuit breaker or fuse) circuits or install AC line filter/s.

In the case of radio or TV interference, relocate/reorient the antenna. If the antenna lead-in is 300 ohm ribbon lead, change the lead-in to co-axial type cable.

If these corrective measures do not produce satisfactory results, please contact the local retailer authorized to distribute this type of product. If you can not locate the appropriate retailer, please contact Yamaha Corporation of America, Electronic Service Division, 6600 Orangethorpe Ave., Buena Park, CA90620

The above statements apply ONLY to those products distributed by Yamaha Corporation of America or its subsidiaries.

* This applies only to products distributed by Yamaha Corporation of America.

(class B)

COMPLIANCE INFORMATION STATEMENT (Supplier's declaration of conformity procedure)

Responsible Party : Yamaha Corporation of America
Address : 6600 Orangethorpe Ave., Buena Park, Calif. 90620
Telephone : 714-522-9011
Type of Equipment : Digital Keyboard
Model Name : EZ-300

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- 1) this device may not cause harmful interference, and
- 2) this device must accept any interference received including interference that may cause undesired operation.

* This applies only to products distributed by Yamaha Corporation of America.

(FCC SDoC)


The model number, serial number, power requirements, etc., may be found on or near the name plate, which is at the bottom of the unit. You should note this serial number in the space provided below and retain this manual as a permanent record of your purchase to aid identification in the event of theft.

Model No. _____

Serial No. _____

(bottom_en_01)

For the AC adaptor



Explanation of Graphical Symbols



The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated “dangerous voltage” within the product’s enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

IMPORTANT SAFETY INSTRUCTIONS

- 1 Read these instructions.
- 2 Keep these instructions.
- 3 Heed all warnings.
- 4 Follow all instructions.
- 5 Do not use this apparatus near water.
- 6 Clean only with dry cloth.
- 7 Do not block any ventilation openings. Install in accordance with the manufacturer’s instructions.
- 8 Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- 9 Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- 10 Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- 11 Only use attachments/accessories specified by the manufacturer.
- 12 Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
- 13 Unplug this apparatus during lightning storms or when unused for long periods of time.
- 14 Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.



WARNING

TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPARATUS TO RAIN OR MOISTURE.

(UL60065_03)

PRECAUTIONS

PLEASE READ CAREFULLY BEFORE PROCEEDING

Please keep this manual in a safe and handy place for future reference.

For the AC adaptor



WARNING

- This AC adaptor is designed for use with only Yamaha electronic instruments. Do not use for any other purpose.
- Indoor use only. Do not use in any wet environments.



CAUTION

- When setting up, make sure that the AC outlet is easily accessible. If some trouble or malfunction occurs, immediately turn off the power switch of the instrument and disconnect the AC adaptor from the outlet. When the AC adaptor is connected to the AC outlet, keep in mind that electricity is flowing at the minimum level, even if the power switch is turned off. When you are not using the instrument for a long time, make sure to unplug the power cord from the wall AC outlet.

For the instrument



WARNING

Always follow the basic precautions listed below to avoid the possibility of serious injury or even death from electrical shock, short-circuiting, damages, fire or other hazards. These precautions include, but are not limited to, the following:

Power supply/AC adaptor

- Do not place the power cord near heat sources such as heaters or radiators. Also, do not excessively bend or otherwise damage the cord, or place heavy objects on it.
- Only use the voltage specified as correct for the instrument. The required voltage is printed on the name plate of the instrument.
- Use the specified adaptor (page 94) only. Using the wrong adaptor can result in damage to the instrument or overheating.
- Check the electric plug periodically and remove any dirt or dust which may have accumulated on it.

Do not open

- This instrument contains no user-serviceable parts. Do not open the instrument or attempt to disassemble or modify the internal components in any way. If it should appear to be malfunctioning, discontinue use immediately and have it inspected by qualified Yamaha service personnel.

Water warning

- Do not expose the instrument to rain, use it near water or in damp or wet conditions, or place on it any containers (such as vases, bottles or glasses) containing liquids which might spill into any openings. If any liquid such as water seeps into the instrument, turn off the power immediately and unplug the power cord from the AC outlet. Then have the instrument inspected by qualified Yamaha service personnel.
- Never insert or remove an electric plug with wet hands.

Fire warning

- Do not put burning items, such as candles, on the unit. A burning item may fall over and cause a fire.

Battery

- Follow the precautions below. Failure to do so might result in explosion, fire, overheating or battery fluid leakage.
 - Do not tamper with or disassemble batteries.
 - Do not dispose of batteries in fire.

- Do not attempt to recharge batteries that are not designed to be charged.
- Keep the batteries separate from metallic objects such as necklaces, hairpins, coins, and keys.
- Use the specified battery type (page 94) only.
- Use new batteries, all of which are the same type, same model, and made by the same manufacturer.
- Always make sure all batteries are inserted in conformity with the +/- polarity markings.
- When the batteries run out, or if the instrument is not to be used for a long time, remove the batteries from the instrument.
- When using Ni-MH batteries, follow the instructions that came with the batteries. Use only the specified charger device when charging.
- Keep batteries away from small children who might accidentally swallow them.
- If the batteries do leak, avoid contact with the leaked fluid. If the battery fluid should come in contact with your eyes, mouth, or skin, wash immediately with water and consult a doctor. Battery fluid is corrosive and may possibly cause loss of sight or chemical burns.

If you notice any abnormality

- When one of the following problems occur, immediately turn off the power switch and disconnect the electric plug from the outlet. (If you are using batteries, remove all batteries from the instrument.) Then have the device inspected by Yamaha service personnel.
 - The power cord or plug becomes frayed or damaged.
 - It emits unusual smells or smoke.
 - Some object has been dropped into the instrument.
 - There is a sudden loss of sound during use of the instrument.
 - If any cracks or breakages exist on the instrument.



CAUTION

Always follow the basic precautions listed below to avoid the possibility of physical injury to you or others, or damage to the instrument or other property. These precautions include, but are not limited to, the following:

Power supply/AC adaptor

- Do not connect the instrument to an electrical outlet using a multiple-connector. Doing so can result in lower sound quality, or possibly cause overheating in the outlet.
- When removing the electric plug from the instrument or an outlet, always hold the plug itself and not the cord. Pulling by the cord can damage it.
- Remove the electric plug from the outlet when the instrument is not to be used for extended periods of time, or during electrical storms.

Location

- Do not place the instrument in an unstable position where it might accidentally fall over.
- Before moving the instrument, remove all connected cables, to prevent damage to the cables or injury to anyone who might trip over them.
- When setting up the product, make sure that the AC outlet you are using is easily accessible. If some trouble or malfunction occurs, immediately turn off the power switch and disconnect the plug from the outlet. Even when the power switch is turned off, electricity is still flowing to the product at the minimum level. When you are not using the product for a long time, make sure to unplug the power cord from the wall AC outlet.

- Use only the stand specified for the instrument. When attaching it, use the provided screws only. Failure to do so could cause damage to the internal components or result in the instrument falling over.

Connections


- Before connecting the instrument to other electronic components, turn off the power for all components. Before turning the power on or off for all components, set all volume levels to minimum.
- Be sure to set the volumes of all components at their minimum levels and gradually raise the volume controls while playing the instrument to set the desired listening level.

Handling caution

- Do not insert a finger or hand in any gaps on the instrument.
- Never insert or drop paper, metallic, or other objects into the gaps on the panel. This could cause physical injury to you or others, damage to the instrument or other property, or operational failure.
- Do not rest your weight on, or place heavy objects on the instrument, and do not use excessive force on the buttons, switches or connectors.
- Do not use the instrument/device or headphones for a long period of time at a high or uncomfortable volume level, since this can cause permanent hearing loss. If you experience any hearing loss or ringing in the ears, consult a physician.

Yamaha cannot be held responsible for damage caused by improper use or modifications to the instrument, or data that is lost or destroyed.

Always turn the power off when the instrument is not in use.

Even when the [] (Standby/On) switch is in standby status (display is off), electricity is still flowing to the instrument at the minimum level.

When you are not using the instrument for a long time, make sure you unplug the power cord from the wall AC outlet.

Make sure to discard used batteries according to local regulations.

NOTICE

To avoid the possibility of malfunction/ damage to the product, damage to data, or damage to other property, follow the notices below.

■ Handling

- Do not use the instrument in the vicinity of a TV, radio, stereo equipment, mobile phone, or other electric devices. Otherwise, the instrument, TV, or radio may generate noise. When you use the instrument along with an application on your smart device such as a smartphone or tablet, we recommend that you set "Airplane Mode" to on on that device in order to avoid noise caused by communication.
- Depending on the condition of surrounding radio waves, the instrument may possibly malfunction.
- Do not expose the instrument to excessive dust or vibrations, or extreme cold or heat (such as in direct sunlight, near a heater, or in a car during the day) to prevent the possibility of panel disfiguration, damage to the internal components or unstable operation. (Verified operating temperature range: 5° – 40°C, or 41° – 104°F.)
- Do not place vinyl, plastic or rubber objects on the instrument, since this might discolor the panel or keyboard.
- Do not press the LCD screen with your finger because it is a sensitive, precision-made part. Doing so might cause an appearance abnormality, such as a stripe on the LCD, although this abnormality should disappear again within a short time.

■ Maintenance

- When cleaning the instrument, use a soft cloth. Do not use paint thinners, solvents, alcohol, cleaning fluids, or chemical-impregnated wiping cloths.

■ Saving data

- Some of the data of this instrument (page 59) are retained when the power is turned off. However, the saved data may be lost due to some failure, an operation mistake, etc. Save your important data onto an external device such as a computer (page 57).

Information

■ About copyrights

- Copying of the commercially available musical data including but not limited to MIDI data and/or audio data is strictly prohibited except for your personal use.
- This product incorporates and bundles contents in which Yamaha owns copyrights or with respect to which Yamaha has license to use others' copyrights. Due to copyright laws and other relevant laws, you are NOT allowed to distribute media in which these contents are saved or recorded and remain virtually the same or very similar to those in the product.
 - * The contents described above include a computer program, Accompaniment Style data, MIDI data, WAVE data, voice recording data, a score, score data, etc.
 - * You are allowed to distribute medium in which your performance or music production using these contents is recorded, and the permission of Yamaha Corporation is not required in such cases.

■ About functions/data bundled with the instrument

- Some of the preset songs have been edited for length or arrangement, and may not be exactly the same as the original.
- The bitmap fonts used in this instrument have been provided by and are the property of Ricoh Co., Ltd.

■ About this manual

- The illustrations and LCD screens as shown in this manual are for instructional purposes only, and may appear somewhat different from those on your instrument.
- Windows is a registered trademark of Microsoft® Corporation in the United States and other countries.
- The company names and product names in this manual are the trademarks or registered trademarks of their respective companies.

Thank you for purchasing this Yamaha Digital Keyboard!

This instrument features a convenient lighting keyboard which makes it easy for beginners to play the keyboard. It also features a wide variety of built-in preset Songs, including pop and classical music, for your playing pleasure.

We recommend that you read this manual carefully so that you can fully take advantage of the advanced and convenient functions of the instrument.

We also recommend that you keep this manual in a safe and handy place for future reference.

About the Manuals

In addition to this Owner's Manual, the following Online materials (PDF files) are available.

■ Included Document



Owner's Manual

- **Setting Up:** This section explains how to set up and start using this instrument.
- **Quick Guide:** This section explains briefly how to use the basic functions.
- **Reference:** This section explains in detail how to use various functions.
- **Appendix:** This section includes specifications, Voice List, etc.

■ Online Materials (PDF)



Drum Kit List

This contains detailed information of the Drum Kit Voices (Voice No. 242-263; page 78). When you select these Voices, various drum, percussion and SFX sounds listed here are assigned to each key.



MIDI Reference

This contains MIDI-related information, such as the MIDI Implementation Chart.



Computer-related Operations

This contains instructions about computer-related functions.



Smart Device Connection Manual

This explains how to connect the instrument to smart devices, such as smartphones, tablet devices, etc.

To obtain these manuals, access the Yamaha Downloads, and then enter the model name for searching the desired files.

Yamaha Downloads <https://download.yamaha.com/>

NOTE

- For a general overview of MIDI and how you can effectively use it, search for "MIDI Basics" (only in English, German, French and Spanish) on the website above.



Song Book (only in English, French, German and Spanish)

This contains music scores for the preset Songs (excepting for a Demo Song and some Songs due to copyright issues) of this instrument.

To obtain this Song Book, access the Yamaha website and download it from the product web page.

Yamaha Global Site <https://www.yamaha.com>

Included Accessories

- Owner's Manual (this book)
 - Music rest
 - Online Member Product Registration
 - AC adaptor*
- * May not be included depending on your particular locale. Check with your Yamaha dealer.

Formats and functions



GM System Level 1

"GM System Level 1" is an addition to the MIDI standard which ensures that any GM-compatible music data can be accurately played by any GM-compatible tone generator, regardless of manufacturer. The GM mark is affixed to all software and hardware products that support GM System Level.



XGlite

As its name implies, "XGlite" is a simplified version of Yamaha's high-quality XG tone generation format. Naturally, you can play back any XG song data using an XGlite tone generator. However, keep in mind that some songs may play back differently compared to the original data, due to the reduced set of control parameters and effects.



Style File Format (SFF)

The Style File Format combines all of Yamaha's auto accompaniment know-how into a single unified format.



USB

USB is an abbreviation for Universal Serial Bus. It is a serial interface for connecting a computer with peripheral devices. It allows "hot swapping" (connecting peripheral devices while the power to the computer is on).



Touch Response

The exceptionally natural Touch Response feature gives you maximum expressive control over the level of the Voices.

Contents

PRECAUTIONS	5
NOTICE	7
Information	7
About the Manuals	8
Included Accessories	9
Formats and functions	9

Setting Up

Panel Controls and Terminals	12
---	-----------

Setting Up	14
-------------------------	-----------

Power Requirements	14
Turning the Power On	15
Setting the Auto Power Off function	15
Adjusting the Master Volume	16
Connecting Headphones or External Speaker	16
Using a Pedal (Footswitch)	16
Using the Music Rest	16

Display Items	17
----------------------------	-----------

Quick Guide

Basic Operations	18
-------------------------------	-----------

Transfer Your Favorite MIDI Song from the Computer to the Instrument	19
---	-----------

Practice Playing a Song Using Lesson Functions	20
---	-----------

Play with Rhythm and Accompaniment (Styles)	21
--	-----------

Record Your Performance	22
--------------------------------------	-----------

Use the Metronome	23
--------------------------------	-----------

Make Detailed Settings (Function Settings)	23
---	-----------

Reference

Playing a Variety of Instrument Voices	24
---	-----------

Selecting a Main Voice	24
Playing the “Grand Piano”	24
Using the Metronome	24
Adding a Layer – Dual Voice	25
Playing Different Voices with Your Left and Right Hands (Split)	25
Changing the Touch Response of the Keyboard	26
Applying Effects to the Sound	26
Adding Harmony or Arpeggio	28

Playing the keyboard with two persons (Duo mode)	30
---	-----------

Playing Songs	31
----------------------------	-----------

Selecting and Playing Back a Song	32
Playing Songs Repeatedly (BGM function)	33
Song Fast Forward, Fast Reverse, and Pause	33
Changing the Song Melody Voice	33
A-B Repeat	34
Turning Each Part On/Off	34
Transferring Songs from a Computer to this Instrument	34

Using the Song Lesson Feature	35
--	-----------

Lighting Keyboard (Light Guide Function)	36
Keys to Success	36
Phrase Repeat	38
Listening, Timing and Waiting	39

Learning How to Use “Touch” Control (Touch Tutor)	41
--	-----------

Hearing and Experiencing the Sound of the Chords (Chord Study)	42
---	-----------

Hear and experience a sound of a single chord ..	42
Hear and experience basic chord progressions ..	42

Playing Chords along with Chord Progressions of a Song	43
---	-----------

Play the chords in combination with “Waiting” of the Lesson function	43
--	----

Playing with Rhythm and Accompaniment (Styles) 44

Setting the Fingering Type	44
Setting the Smart Chord Key	44
Playing Styles	45
Style Variations	46
Chord Types for Style Playback.....	47
Chords Heard When Smart Chord is Selected ..	48
Looking Up Chords Using the Chord Dictionary ..	49
Using the Music Database	50
Registering a Style File	50

Recording Your Performance 51

Track Structure of a Song	51
Quick Recording	51
Recording to a Specified Track.....	52
Clearing a User Song.....	52

Memorizing Your Favorite Panel Settings 53

Recalling Panel Settings from the Registration Memory	53
Memorizing Panel Settings to the Registration Memory	54
Deleting the Registration Memory.....	54
Disabling Recall of Specific Items (Freeze)	54

Selecting an EQ Setting for your Favorite Sound 55

Connecting to Other Devices 56

Playing an External Audio Device with the Built-in Speakers	56
Connecting to a Computer	57
Connecting a Smart Device	58
Lowering the volume of a melody part (Melody Suppressor function)	58

Backup and Initialization 59

Backup Parameters	59
Initialization	59


The Functions 60

Appendix

Troubleshooting	64
Song Book Sample.....	66
Voice List	76
Standard Kit 1 List.....	82
Song List.....	83
Style List	85
Music Database List.....	87
Effect Type List.....	89
Specifications	93
Index	95

Panel Controls and Terminals

Front Panel




Music Database List
(page 87)

Song List
(page 83)


Display
(page 17)

Voice List
(page 76)

Style List
(page 85)



As illustrated, each note of the keyboard has a specific note number and name (e.g., 036/C1), which is used in making various settings, such as Split Point (page 45).



- 1 [⏻] (Standby/On) switch page 15
- 2 [MASTER VOLUME] dial page 16
- 3 [DEMO] button page 33
 - ⓪ BGM page 33
- 4 [METRONOME] button page 24
 - ⓪ TIME SIG. page 24
- 5 [TEMPO/TAP] button page 32

In the Lesson mode

- 6 PART
 - [L] button page 39
 - [R] button page 39

In the Recording mode

- 6 [REC TRACK 2] button page 52
- [REC TRACK 1] button page 52

- 7 [KEYS TO SUCCESS] button page 36
- 8 [PHRASE REPEAT] button page 38
- 9 [1 LISTENING 2 TIMING 3 WAITING] button page 39
 - ⓪ CHORD DICT. page 49

In the Song mode

- 10 [A-B REPEAT] button page 34
- 11 [REW] button page 33
- 12 [FF] button page 33
- 13 [PAUSE] button page 33

In the Style mode



- 10 [ACMP ON/OFF] button page 45
 - ⓪ SPLIT POINT page 60
- 11 [INTRO/ENDING/rit.] button page 46
- 12 [MAIN/AUTO FILL] button page 46
- 13 [SYNC START] button page 45

- 14 [START/STOP] button page 32
- 15 [REC] button page 51
 - ⓪ CLEAR page 52
- 16 [VOICE] button page 24
 - ⓪ SONG MELODY VOICE page 33
- 17 [SONG] button page 32
- 18 [STYLE] button page 45
- 19 Number buttons [0]–[9], [+ / YES], [- / NO] page 18
- 20 [PORTABLE GRAND] button page 24
- 21 [DSP] button page 26
 - ⓪ TYPE page 26
- 22 [ARTICULATION] button page 27
- 23 [REGIST MEMORY] button page 53
 - ⓪ MEMORY page 53

- 24 [FUNCTION] button page 60
 - ⓪ LIGHT GUIDE page 36
- 25 [MUSIC DATABASE] button page 50
- 26 [DUAL] button page 25
 - ⓪ DUAL VOICE page 25
- 27 [SPLIT] button page 25
 - ⓪ SPLIT VOICE page 25
- 28 [HARMONY/ARPEGGIO] button page 28
 - ⓪ TYPE page 28
- 29 Drum illustrations for the Drum Kit ... page 24

Each of these indicates the drum or percussion instrument assigned to the corresponding key for "Standard Kit 1."

Rear Panel



- 30 [SUSTAIN] jack page 16
- 31 [PHONES/OUTPUT] jack page 16
- 32 [AUX IN] jack page 56
- 33 [USB TO HOST] terminal page 57
- 34 DC IN jack page 14

Panel Setup (Panel Settings)

By using the controls on the panel, you can make various settings as described here. These settings of the instrument are together referred to as "panel setup" or "panel settings" in this manual.

The "Press and hold" Symbol

- ⓪ Buttons having this indication can be used to call up an alternate function when the relevant button is pressed and held. Hold down this button until the function is called up.


Setting Up

Power Requirements

Although the instrument will run either from an AC adaptor or batteries, Yamaha recommends use of an AC adaptor whenever possible. An AC adaptor is more environmentally friendly than batteries and does not deplete resources.

Using an AC Adaptor

Connect the AC adaptor in the order shown in the illustration.




WARNING

- Use the specified AC adaptor (page 94) only. Using the wrong AC adaptor can result in damage to the instrument or overheating.

WARNING

- When using the AC adaptor with a removable plug, make sure to keep the plug attached to the AC adaptor. Using the plug alone can cause electric shock or fire.
- If the plug is accidentally removed from the AC adaptor, slide it back in until it clicks into place, taking care to avoid touching any internal metal parts. To avoid electric shock, short circuit or damage, also be careful that there is no dust between the AC adaptor and plug.



CAUTION

- When setting up the product, make sure that the AC outlet you are using is easily accessible. If some trouble or malfunction occurs, immediately turn the power off and disconnect the plug from the outlet.

NOTE

- Follow the order shown above in reverse when disconnecting the AC adaptor.


Using Batteries

This instrument requires six "AA" size, Alkaline (LR6)/Manganese (R6) batteries, or rechargeable nickel-metal hydride batteries (rechargeable Ni-MH batteries). The Alkaline batteries or rechargeable Ni-MH batteries are recommended for this instrument, since other types may result in poorer battery performance.


WARNING

- When the batteries run out, or if the instrument is not to be used for a long time, remove the batteries from the instrument.

- 1 Make sure that the power of the instrument is off.
- 2 Open the battery compartment cover located on the instrument's bottom panel.



- 3 Insert the six new batteries, being careful to follow the polarity markings on the inside of the compartment.



- 4 Replace the compartment cover, making sure that it locks firmly in place.

Make sure to set the battery type correctly (page 15).

NOTICE

- Connecting or disconnecting the AC adaptor with batteries installed may turn the power off, resulting in loss of data being recorded or transferred at the time.
- When battery power becomes too low for proper operation, the volume may be reduced, the sound may be distorted, and other problems may occur. When this happens, make sure to replace all batteries with new ones or already recharged ones.

NOTE

- This instrument cannot charge the batteries. Use only the specified charger device when charging.
- Power will be automatically drawn from the AC adaptor if an AC adaptor is connected while batteries are installed in the instrument.

■ Setting the battery type


Depending on the battery type to be used, you need to change the battery type setting on this instrument. Alkaline (and manganese) batteries are chosen by default. After installing new batteries and turning the power on, make sure to set the Battery Type appropriately (rechargeable or not) via Function number 064 (page 63).

NOTICE

- Failure to set the battery type may shorten the amount of the battery life. Make sure to set the battery type correctly.

Turning the Power On

- 1 Turn down the [MASTER VOLUME] dial to "MIN."



- 2 Press the [⏻] (Standby/On) switch to turn the power on. The Voice name appears on the display. Adjust the volume as desired while playing the keyboard.
- 3 Press and hold the [⏻] (Standby/On) switch for about a second to set the instrument to standby mode.

⚠ CAUTION

- Even when the [⏻] (Standby/On) switch is in standby status, electricity is still flowing to the product at the minimum level. Remove the electric plug from the outlet when the instrument is not to be used for extended periods of time, or during electrical storms.

NOTICE

- Press only the [⏻] (Standby/On) switch when turning the power on. Any other operations such as pressing the pedal are not allowed. Doing so may cause the instrument to malfunction.

Setting the Auto Power Off function

To prevent unnecessary power consumption, this instrument features an Auto Power Off function that automatically turns the power off if the instrument is not operated for a specified period of time. The amount of time that elapses before the power is automatically turned off is 30 minutes by default; however, you can change the setting.

■ To set the time that elapses before Auto Power Off is executed:


Press the [FUNCTION] button several times until "AutoOff" (Function 063; page 63) appears, then use the [+ / YES] or [- / NO] button to select the desired value.

Settings: oFF, 5, 10, 15, 30, 60, 120 (minutes)

Default value: 30 (minutes)

■ To disable the Auto Power Off function:

Turn the power on while holding down the lowest key on the keyboard. A message "oFF AutoOff" appears briefly, then the instrument starts up with the Auto Power Off function disabled. The Auto Power Off function also can be disabled by selecting Off in Function number 063 (page 63).

**NOTICE**


- Depending on the instrument status, the power may not turn off automatically, even after the elapse of the specified period of time. Always turn off the power manually when the instrument is not in use.
- When the instrument is not operated for a specified period of time while connected to an external device such as an amplifier, speaker or computer, make sure to follow the instructions in the Owner's Manual to turn off the power to the instrument and the connected devices, in order to protect the devices from damage. If you do not want the power to turn off automatically when a device is connected, disable Auto Power Off.

NOTE

- Generally, the data and settings are maintained even when the power is turned off with the Auto Power Off function. For details, see page 59.

Adjusting the Master Volume


To adjust the volume of the entire keyboard sound, use the [MASTER VOLUME] dial while playing the keyboard.



CAUTION

- Do not use the instrument for a long period of time at a high or uncomfortable volume level, since this can cause permanent hearing loss.

Connecting Headphones or External Speaker



Connect a pair of headphones to the [PHONES/OUTPUT] jack. This jack also functions as an external output. By connecting to a computer, keyboard amplifier, recorder, or other audio device, you can output the audio signal of this instrument to that external device. The speakers of this instrument are automatically shut off when a plug is inserted into this jack.

CAUTION

- Do not use the instrument or headphones for a long period of time at a high or uncomfortable volume level, since this can cause permanent hearing loss.
- Before connecting the instrument to other electronic components, turn off the power of all the components. Also, before turning any components on or off, make sure to set all volume levels to minimum. Otherwise, damage to the components or electrical shock may occur.


NOTICE

- To avoid possible damage to the external device, first turn on the power to the instrument, then to the external device. When turning off the power, do so in reverse order: first turn off the power to the external device, then to the instrument.

NOTE

- When connecting the headphones or external speaker to the instrument, set the Master EQ (page 55) to "2 Headphone." The Master EQ can be set in Function settings (page 61; Function 025).

Using a Pedal (Footswitch)




You can control three functions: Sustain, Articulation (page 27), and Arpeggio (page 29) as you play by pressing a footswitch (FC5 or FC4A; sold separately) plugged into the [SUSTAIN] jack. By default, Sustain is assigned, so that the sound can be heard for a long time even if you take your finger off the keyboard while pressing the footswitch, like a damper pedal on a piano. To use a function other than Sustain, use the function settings (Function 029; page 61).

NOTE

- Plug or unplug the footswitch while the power is off. Also, do not press the footswitch when turning the power on. Doing so changes the polarity of the footswitch, resulting in reversed operation.
- The Sustain function does not affect Split Voices (page 25) or the Styles (Auto Accompaniment; page 44).

Using the Music Rest

Insert the music rest into the slots as shown.



Display Items

Function status

HARMONY
Harmony (page 28)

ARPEGGIO
Arpeggio (page 28)

DUAL Dual (page 25)

SPLIT Split (page 25)

DSP DSP (page 26)

DUO Duo (page 30)

S.Art Lite
Articulation (page 27)

Voice/Song/Style

▶ **VOICE** Voice selection mode

▶ **SONG** Song mode

▶ **STYLE** Style mode

* The mark ▶ next to the mode name indicates which mode is activate and whose contents can be selected with the number buttons or [+ / YES] / [- / NO] buttons.

* **VOICE** is always shown, even when in the Song or Style mode.

Registration Memory


REGIST

1	2	3
4	5	6
7	8	9

(page 53)

Touch Indication


TOUCH Touch Response (page 26)



Strength Meter

■ is a meter that lights up according to the strength with which you play the keyboard. (pages 26, 41)

■ represents the target strength when practicing with Songs in the "Touch Tutor" category. (page 41)



Lesson Indication

This area indicates the Lesson related status is on.

■ ■ ■ ■ ■ Keys to Success (page 36)

PHRASE Phrase Repeat (page 38)
Chord Progression (page 43)

★ ★ ★ Indicates the Passing Status (page 37) of the Keys to Success Lesson.

Chord

Indicates the chord which is played on the Auto Accompaniment range (page 45) of the keyboard, or specified via Song playback. [

Measure or Function

Normally indicates the current measure number of the current Style or Song. When the [FUNCTION] button (page 60) is in use, this indicates the Function number.


MEASURE 003
FUNCTION 027

Beat

Indicates the current beat of playback. ▶▶▶▶▶

Keyboard Display

Indicates notes currently being played (same as the lighting keyboard). Indicates the melody and chord notes of a Song when the Song Lesson function is in use. Also indicates the notes of a chord—either when playing a chord or when using the Dictionary function.



Song Track status

Indicates the on/off status of Song playback or target Track of Song recording (pages 34, 52).

L **R**

R Lit: Track contains data

R Unlit: Track is muted or contains no data

R Flashing: Track is selected as recording track

A-B Repeat

Appears when the A-B Repeat function is active. (page 34) A B


Auto Accompaniment

Appears when the Auto Accompaniment function is on. (page 45) ACMP

Basic Operations

This instrument features three basic functions: Voice, Song, and Style. This section shows you how to use these three functions and how to use the number buttons and [+ / YES], [- / NO] buttons which are useful for various functions.

1 Press one of the following buttons to select a basic function.




The above operation calls up the name and number of the current Voice, Song, or Style, and shows it in the display.

2 Select a Voice, Song, or Style by using the number buttons [0]–[9], [+ / YES], [- / NO].

■ Number buttons [0]–[9]


The Number buttons can be used to directly enter a Voice, Song, or Style number or parameter value.

Example: Selecting Voice 003, Bright Piano



■ [+ / YES], [- / NO] buttons

Press the [+ / YES] button briefly to increase the value by 1, or press the [- / NO] button briefly to decrease the value by 1. Press and hold either button to continuously increase or decrease the value in the corresponding direction. Pressing both buttons simultaneously lets you reset a parameter to the default value.



3 Start playing the Voice, Song or Style that you selected.

Voice..... Play the keyboard.

Pressing the [PORTABLE GRAND] button will reset the Voice settings to the Grand Piano Voice (Voice No.001 Live!ConcertGrandPiano).



Song..... Press the [START/STOP] button to start Song playback.

Style..... Press the [START/STOP] button to start only the rhythm part.


For instructions on playing the chord accompaniment part etc., refer to page 45.

Transfer Your Favorite MIDI Song from the Computer to the Instrument

→ Page 57

Windows10 is used for the examples in this manual.

- 1 Connect the [USB TO HOST] terminal (page 13) on rear panel of this instrument and the computer via a USB cable.




- 2 Press the [+ / YES] button in the function settings (Storage; Function 059; page 63) to turn the “Storage Mode” on.




- 3 Copy your favorite song file from the computer to the instrument folder on the computer display.

For other important information about copying files, refer to “Computer-related Operations” on the website (page 8).



- 4 After copying is completed, remove the instrument drive from the computer.



- 5 Disconnect the USB cable connecting the instrument to the computer.
- 6 Press the [- / NO] button in the same function settings as in step 2 to turn the “Storage Mode” off.
- 7 Start playback of the transferred Song (Song No. 208 –).

For instructions on playing back a Song, refer to page 32.


Practice Playing a Song Using Lesson Functions

→ Page 35

This instrument features the following Lesson functions. Select and practice your favorite preset Songs, and improve your playing skills with the Song Book, which includes the music scores of the preset Songs, or important points for “Keys to Success,” etc.

Keys to Success

You can select just the key phrases of the Song - the ones you like most or need to work on - and practice them one by one. Enjoy this Lesson by passing and completing each step.



Select the Song you want to learn, and then press the [KEYS TO SUCCESS] and [START/STOP] buttons to start Lesson.



Phrase Repeat

This lets you practice difficult phrases repeatedly. It's ideal for use as a final practice before you go on to the last Step to try to pass in the Keys to Success mode, or when you just want to practice a difficult phrase repeatedly.

Listening, Timing and Waiting

You can practice the preset Songs in the following three steps, independently for the right or left hand, or both hands.

These three lessons can be used with Keys to Success or Phrase Repeat. If you feel it difficult to play the specific phrase in Keys to Success, use the Waiting lesson to have the phrase pause until you play the correct note (page 39).

- **Lesson 1 (Listening)** Listen to the model melody/chords of the part you selected carefully and remember it well.
- **Lesson 2 (Timing)** Play the notes with the correct timing.
- **Lesson 3 (Waiting)** Play the correct notes.

Select the Song you want to learn, and then press the [1 LISTENING 2 TIMING 3 WAITING] button to start your desired Lesson.



Play with Rhythm and Accompaniment (Styles)


→ Page 44

This instrument includes an Auto Accompaniment feature that automatically plays appropriate “Styles” (rhythm + bass + chord accompaniment), controlled simply by playing only the root note of a chord. These Styles give you automatic, fingertip control of a full backing band.

- 1 Press the [STYLE] button.




- 2 Use the number buttons [0]–[9], [+ / YES], [- / NO] buttons to select the desired Style.
- 3 Press the [ACMP ON/OFF] button to turn on the Auto Accompaniment.




- 4 Press the [SYNC START] button to turn Synchro Start on.

This puts the Style playback in “standby” and Style starts playing back when you play the keyboard.




- 5 Press the [INTRO/ENDING/rit.] button.

An Intro part is added before starting Style playback.



- 6 Play the root note of a chord with your left hand in the Auto Accompaniment range to start Style playback.



- 7 Play the root note of a chord with your left hand and the melody part with your right hand.
- 8 Press the [INTRO/ENDING/rit.] button to stop Style playback.


The Ending part is added before stopping Style playback.

Record Your Performance

→ Page 51

You can record your performance.

- 1 Make the necessary settings, such as Voice selection, etc.
- 2 Press the [REC] button to enter the Record Ready mode.



Press the [REC] button to exit from the Record Ready mode.

- 3 Play the keyboard to start recording.
- 4 Press the [START/STOP] button to stop recording.



- 5 To play back the recorded Song, press the [START/STOP] button.

Use the Metronome

→ Page 24

- 1 Press the [METRONOME] button to start the Metronome.



- 2 Press the [METRONOME] button again to stop the Metronome.

Pressing the [TEMPO/TAP] button enables you to adjust the Metronome tempo.

Make Detailed Settings (Function Settings)

→ Page 60

After learning how to use this instrument, use the [FUNCTION] button to set various parameters. This instrument contains 64 settings. Each time you press the [FUNCTION] button, the setting item is selected in sequence, and the value of the selected item can be changed by using the number buttons [0]–[9], and [+ /YES], [- /NO] buttons.



You can select the setting items by simultaneously holding down the [FUNCTION] button and pressing the [+ /YES] or [- /NO] button.

When the Function settings display does not appear, press one of the [VOICE], [SONG] or [STYLE] buttons, and then press the [FUNCTION] button again.

Pressing one of the [VOICE], [SONG] or [STYLE] buttons also lets you exit from the Function settings.

Lighting Keyboard (Light Guide function)

This instrument features the Light Guide function which makes the keys you press or those specified by Song data light. Although this function is turned on by default, you can turn the function off by holding down the [FUNCTION] button for longer than a second.


Playing a Variety of Instrument Voices

In addition to piano, organ, and other “standard” keyboard instruments, this instrument has a large range of Voices that includes guitar, bass, strings, sax, trumpet, drums and percussion, and even sound effects—giving you a wide variety of musical sounds.

Selecting a Main Voice

1 Press the [VOICE] button.

The Voice number and name will be shown.



NOTE

- VOICE is always displayed with SONG or STYLE. For details, refer to page 17.


2 Use the number buttons [0]–[9], [+ / YES], [- / NO] buttons to select the desired Voice.

Refer to the Voice List on page 76.



Select the Voice you want to play

3 Play the keyboard.



Preset Voice Types

001–241	Instrument Voices (including sound effects).
242–263 (Drum Kit)	Various drum and percussion sounds are assigned to individual keys, from which they can be played. Details on the instruments and key assignments of each Drum Kit can be found in the Standard Kit 1 List on page 82 and “Drum Kit List” on the website (page 8).
264–283	Arpeggios are automatically reproduced by simply playing the keyboard (page 28).
284–622	XGlite Voices (page 79)
000	One Touch Setting The One Touch Setting feature automatically selects the most suitable Voice when you select a Style or Song (excepting the Song inputted from other devices). Simply select Voice number “000” to activate this feature.

Playing the “Grand Piano”

When you want to reset various settings to default and simply play a Piano sound, press the [PORTABLE GRAND] button.



The Voice “001 Live!ConcertGrandPiano” will automatically be selected as the Main Voice.

Using the Metronome

The instrument features a built-in Metronome (a device that keeps an accurate tempo), convenient for practicing.

1 Press the [METRONOME] button to start the Metronome.



2 Press the [METRONOME] button again to stop the Metronome.

To change the Tempo:

Press the [TEMPO/TAP] button to call up the Tempo value, then use the number buttons [0]–[9], [+ / YES], [- / NO].



Current Tempo value

Press the [+ / YES] and [- / NO] buttons simultaneously to instantly reset the value to the default tempo.

To set the Time Signature:

Press and hold the [METRONOME] button to call up “TimeSigN” (Function 030; page 62), then use the number buttons, [+ / YES] and [- / NO] buttons.


To set the Metronome Volume:

This can be set via Function number 032 (page 62).

Adding a Layer – Dual Voice

In addition to the Main Voice, you can layer a different Voice over the entire keyboard as a “Dual Voice.”


- 1 Press the [DUAL] button to turn on the layer.



NOTE

- Pressing and holding the [DUAL] button for longer than a second calls up “D. Voice,” allowing you to select a different Dual Voice.

- 2 Play the keyboard.



- 3 To exit from the layer, press the [DUAL] button again.


To select a different Dual Voice:

Although turning on Dual will select a Dual Voice suitable for the current Main Voice, you can easily select a different Dual Voice by pressing and holding the [DUAL] button to call up “D.Voice” (Function 008; page 61), then using the number buttons [0]–[9], [+ / YES], [- / NO].

Playing Different Voices with Your Left and Right Hands (Split)

By dividing the keyboard into the two separate areas, you can play one Voice with your left hand and a different Voice with your right.


Furthermore, you can play both a Main Voice and Dual Voice in the right-hand area of the keyboard while playing a different Voice (called “Split Voice”) in the left-hand area.



The highest key for the left-hand area is referred to as the “Split Point” (Function 003; page 60) which can be changed from the default F#2 key.

- 1 Press the [SPLIT] button to turn on the Split function.

The keyboard is divided into the left- and right-hand areas.



NOTE

- Pressing and holding the [SPLIT] button for longer than a second calls up “S. Voice,” allowing you to select a different Split Voice.

- 2 Play the keyboard.



- 3 To exit from the Split function, press the [SPLIT] button again.

To select a different Split Voice:



Press and hold the [SPLIT] button to call up “S.Voice” (Function 012; page 61), then use the number buttons [0]–[9], [+ / YES], [- / NO].

Changing the Touch Response of the Keyboard

The keyboard of this instrument is equipped with a Touch Response feature that lets you dynamically and expressively control the level of the Voices according to your playing strength.

1 Press the [FUNCTION] button several times until "TouchRes" (Function 004; page 60) appears.

After a few seconds, the current Touch Response appears.



[TOUCH] Appears when the Touch Response is not "Fixed."

2 Use the number buttons [1]–[4], [+ / YES], [- / NO] buttons to select a Touch Response setting between 1 and 4.

Touch Response

1	Soft	Produces relatively high volume even with light playing strength. Best for players with a light touch who want to maintain a consistent, relatively loud volume.
2	Medium	Produces a fairly "standard" keyboard response.
3	Hard	The keys must be played very strongly to generate loud volume. This setting is best for a wide dynamic range and optimum expressive control of the sound, from pianissimo to fortissimo.
4	Fixed	All notes are produced at the same volume no matter how hard the keyboard is played.

3 Play the keyboard.

The strength meter will light according to the strength with which you play the keyboard.

When you play softly. ■■■■■■■■

When you play at medium strength. ■■■■■■■■

When you play strongly. ■■■■■■■■

NOTE

• When the Touch Response is "Fixed," the strength meter is at fixed medium strength.

Applying Effects to the Sound

This instrument can apply various Effects as listed below to the instrument's sound.


• DSP

The DSP (digital signal processor) is an effect in which digital signal processing is applied to the sound to change it.

There are various types of DSP. When the DSP is turned on, the most suitable type will be selected for the current Main Voice. If you want to select a specific type, use operation steps 2 and 3 below.

For details on DSP types, refer to page 91.

1 Check whether the DSP is ON or not. If the "DSP" icon is not shown on the display, press the [DSP] button.




Depending on the selected Voice, the DSP may automatically be turned on.

NOTE

- The DSP is only applied to the Main Voice. It is not applied to the Dual Voice (page 25) or Split Voice (page 25).
- The DSP cannot be turned on during Lessons.

2 Hold down the [DSP] button for longer than a second to call up "DSPType" (Function 023; page 91). After a few seconds, the current DSP type appears.



3 Use the number buttons [0]–[9], [+ / YES], [- / NO] buttons to select the desired type.

4 Play the keyboard.

5 Press the [DSP] button again to turn off the DSP.

● **Articulation**

Articulation is an effect that reproduces the playing methods that are unique to specific instruments. The Articulation effect is applied to notes you play only while holding down the [ARTICULATION] button. The Voice to which the Articulation effect is applied is called “S. Art Lite Voice” (Super Articulation Lite Voice). The S. Art Lite Voices have the added indication “****” in the Voice List (page 76).

Examples of the Articulation effect

If you select a guitar Voice, you can realistically reproduce the following guitar-specific playing techniques.

Example: Voice number 044 “S.Art Lite Nylon Guitar Harmonics”

Playing the keyboard while holding down the [ARTICULATION] button produces harmonics sounds.

Example: Voice number 048 “S.Art Lite Distortion Guitar”

Pressing the [ARTICULATION] button produces a scratching noise.

Only when an S. Art Voice is selected, the most suitable Articulation effect is automatically applied to the Voice.


When other Voices are selected, the modulation effect is applied to the Voices.

- 1 Select the desired S. Art Lite Voice.

Appears when the S.Art Lite Voice is selected



- 2 Press the [ARTICULATION] button while playing the keyboard.



Release the [ARTICULATION] button to turn Articulation off.

Adding the Articulation effect by using the pedal

If you assign the Articulation function to the pedal (footswitch) with “PdIFunc” (Function 029; page 61), you can apply the effect by pressing the pedal.

NOTE

- The Articulation effect is applied only to a Main Voice.
- S.Art Lite Voices sound differently depending on the velocity, etc.

● **Reverb**

Adds the ambience of a club or concert hall to the sound. Although the best-suited Reverb type is called up by selecting a Song or Style, you can select another one via Function number 020 (page 61). When you select “oFF,” the Reverb effect is turned off. And you can also set the Reverb level via Function number 021 (page 61).

● **Chorus**

Makes the Voice sound richer, warmer and more spacious. Although the best-suited Chorus type is called up by selecting a Song or Style, you can select another one via Function number 022 (page 61). When you select “oFF,” the Chorus effect is turned off. You can also set the Chorus depth for Voices via Function numbers 007 (page 60), 011, 015 (page 61).

The Chorus depth cannot be applied to the Styles or Songs.

● **Sustain**

By turning on the Sustain parameter of Function number 024 (page 61), you can add a fixed, automatic sustain to the Main/Dual Voices played on the keyboard. Or, you can produce a natural sustain as desired with the footswitch (sold separately; page 16).

NOTE

- Even if you turn on Sustain, there are some Voices to which sustain is not applied.


Adding Harmony or Arpeggio

You can add harmony or arpeggio notes to the Voice played on the keyboard.

By specifying the Harmony Type, you can apply harmony parts, such as duet or trio, or add tremolo or echo effects to the played sound of the Main Voice.

Also, when the Arpeggio Type is selected, arpeggios (broken chords) are automatically played back when you simply play the appropriate notes on the keyboard. For example, you could play the notes of a triad—the root, third, and fifth—and the Arpeggio function will automatically create a variety of interesting phrases.

- 1 Press the [HARMONY/ARPEGGIO] button to turn on the Harmony or Arpeggio function.



When the Harmony or the Arpeggio is turned on, the most suitable one will be selected for the current Main Voice.


If you want to select a specific type, select it by the operation steps 2 and 3 at right.

NOTE

- The Harmony effect can be added to only the Main Voice.
- When selecting a Voice number between 264 and 283, the Arpeggio function will automatically be turned on.
- When selecting a Harmony Type between 001 and 005, the harmony effect will only be added to your right-hand melody play if you turn on the Style (page 45) and press chords in the auto accompaniment range of the keyboard.

- 2 Hold down the [HARMONY/ARPEGGIO] button for longer than a second so that “Harm/Arp” (Function 026; page 61) appears on the display.

After “Harm/Arp” is shown for a few seconds, the current type appears.



- 3 Use the number buttons [0]–[9], [+ / YES], [- / NO] buttons to select the desired type.

When you want to specify a Harmony Type, refer to the Harmony Type list on page 89; to specify an Arpeggio Type, refer to the Arpeggio Type list on page 90.


NOTE

- When playing one of the Arpeggio Types 143 to 176, select the corresponding Voice below as the Main Voice.
 143–173: Drum Kit Voices (Voice No. 242–252)
 174 (China): StdKit1 + Chinese Perc. (Voice No.253)
 175 (Indian): Indian Kit 1 (Voice No.254) or Indian Kit 2 (Voice No. 255)
 176 (Arabic): Arabic Kit (Voice No. 259)

- 4 Press a note or notes on the keyboard to trigger the Harmony or Arpeggio.

When a Harmony Type is selected, a harmony part (for example, duet or trio) or an effect (for example, tremolo or echo) can be added to the played sound of the Main Voice.

Also, when an Arpeggio Type is selected, arpeggios (broken chords) are automatically played back when you simply play the appropriate notes on the keyboard. The particular arpeggio phrase differs depending on the number of pressed notes and the area of the keyboard.



- 5 To turn the Harmony or Arpeggio off, press the [HARMONY/ARPEGGIO] button again.

How to play the various Types

The method of sounding the Harmony effect (01–26) differs depending on the selected type. For Types 01–05, turn the Auto Accompaniment on and play it by pressing a chord in the auto accompaniment section of the keyboard, then play some keys in the right-hand side to produce the Harmony effect. For Types 06–26, turning auto accompaniment on or off has no effect. However, it is necessary to play two notes simultaneously for Types 06–12.

- Harmony Type 001 to 005



Press the right-hand keys while playing chords in the auto accompaniment range of the keyboard when Auto Accompaniment is on (page 45).

- Harmony Type 006 to 012 (Trill)



Hold down two keys.

- Harmony Type 013 to 019 (Tremolo)



Keep holding down the keys.

- Harmony Type 020 to 026 (Echo)



Play the keys.

- Arpeggio Type 027 to 176

When Split is off:



Arpeggio function applies to the Main Voice and the Dual Voice.

When Split is on:



Arpeggio function applies only to the split Voice.

NOTE

- Arpeggio cannot be applied to the Split and Main/Dual Voices simultaneously.
- Selecting a Voice number between 274 and 283 as the Main Voice will turn on Arpeggio and Split automatically.

To adjust the Harmony Volume:

This can be adjusted via Function number 027 (page 61).

To adjust the Arpeggio Velocity:

This can be adjusted via Function number 028 (page 61).

Holding the Arpeggio Playback via the Pedal (Footswitch) (Hold)

You can set the instrument so that Arpeggio playback continues even after the note has been released, by pressing the pedal connected to the [SUSTAIN] jack.

- 1 Press a [FUNCTION] button a number of times until the “PdIFunc” (Function 029; page 61) item appears on the display.

After “PdIFunc” is shown for a few seconds, the current setting is shown.



- 2 Select the desired function by using the number buttons [1]–[3] or [+ /YES], [- /NO] buttons. (In this case, number button [2] to select “Arp Hold.”)

If you want to restore the pedal function to sustain, select “Sustain.” If you want to use both hold and sustain functions, select “Sus+ArpH.”



- 3 Try playing the keyboard with Arpeggio playback using the pedal.

Even if you release the notes, Arpeggio playback will continue. To stop Arpeggio playback, release the footswitch.

Playing the keyboard with two persons (Duo mode)

When the Duo mode is activated on this instrument, two different players can play the instrument simultaneously, with the same sound, over the same octave range—one person on the left and the other on the right. This is useful for learning applications, in which one person (a teacher, for example) plays a model performance and the other person watches and practices while sitting at the first person's side.


1 Press a [FUNCTION] button several times until “DuoMode” (Function 051; page 63) appears on the display.

2 Use the [+ / YES] button to select “on.”
The F#3 key becomes the Duo Split Point and the keyboard is divided into two sections: one for the left Voice and one for the right Voice.



DUO Appears when the Duo is turned on.

Duo Split Point
default setting: 066 (F#3)



NOTE

- The right Voice section and the left Voice section of the keyboard are both set to the same Voice (Main Voice).
- The Duo Split Point can be changed via Function number 053 (page 63) by holding down the [ACMP ON/OFF] button for longer than a second.

3 One person can play the left Voice section of the keyboard while the other plays the right Voice section.

4 To exit from Duo mode, select “oFF” via “DuoMode” (Function 051; page 63) by executing steps 1.

Changing the Left Voice

Only the left Voice can be changed via “DuoLVC” (Function 052; page 63).

NOTE

- When playing different Voices between the left and right, the right Voice name is shown in the display.
- Certain functions such as Lesson, Harmony/Arpeggio and Dual cannot be used in the Duo mode.

How sounds are output in the Duo mode

The performance sound of the left Voice will sound from the left speaker, and the performance sound of the right Voice will sound from the right speaker, in the initial Duo mode setting (“Separate”). This output setting can be changed from the “DuoType” setting (Function 058; page 63).

NOTE

- In the Duo mode, the pan, volume and tonal characteristics of the stereo sound may differ from those in the normal mode, due to the setting of DuoType = “Separate” (page 63). Particularly with Drum Kits, the difference may be more obvious, since each key of a Drum Kit features a different stereo pan position.

Using sustain in the Duo mode

Sustain can be applied to the left and right Voice sections in Duo mode just as it normally is by using one of the following methods in the Duo mode like the usual mode.

- Press the footswitch (page 16) connected to the [SUSTAIN] jack.
- Set “Sustain” (Function 024; page 61) to on. Sustain is applied to all notes.

NOTE

- Sustain cannot be applied independently to the left Voice section and the right Voice section.
- While Sustain is set to on via Function 024, the setting of hold is maintained even when the power is turned off.

Playing Songs

You can simply enjoy listening to the internal Songs, or use them with just about any of the functions, such as Lesson.

● Song Category


The Songs are organized by category as listed below.

Song No.	Song Category	Descriptions
001	DEMO	This demonstration Song showcases the various sounds of the instrument.
002–011	POP	This category features a collection of hit songs. Have fun playing your favorite song.
012–042	FAVORITE	We've collected various folk songs from around the world which have been handed down from through the generations, as well as famous classical pieces. Try playing the melodies of these Songs.
043–051	INSTRUMENT MASTER	These Songs feature solo instruments other than piano—letting you enjoy playing other instrumental voices along with orchestral accompaniment.
052–074	PIANO REPERTOIRE	These include famous pieces from around the world along with well-known piano pieces. Enjoy the beautiful, resonant piano sound as you play solo or along with orchestral backing.
075–090	LEARN TO PLAY	Each of these Songs has two variations: a simple one which even beginners can practice with ease, and another more challenging version.
091–110	FAVORITE WITH STYLE	Enjoy performing a piece with Style accompaniment (automatic accompaniment data). (Keys to Success (page 36) is designed so that you master playing the melody with your right hand first, and then learn the roots of the chords with your left hand.)
111–116	JAPANESE SONG	This category features a collection of songs that are well-known in Japan and have been enjoyed for generations. Experience these traditional melodies for yourself.
117–129	DUET	Get together with a friend or family member and make great music together. (The Songs have been arranged so that it is also possible to perform them alone.)
130–140	PIANO SOLO	This category features a collection of well-known classical piano compositions. Enjoy the beautiful sounds of the piano.
141–150	TOUCH TUTOR	Learn how to use expressive “touch” control while playing the keyboard according to the strength level displayed in the LCD.
151–162	CHORD STUDY	Hear and experience the sound of chords and easy chord progressions while playing the lighting keyboard.
163–202	CHORD PROGRESSION	Learn how to play chords with Songs featuring simple, fundamental chord progressions.
203–207	USER SONG	Songs (User Songs) you record yourself.
208–	FLASH MEMORY	Songs transferred from a computer. For instructions on how to transfer, refer to page 19 or “Computer-related Operations” on the website (page 8).

Selecting and Playing Back a Song

- 1 Press the [SONG] button, and then use the number buttons [0]–[9], [+ / YES], [- / NO] to select the desired Song.

Refer to the Song List (page 83).




- 2 Press the [START/STOP] button to start playback.

To stop playback, press the [START/STOP] button again.



Changing the Tempo

Press the [TEMPO/TAP] button to call up the Tempo value, then use the number buttons, [- / NO] and [+ / YES] buttons to adjust the Tempo value.



Press the [+ / YES] and [- / NO] buttons simultaneously to reset the value to the default tempo of the current Song or Style (page 44).

Using the Tap function:

While a Song or Style is playing back, press the [TEMPO/TAP] button just twice at the desired tempo to change the tempo. While Song or Style playback is stopped, tap the [TEMPO/TAP] button several times to start playback at the tapped tempo—four times for a 4-beat Song or Style or three times for a 3-beat Song or Style.



Adjusting the Song Volume


To adjust the volume balance between Song playback and keyboard, you can adjust the Song Volume. This can be set via Function number 019 (page 61).

Playing Songs Repeatedly (BGM function)

With the default setting, pressing the [DEMO] button will play back only 11 Songs (Song No. 001–011) repeatedly. This setting can be changed so that, for example, all internal Songs automatically play back, letting you use the instrument as a background music source.

1 Hold down the [DEMO] button for longer than a second.

“DemoGrp” (Function 061; page 63) is shown in the display for a few seconds, followed by the current repeat playback target.



2 Use the [+ / YES] or [- / NO] button to select a playback group.

1	Demo	Preset Songs (001–011)
2	Preset	All preset Songs (001–140)
3	User	All User Songs (203–207)
4	Download	All Songs transferred from a computer (208–)

NOTE 1

- When User Songs and Download Songs data do not exist, Demo Songs are played back.

3 Press the [DEMO] button to start playback.


To stop playback, press the [DEMO] button again or press the [START/STOP] button.

Random Song Playback

When the Demo Group (above) is set to something other than “Demo,” the playback order via the [DEMO] button can be changed between numerical order and random order. To do this, press the [FUNCTION] button several times until “PlayMode” (Function 062; page 63) is called up, then select “Normal” or “Random.”

Song Fast Forward, Fast Reverse, and Pause

Like the transport controls on an audio player, this instrument lets you fast forward (FF), rewind (REW) and pause (PAUSE) playback of the Song.



NOTE 1

- When the A-B repeat (page 34) is specified, the Fast Reverse and Fast Forward will only work within the range between A and B.
- [REW], [FF] and [PAUSE] button cannot be used during Song playback by using the [DEMO] button.

Changing the Song Melody Voice

You can change a Song's melody Voice to any other desired Voice.

- 1 Select and play back a Song.
- 2 Select the desired Voice.
- 3 Press and hold the [VOICE] button for longer than a second.


“SONG MELODY VOICE” appears in the display for a few seconds, and the selected Voice replaces the Song's original melody Voice.

NOTE 1

- You can change the melody Voice even when the Song playback is stopped.
- Selecting another Song will cancel the changed Melody Voice.
- You cannot change the melody Voice of a User Song.

A-B Repeat

You can play back only a specific section of a Song repeatedly by setting the A point (start point) and B point (end point) in one-measure increments.



- 1 Start playback of the Song (page 32).
- 2 When playback reaches to the point you want to specify as the start point, press the [A-B REPEAT] button to set the A point.



- 3 When playback reaches to the point you want to specify as the end point, press the [A-B REPEAT] button again to set the B point.

The specified A-B section of the Song will now play repeatedly.

NOTE

- You can also set the A-B Repeat function when the Song is stopped. Simply use the [REW] and [FF] buttons to select the desired measures, pressing the [A-B REPEAT] button for each point, then start playback.
- If you want to set the start point "A" at the top of the Song, press the [A-B REPEAT] button before starting playback.

- 4 To cancel repeat playback, press the [A-B REPEAT] button.


To stop playback, press the [START/STOP] button.

NOTE

- The A-B Repeat function will be canceled when you select another Song.

Turning Each Part On/Off

As indicated above the panel buttons (shown below), Songs other than Song numbers 163–202 consist of two parts; L and R, which can be turned on or off individually by pressing the corresponding button, L or R.



- When a User Song (number 203-207; page 51) is selected

The L and R indicators light when the tracks contain data, and are unlit when a track is muted or contains no data.

- When Songs other than a User Song is selected

The L and R indicators always light regardless of whether a track contains data or not.

By turning the left- and right-hand parts on or off during playback, you can listen to the Part (that is turned on), or practice the other part (that is turned off) on the keyboard.

NOTE

- Selecting another Song will cancel the on/off status of the Parts.

Transferring Songs from a Computer to this Instrument

By using a USB cable to connect the [USB TO HOST] terminal of this instrument to a computer, you can transfer song files from the computer.

For details, refer to the "Connecting to a Computer" on page 57.

Using the Song Lesson Feature


Use these convenient features to practice the preset Songs and improve your playing skills. The Lessons are arranged for optimum, enjoyable learning, so select the one suitable for you and take your keyboard skills higher, step by step.

You can refer to the music score in the Song Book (free downloadable scores). To obtain the Song Book, access the Yamaha website and download it from the product web page.
<https://www.yamaha.com>

Keys to Success

(Page 36)

You can select just the key phrases of the Song—the ones you like most or need to work on—and practice them one by one. This lesson is ideal for beginning players.




Each Song consists of several Steps. Each time you play all the way through the current Step, your performance will be evaluated. A score of "60" or more indicates that you passed this Step and you should try the next Step, which begins automatically.

The passing status ★ is saved, but you can go on to next Step even when you didn't pass the Step, or you can retry the Step later.

Phrase Repeat

(Page 38)

You can practice two or more phrases at once repeatedly by specifying them, as desired. This is ideal as a finishing practice before you try a last (finishing) Step to pass in the Keys to Success mode, or when you just want to practice the difficult phrase(s) repeatedly.




Listening, Timing and Waiting

(Page 39)

You can practice the preset Songs in three steps, independently for the right or left hand, or both hands together. This is ideal when you want to practice all the way through the Song with the selected part.

- **Lesson 1 (Listening)** Listen to the playback part you will play. Remember it as best as you can.
- **Lesson 2 (Timing)** Learn to play the notes with the correct timing. Even if you play wrong notes, the correct notes will sound.
- **Lesson 3 (Waiting)** Learn to play the correct notes. The Song pauses until you play the right note.



You can combine the Keys to Success lesson (page 36) and Phrase Repeat lesson (page 38) with the Listening, Timing or Waiting lesson (page 40). If you feel it difficult to play the specific phrase in the Keys to Success lesson, use Listening, Timing or Waiting lesson to listen to the phrase, to practice only the timing to play, or to let the phrase pause until you play the correct notes.

In addition, various learning functions are provided for your enjoyable playing experience as follows:

- Touch Tutor (page 41)
- Chord Study (page 42)
- Chord Progressions (page 43)

Lighting Keyboard (Light Guide Function)

When using the Song Lesson function, keys that you should press next will light in succession. The lighting keyboard can help you play the keyboard easily, even if you have limited music reading skills.

When you do not want the keyboard to light:

Hold down the [FUNCTION] button for longer than a second to call up "Light" (Function 037; page 62) and press the [-/NO] button to turn the Light Guide function off.

In addition to the Song Lesson, the keys you press or those specified by Song data light.

Compatible Song data includes not only the preset Songs but also Songs transferred from the computer to the instrument or played on the computer.

NOTE

- The keys light only when playing the MIDI Songs. They do not light when playing the Audio Songs.
- When playing the MIDI Song data on a computer, you can determine the channel which lights the keyboard. For details, refer to the "Light Part 1 Setting" (Function 038) or "Light Part 2 Setting" (Function 039) on page 62.

Keys to Success

In this lesson, you can practice individual phrases in the Song (with each Step) to effectively master the entire Song.

1 Prepare the Song Book.

Download the Song Book from the Yamaha website (page 8), or you can refer to the scores of some Songs at the end of this manual.


The amount of Steps and lesson parts (which are pre-programmed) will differ depending on the Song. For details, refer to the Song Book.

NOTE

- All preset Songs 002 to 202 other than 001 can be used with this mode, especially the "LEARN TO PLAY" category Songs.


2 Press the [SONG] button, then select a Song for your lesson.

Here, select Song "Für Elise (Basic)" from the "LEARN TO PLAY" category, then open the corresponding page of the Song Book.




3 Press the [KEYS TO SUCCESS] button to engage this lesson.

The keyboard icon, "Step01" and lesson part ("R" or "L" or "LR") appears on the display, indicating that you are to start this lesson from scratch. If you have already passed several Steps, the next Step number appears on the display.



4 Press the [START/STOP] button to start Lesson.

After the lead-in, playback of the current Step starts.



NOTE


- For your practice enjoyment, a special arrangement is applied to each Song. This is why playback tempo may be slower than original.

5 Practice the phrase in the current Step.

Referring to the notation in the Song Book, play the lighting keyboard.

6 Confirm the evaluation in the current Step.

When the current Step reaches the end, your performance will be evaluated and your score (from 0–100) is shown in the display.



★
Displayed when you've passed the Step.

A score between “0”–“59” indicates that you did not pass this Step and you should try the same Step again, which begins automatically. A score of “60”–“100” indicates that you passed this Step and you should try the next Step, which begins automatically.

NOTE 4

- If the specified part is both hands, you cannot pass the Step until you play both hands, even if you play one of the hands well. Only a message such as “Left Part is correct!” appears in the display.

7 Execute Step 02, 03, 04, and so on.

In the last Step of each Song, you will practice all the way through the Song. When you pass all Steps, the Keys to Success mode will automatically be turned off and playback stops.

NOTE 4


- Even during lesson, you can select another Step by using the [+YES]/[-NO] buttons.

8 To stop this Lesson, press the [KEYS TO SUCCESS] button.

Confirming the Passing Status


You can confirm the passing status of each Song simply by selecting a Song and each Step.

●When Step is selected



★ : Passed
No indication: Not yet passed

●When Song is selected



- ★ : There are one or more Steps not yet passed in addition to the last Step
- ★ ★ : Only last Step passed
- ★ ★ ★ : All Steps passed other than last Step
- ★ ★ ★ ★ : All Steps passed

Clearing the Passing Status

You can clear existing passing status entries for the entire Song or a specific Step of the Song.

●To clear the passing status entries of all Steps:

Select the desired Song then hold down the [KEYS TO SUCCESS] button for longer than three seconds, with the Keys to Success mode disabled. A “Cleared” message will appear on the display.

●To clear the passing status entry for a specific Step:

Select the desired Song, enable Keys to Success, select the desired Step, then hold down the [KEYS TO SUCCESS] button for longer than three seconds. A “Cleared” message will appear on the display.

NOTE 4


- This operation cannot be executed during playback.

Phrase Repeat

You can practice a difficult phrase repeatedly by selecting a specific number of the Phrase Marks pre-programmed in the Preset Songs (excepting the Song numbers 001 and 141–202). You can confirm the Phrase Mark location in the Song Book (page 8).

NOTE

- Phrase Mark is a pre-programmed marker in certain Song data, which indicates a specific location in the Song.
- Depending on the selected Song, some phrases include only one note.



Practicing two or more Phrases


By setting Phrase A (as the start point) and Phrase B (as the end point), you can practice two or more Phrases repeatedly. During Phrase Repeat playback, press the [A-B REPEAT] button to assign the current Phrase to Phrase A. When playback reaches to the desired Phrase, press the [A-B REPEAT] button again to assign Phrase B. "A-B Rep" appears on the display, and Repeat playback between Phrases A and B starts. To cancel this setting, press the [A-B REPEAT] button again.

NOTE

- You can set Phrases A and B also when playback is stopped by selecting the Phrase number via the [+YES] and [-NO] buttons.
- Specifying only Point A results in repeat playback between Point A and the end of the Song.

Practicing only a single Phrase

During Song playback, press the [PHRASE REPEAT] button at the phrase you want to practice. The corresponding Phrase number will appear in the display and, after a lead-in, repeat playback will start. Turn off the L or R part (page 34), then practice the phrase which is turned off repeatedly until you are satisfied.



Even during repeat playback, you can select any other phrase number via the [+YES] or [-NO] button, and you can return to normal playback by pressing the [PHRASE REPEAT] button again.

Listening, Timing and Waiting

●Lesson 1—Listening

In this Lesson, you need not play the keyboard. The model melody/chords of the part you selected will sound. Listen to it carefully and remember it well. When the Light Guide (Function 037; page 62) is on, the keys which are sounding will light.

●Lesson 2—Timing

In this Lesson, simply concentrate on playing the notes with the correct timing. Play the keyboard at the time the keys light. Even if you play wrong notes, the correct notes will sound.

●Lesson 3—Waiting

In this Lesson, try playing the lit notes on the lighting keyboard. These correct notes are also shown on the display. The Song pauses until you play the right note, and playback tempo will change to match the speed at which you are playing at.

NOTE

- If you want to keep a steady playback tempo maintained during Lesson 3: Waiting, set the Your Tempo parameter to OFF via the Function number 035 (page 62).
- Drum sounds are not played in the Waiting Lesson.

1 Press the [SONG] button then select a Song for your lesson.


NOTE

- The Song Lesson can be applied also to the Songs transferred from a computer (page 57), but cannot be applied to the User Songs.

NOTE

- Songs 163 to 202 are not compatible with the Listening, Timing and Waiting Lessons.

2 Press either or both the [R] and [L] buttons to select the part you want to practice.



NOTE

- If "No LPart" appears on the display by pressing the [L] button, the current Song does not contain a left-hand part.

- ## 3 Press the [1 LISTENING 2 TIMING 3 WAITING] button until the desired lesson is shown on the display and start it.
- Pressing this button repeatedly will change the Lesson number from 1: LISTENING → 2: TIMING → 3: WAITING → off → 1....



NOTE

- During playback, you can change the Lesson mode by pressing this button, and you can stop the Lesson at any time by pressing the [START/STOP] button.
- When you play the Lesson Song, the Main Voice automatically changes to "000" (One Touch Setting; page 24). The Dual or Split Voice cannot be used during the Lesson.
- When the melody Voice of the Song is changed, the key position shown in the display may be shifted (in octave units), depending on the selected Voice.

4 When Lesson playback reaches to the end, check your evaluation Grade on the display.

"2 Timing" and "3 Waiting" will evaluate your performance in four levels.

Excellent! ■■■■■■■■
 Very Good! ■■■■■■
 Good ■■■■
 OK ■■

After the evaluation display has appeared, the lesson will start again from the beginning.


5 Press the [START/STOP] button to stop the Lesson mode.

Turning the Guide Note off

When the “Guide” function is on, you can hear the Guide note while you are practicing with Lesson 3 (Waiting), and this is ideal when you are not sure of which keys to play next. The Guide note will sound slightly behind the timing to indicate the correct note, when you fail to play the correct note with the correct timing. When you play the correct note with the correct timing, the Guide note will not sound and the playback continues.

If you don't want to hear the Guide note, turn the function to off in the following steps.

- 1 Press the [FUNCTION] button several times until “Guide” (Function 036; page 62) appears.



- 2 Use the [+ / YES] and [- / NO] buttons to select the value “oFF.”

The default value of this function is “on” (Guide note will sound.)

NOTE

- The Guide setting cannot be changed during the Lesson mode.

The Guide function can be used for all preset Songs, except Songs in categories “FAVORITE WITH STYLE” (left-hand part) and “CHORD PROGRESSION,” and No.51.

Keys to Success with Listening, Timing or Waiting

You can combine the Keys to Success lesson (page 36) with the Listening, Timing or Waiting lesson (page 39).

- 1 **Enable the Keys to Success lesson.**
Refer to Steps 1–3 on page 36.
- 2 **Select the desired Step via the [+ / YES] / [- / NO] buttons, then press the [1 LISTENING 2 TIMING 3 WAITING] button repeatedly to select the desired lesson.**
The selected lesson playback starts under the Keys to Success mode. Practice the phrase of the current Step via the selected Lesson. As evaluation for each Step, just “Timing is correct!” or “Your playing is correct!” appears, and the passing status is not available.
- 3 **To return to only the Keys to Success mode, press the [1 LISTENING 2 TIMING 3 WAITING] button repeatedly until “StepXX” (XX: number) appears in the display.**
- 4 **To exit from the Lesson mode, press the [KEYS TO SUCCESS] button.**

Phrase Repeat with Listening, Timing or Waiting

With Phrase Repeat set to On, press the [1 LISTENING 2 TIMING 3 WAITING] button once, twice or three times to start and use Lesson playback with Phrase Repeat. Pressing the same button again several times to exit from the Lesson mode stops playback and allows use of just the Phrase Repeat mode.

NOTE

- In this status, the evaluation function is not available.

Learning How to Use “Touch” Control (Touch Tutor)

This learning feature lets you practice how hard or soft to play the keys for musical expression, referred to as “Touch” in this chapter, by playing back Song numbers 141 to 150 (in the “Touch Tutor” category). Playing back Songs from this category shows indications for the appropriate playing strength. Try playing according to the level displayed in the LCD as the Song progresses.

NOTE

- Be sure to set the Touch Response parameter (page 26) to a value other than “Fixed.” When set to “Fixed,” the Touch Tutor function is inactive.

1 Select a Song from Song numbers 141 to 150 in the “Touch Tutor” category by executing Step 1 in “Selecting and Playing Back a Song” on page 32.


To play with the same Voice that is used in a performance data, select Voice number “000” (OTS; page 24). After this operation, please make sure to go back to the Touch Tutor display by pressing the [SONG] button.



2 Press the [START/STOP] button to play back the selected Song.

3 When the following display appears, play the lighting keyboard at the strength level displayed in the LCD.

Play while the strength level is shown.




Strength targets are indicated by “■.” Your actual playing “Touch” is indicated by “▣.” Try playing so that the following indications appear (as target values) while you play.




The positions of “■” and “▣” are displayed with a gap when your touch is softer or harder than the target value.


Your touch is harder than the target value (Target value: medium, your touch: hard)



Your touch is same as the target value (Target value: medium, your touch: medium)



Your touch is softer than the target value (Target value: medium, your touch: soft)



When your touch is accurate, the instrument evaluates the accuracy of the touch (velocity) and indicates the following evaluation results on the display. If you continue to play the keys with your “touch” to match the target value on the display, your grade will gradually increase. If you continue to play the keys inaccurately, your grade will gradually decrease.

Great! > VeryGood > Good > OK

4 To stop the playback, press the [START/STOP] button.

To exit from the Touch Tutor mode, select a Song from any other category, except “Touch Tutor.”

NOTE

- This function cannot be used with Keys to Success.

Hearing and Experiencing the Sound of the Chords (Chord Study)

You can hear and experience the sound of the chords used in a typical performance by playing back Song numbers 151 to 162 (in the “Chord Study” category). Song numbers 151 to 157 are very simple Songs consisting of a single chord (C, Dm, Em, F, G, Am, Bm; respectively) played in various positions, letting you listen to and master the chords one by one. On the other hand, Song numbers 158 to 162 consist of several chords strung together in a pattern, for experiencing and understanding basic chord progressions. Hear and experience the sound of simple chords and progressions by playing back these Songs, and play the lighting keyboard.

Hear and experience a sound of a single chord

- 1 Select a Song from Song numbers 151 to 157 in the “CHORD STUDY” category by executing Step 1 in “Selecting and Playing Back a Song” on page 32.
- 2 Press the [START/STOP] button to play back the selected Song.
- 3 Play the lighting keyboard.



If you feel it difficult to play the notes, use the Waiting function (page 39) to have the Song automatically pause until you play the correct notes. Press the [1 LISTENING 2 TIMING 3 WAITING] button repeatedly until “WAITING” appears in the display. To exit from the Waiting function, press the same button again.

- 4 To stop the playback, press the [START/STOP] button.

Hear and experience basic chord progressions

- 1 Select a Song from Song numbers 158 to 162 by pressing the [+ / YES] / [- / NO] buttons.
- 2 Press the [START/STOP] button to play back the selected Song.
- 3 Play the lighting keyboard.
Listen to the basic chord progression, and play along with the Song repeatedly until you can smoothly perform and play along with the chord changes.

If you feel it difficult to play the notes, use the Waiting function (page 39) to have the Song automatically pause until you play the correct notes. Press the [1 LISTENING 2 TIMING 3 WAITING] button repeatedly until “WAITING” appears in the display. To exit from the Waiting function, press the same button again.


- 4 To stop the playback, press the [START/STOP] button.

Playing Chords along with Chord Progressions of a Song

Song numbers 163 to 202 in the “Chord Progression” category are constructed from typical chord progressions. You can listen to and get a feel for the chord progressions by playing back the Song and playing the lighting keyboard. The number of keys that are indicated for you to play progress in sequence—from a single root note, to two notes, then three and four—getting you to gradually and naturally memorize the chords. Also, you can change the key of the Song, allowing you to practice the progressions in all keys for full mastery of the chords.

1 Select a Song from Song numbers 163 to 202 in the “Chord Progression” category by executing Step 1 in “Selecting and Playing Back a Song” on page 32.

2 Press the [PHRASE REPEAT] button. After “CHORD PROGRESSION” scrolls across the display, the tonic pitch of the selected Song and the number of the keys to be pressed are shown.




NOTE

- The initial key setting is C major or A minor.

3 Press the [+ / YES] / [- / NO] buttons to select the number of the keys to be played.

Each time the [+ / YES] button is pressed, the number of the keys to press is increased from just one root note (1Note) to two notes (2Notes), three notes (3Notes) and four notes (All).




NOTE

- The number of the keys to press can also be set by using the number buttons [1]–[4].

4 Press the [START/STOP] button to play back the selected Song.

5 Play the lighting keyboard.




NOTE

- When you play the keyboard within the range of C5–B5, the notes will not sound.

6 Press the [PHRASE REPEAT] button again to turn the Chord Progression function off.

To change the key of a Song:

When Chord Progression is on, press one of the keys in the top octave (C5–B5; indicated to the right of “**ROOT**” on the panel, just above the keys) to change the tonic pitch of the Song.



For example, if you press the key D5 in the Song of C major, the key changes to D major.

NOTE

- The key of a Song cannot be changed during playback.

The number of the keys to be played

- **Only one root note (1Note)**
Press only the root note of the chord.
- **Two notes (2Notes)**
Press the 3rd interval of a chord along with the root note, and understand the difference between major chords and minor chords.
- **Three notes (3Notes)**
Press the 5th interval of a chord along with the root note and the 3rd.
- **Four notes (All)**
Press all the notes that make up the chord. Very often, chords are played with just three notes; however, another interval (such as a 7th) is sometimes added. Keep in mind that depending on the chord, there may be no 4th note.

Play the chords in combination with “Waiting” of the Lesson function

You can practice the playing the chords in combination with “Waiting” (page 39) of the Lesson function by simply pressing the [1 LISTENING 2 TIMING 3 WAITING] button once.

NOTE

- Even if you play notes in octaves outside of the notes of the lighting keyboard (excluding the range of C5–B5, which are used to change the key of a Song), as well as different inversions of the chords, the playback will progress.

Playing with Rhythm and Accompaniment (Styles)

This instrument includes an Auto Accompaniment feature that automatically plays appropriate “Styles” (rhythm + bass + chord accompaniment), controlled simply by playing only root note or all notes of a chord with your left hand.

You can select how you want to play the chords from two ways: “Smart Chord,” which lets you play chords by playing a key with only one finger, and “Multi Finger,” which lets you play them normally, with all the constituent notes.

Setting the Fingering Type

How you play the chords when playing Styles is called “Fingering Type,” which can be specified via Function number 017 (page 61). With this instrument, you can choose from two Fingering Types.

● Smart Chord (Default setting)

You can play the Style by playing only the root note of a chord.


● Multi Finger

This is a way to play the Style by playing all notes of a chord. However, major, minor, seventh, and minor sevenths can also be easily played by pressing one to three keys.

For information about chords, refer to “Chord Types for Style Playback” (page 47) or use the Chord Dictionary function (page 49).

1 Press the [FUNCTION] button several times until “FingType” (Function 017; page 61) appears.

“FingType” is shown in the display for a few seconds, followed by the current Fingering Type.



2 Use the number buttons [0]-[9] or [+ / YES] and [- / NO] buttons to select “SmartChd” or “Multi.”

3 Press the [STYLE] button to exit from the Fingering Type settings.

Setting the Smart Chord Key

If the Fingering Type is set to “SmartChd,” you need to set the keys of the Songs you want to play in advance. The specified key is called the Smart Chord Key.

1 Press the [FUNCTION] button until “S.ChdKey” (Function 018; page 61) appears.

The current Smart Chord Key appears.



2 Press the [+ / YES] and [- / NO] buttons to select the Smart Chord Key that matches the score.

For example, when you want to play the music score below, you need to set the Smart Chord Key to “FL2” (2 flats) (page 48).




3 Press the [STYLE] button to exit from the Smart Chord Key settings.


Playing Styles

- 1 Press the [STYLE] button, then use the number buttons [0]–[9], [+ / YES], [- / NO] to select the desired Style.


The Style List is provided on the front panel, or in the Style List (page 85).



- 2 Press the [ACMP ON/OFF] button to turn on the Auto Accompaniment.



With this operation, the area of the keyboard to the left of the Split Point (054: F#2) becomes the “Auto Accompaniment range” and is used only for specifying the chords.



You can change the Split Point via Function number 003 (page 60) by holding down the [ACMP ON/OFF] button for longer than a second.

NOTE

- The strength meter (page 17) does not respond to playing in the Auto Accompaniment range.

- 3 Press the [SYNC START] button to turn Synchro Start on.


This puts the style playback in “standby” and Style starts playing back when you play the keyboard.



Flashes when sync start is on.

- 4 Play a key in the Auto Accompaniment range to start playback.

If the Fingering Type is set to “SmartChd,” play only the root note of a chord with your left hand. If the Fingering Type is “Multi,” play all notes of a chord referring to page 47. Play a melody with the right hand and chords with the left hand.



- 5 Press the [START/STOP] button to stop playback.



You can add intro, ending and rhythm variations to Style playback by using “Sections.” For details, refer to page 46.

To play back the rhythm part only

If you press the [START/STOP] button (without pressing the [ACMP ON/OFF] button in step 2), only the rhythm part can be played back, and you can play a melody performance using the entire keyboard range.

NOTE

- Since the Pianist category Styles (197–205) have no rhythm parts, no sound will be produced if you start rhythm-only playback. When playing these Styles, make sure to carry out Steps 2–4 on this page.

Changing the Tempo

Refer to “Changing the Tempo” on page 32.

Adjusting the Style Volume

To adjust the volume balance between Style playback and keyboard, you can adjust the Style Volume. This can be set via Function number 016 (page 61).

Style Variations

Each Style consists of "Sections" that allow you to vary the arrangement of the accompaniment to match the song you are playing.



● INTRO

This is used for the beginning of the Song. When the Intro finishes, Style playback shifts to the Main section. The length of the Intro (in measures) differs depending on the selected Style.

● MAIN

This is used for playing the main part of the Song. Playback of the Main section repeats indefinitely until another Section's button is pressed. There are two variations (A and B), and the Style playback sound changes harmonically in response on the chords you play with your left hand.

● AUTO FILL

This is automatically added before changing to Main A or B.

● ENDING

This is used for the ending of the Song. When the Ending finishes, the Style playback stops automatically. The length of the Ending (in measures) differs depending on the selected Style.

1-3

Same as Steps 1-3 in page 45.

4 Press the [MAIN/AUTO FILL] button to select Main A or Main B.



5 Press the [INTRO/ENDING/rit.] button.




Now, you're ready to start Style playback from the Intro section.

6 Play a chord with your left hand to start playback of the Intro.

For example, play a C major chord.

For information on how to enter chords, refer to page 47.



7 After the Intro finishes, play the keyboard according to the progression of the Song you are playing.

Play chords with your left hand while playing melodies with your right hand, and press the [MAIN/AUTO FILL] button as necessary. The Section will change to Fill-in then Main A or B.



8 Press the [INTRO/ENDING/rit.] button.



The Section switches to the Ending. When the Ending is finished, Style playback stops automatically. You can have the Ending gradually slow down (ritardando) by pressing the [INTRO/ENDING/rit.] button again while the Ending is playing back.

Chord Types for Style Playback

For users who are new to chords, this chart conveniently shows how to play common chords in the Auto Accompaniment range of the keyboard. You can also use the Chord Dictionary function (page 49) to find out how to play the chords. Since there are many useful chords and many different ways to use them musically, refer to commercially available chord books for further details.

When the Fingering Type is “Multi,” play the notes that make up the chord in the Auto Accompaniment range. When the Fingering Type is “SmartChd,” play the root note “★” in the Auto Accompaniment range.

★ indicates the root note.

Major	Minor	Seventh	Minor Seventh	Major Seventh
C 	Cm 	C7 	Cm7 	CM7
D 	Dm 	D7 	Dm7 	DM7
E 	Em 	E7 	Em7 	EM7
F 	Fm 	F7 	Fm7 	FM7
G 	Gm 	G7 	Gm7 	GM7
A 	Am 	A7 	Am7 	AM7
B 	Bm 	B7 	Bm7 	BM7

- Inversions can be used as well as in “root” position—with the following exceptions:
m7, m7♯5, m7(11), 6, m6, sus4, aug, dim7, 7♯5, 6(9), sus2
- Inversions of the 7sus4 chords are not recognized if the notes are omitted.
- When playing a chord which cannot be recognized by this instrument, nothing is shown on the display. In such a case, only a specific part, such as the rhythm, will be played.

When “Multi” is selected, major, minor, seventh, and minor sevenths can also be easily played by pressing one to three keys.

Easy Chords for root “C”



To play a major chord
Press the root note (★) of the chord.



To play a minor chord
Press the root note together with the nearest black key to the left of it.



To play a seventh chord
Press the root note together with the nearest white key to the left of it.



To play a minor seventh chord
Press the root note together with the nearest white and black keys to the left of it (three keys altogether).

Chords Heard When Smart Chord is Selected

When the Fingering Type is “SmartChd,” if you set Smart Chord Key based on the composition of the score (page 44), play the root note in the Auto Accompaniment range. This lets you hear the respective chords below.

Key Signature on the music score	Smart Chord Key (Display)	Root Note													
		D♭			E♭			F♯			G♯			B♭	
		C	D	E	F	G	A	B							
	FL7	C dim	D♭ m	D dim7	E♭ 1+5	E	F dim	F♯ 7	G	G♯ m	A	B♭ m7 ♭5	B		
	FL6	C dim	D♭ 7	D	E♭ m	E	F m7 ♭5	F♯	G dim	G♯ m	A dim7	B♭ 1+5	B		
	FL5	C m7 ♭5	D♭	D dim	E♭ m	E dim7	F 1+5	F♯	G dim	G♯ 7	A	B♭ m	B		
	FL4	C 1+5	D♭	D dim	E♭ 7	E	F m	F♯	G m7 ♭5	G♯	A dim	B♭ m	B dim7		
	FL3	C m	D♭	D m7 ♭5	E♭	E dim	F m	F♯ dim7	G 1+5	G♯	A dim	B♭ 7	B		
	FL2	C m	D♭ dim7	D 1+5	E♭	E dim	F 7	F♯	G m	G♯	A m7 ♭5	B♭	B dim		
	FL1	C 7	D♭	D m	E♭	E m7 ♭5	F	F♯ dim	G m	G♯ dim7	A 1+5	B♭	B dim		
No key signature	SP0 (Default)	C	D♭ dim	D m	E♭ dim7	E 1+5	F	F♯ dim	G 7	G♯	A m	B♭	B m7 ♭5		
	SP1	C	D♭ dim	D 7	E♭	E m	F	F♯ m7 ♭5	G	G♯ dim	A m	B♭ dim7	B 1+5		
	SP2	C	D♭ m7 ♭5	D	E♭ dim	E m	F dim7	F♯ 1+5	G	G♯ dim	A 7	B♭	B m		
	SP3	C dim7	D♭ 1+5	D	E♭ dim	E 7	F	F♯ m	G	G♯ m7 ♭5	A	B♭ dim	B m		
	SP4	C	D♭ m	D	E♭ m7 ♭5	E	F dim	F♯ m	G dim7	G♯ 1+5	A	B♭ dim	B 7		
	SP5	C dim	D♭ m	D dim7	E♭ 1+5	E	F dim	F♯ 7	G	G♯ m	A	B♭ m7 ♭5	B		
	SP6	C dim	D♭ 7	D	E♭ m	E	F m7 ♭5	F♯	G dim	G♯ m	A dim7	B♭ 1+5	B		
	SP7	C m7 ♭5	D♭	D dim	E♭ m	E dim7	F 1+5	F♯	G dim	G♯ 7	A	B♭ m	B		

NOTE

• The “1+5” chord indication on the instrument’s display is the same as that of a major chord.

Looking Up Chords Using the Chord Dictionary

The Dictionary function is useful when you know the name of a certain chord and want to quickly learn how to play it.


1 Press and hold the [1 LISTENING 2 TIMING 3 WAITING] button for longer than a second to call up “Dict.”

“Dict.” will appear in the display.




This operation will divide the entire keyboard into the three ranges as illustrated below.

- The range to the right of “**ROOT**”:
Lets you specify the Chord Root, but produces no sound.
- The range between “**CHORD TYPE**” and “**ROOT**”:
Lets you specify the Chord Type, but produces no sound.
- The range to the left of “**CHORD TYPE**”:
Lets you play and confirm the Chord specified in the above two ranges.




2 As an example, learn how to play a GM7 (G major seventh) chord.

- 2-1. Press the “G” key in the section to the right of “**ROOT**” so that the “G” is shown as the root note.



- 2-2. Press the key labeled “M7” in the section between “**CHORD TYPE**” and “**ROOT**.”
The notes you should play for the specified chord are lit. They are also shown in the keyboard display.



Chord name (root and type)



Individual notes of chord (keyboard)

To call up possible inversions of the chord, press the [+ / YES] / [- / NO] buttons.

NOTE

- About major chords: Simple major chords are usually indicated only by the root note. For example, “C” refers to C major. However, when specifying major chords here, make sure to select “M” (major) after pressing the root note.
- These chords are not shown in the Chord Dictionary function: 6(9), M7(9), M7(#11), b5, M7b5, M7aug, m7(11), mM7(9), mM7b5, 7b5, sus2

3 Following the notation and keyboard diagram in the display, try playing a chord in the range to the left of “**CHORD TYPE**.”

When you’ve played the chord properly, a bell sound signals your success and the chord name in the display flashes.


4 To exit from the Chord Dictionary mode, press one of these buttons; [VOICE], [SONG] or [STYLE].

Using the Music Database

If you have difficulty finding and selecting the desired Style and Voice, use this feature. From the Music Database, just selecting the favorite music genre calls up the ideal settings.

1 Press the [MUSIC DATABASE] button.

Both the Auto Accompaniment and Synchro Start are automatically turned on.



2 Use the number buttons [0]–[9], [+ / YES], [- / NO] to select the desired Music Database.

This operation calls up the panel settings such as Voice and Style that are registered to the selected Music Database. The category name of Music Database List is provided on the front panel, or in the Music Database List (page 87).

3 Play the keyboard as described in Steps 4–5 on page 45.

Registering a Style File

Style data created on another instrument or computer can be registered (loaded) to Style numbers 206–215, and you can play them just the same as the internal preset Styles.

1 Transfer the Style file (***.STY) from a computer to this instrument by connecting this instrument and the computer.

For instructions, refer to “Computer-related Operations” on the website (page 8).

2 Press the [FUNCTION] button several times until “StyleReg” (Function 060; page 63) appears.



After about two seconds, a registerable Style file name will appear in the display.

3 If some Style files have already been transferred to the instrument, select the desired Style by using the [+ / YES] or [- / NO] button.

4 Press the [0] button.

As the Load destination, “***Load To?” (***: 206–215) appears on the display. If desired, select a different number using the [+ / YES] or [- / NO] button.

5 Press the [0] button.

A confirmation message will appear. To cancel the operation, press the [- / NO] button.

6 Press the [+ / YES] button to actually load the file.

After a while, a message indicating completion of the operation appears.

NOTICE

- The load operation cannot be cancelled during execution. Never turn off the power during the operation. Doing so may result in data loss.

7 Press the [STYLE] button, use the [+ / YES] or [- / NO] button to select a Style from 206–215, and then try playing it back.

For instructions on playing the Style, refer to page 45.

Recording Your Performance

You can record up to 5 of your performances as User Songs (User 1–5: Song numbers 203–207). The recorded User Songs can be played back on the instrument. The recorded User Song can be played back in the same way as the preset Songs.

Track Structure of a Song


You can record your performance to the following two tracks of a User Song individually or simultaneously.

●Track 1:

Your melody performance is recorded to this track.

●Track 2:

Your melody performance, or Style playback (Chord changes and Section changes), is recorded to this track.



●Recording Data Capacity:

A total of approximately 10,000 notes can be recorded to the five User Songs.

Quick Recording


The operation is convenient for recording a new Song without having to specify a track.

1 Make the desired settings such as Voice and Style settings.

If you want to record only the melody performance, turn ACMP off (page 45). If you want to record Style playback or Rhythm playback as well as melody performance, turn ACMP on (page 45).

2 Press the [REC] button to enter the Record Ready mode.

This operation selects the lowest-numbered unrecorded User Song (“User 1”–“User 5”) as the recording target, if a User Song has not been specified in advance or if Record Ready mode has been entered from the Style mode. If you want to select another Song, use the [+ / YES] and [- / NO] buttons.



To exit from the Record Ready mode, press the [REC] button again to stop flashing on the display.

NOTICE


- If all User Songs contain recorded data, “User 1 (Song Number 203)” will automatically be selected. In this case, since you will record over and erase any previous data in “User 1,” we recommend that you save your important data to a computer (see page 59).

NOTE

- ACMP cannot be turned on or off in this status while you can select another Style in this status by using the [STYLE] and Number buttons.

3 Play the keyboard to start recording.

If ACMP is turned on, you can independently record just the rhythm sound of Style playback by pressing the [START/STOP] button then changing the Section (page 46).



4 Press the [START/STOP] button to stop recording.

When using a Style, you can stop recording also by pressing the [INTRO/ENDING/rit.] button then waiting until playback ends.

NOTICE

- After Recording stops, a “Writing!” message is shown on the display for a while. Never attempt to turn the power off while this is shown in the display. Doing so can damage the internal memory and result in a loss of data.

5 To play back the recorded Song, press the [START/STOP] button.

Limitations while Recording

- You cannot record the Reverb Level, Metronome click, or the Transpose and Tuning settings.
- The following settings and buttons are not available, or if operated, the new settings cannot be recorded: ACMP ON/OFF, Split Point, Reverb Type, Chorus Type, Harmony/Arpeggio Type, [FUNCTION] button, [PORTABLE GRAND] button.
- When you play the keyboard while turning the DSP on and record your performance, make sure to record it to track 1.


Recording to a Specified Track

1 Make the desired settings, such as those of Voice or Style.


If you want to record the melody performance, turn ACMP off (page 45). If you want to record Style playback, turn ACMP on (page 45).

2 While holding down the [REC] button, press the desired Track button 1 or 2 to engage the Record mode.

If you want to record Style playback, make sure to select the Track 2. If you want to record melody performance, select either Track 1 or Track 2 as desired. The illustration below is the example when selecting Track 2.



The User Song appears on the display.



Flashing: Track is selected as a recording target.
Lit: Track contains data.
Unlit: Track contains no data or is muted.

You can record your performance while playing back or muting the recorded track. To play back or mute the track, press the [REC TRACK 1] or [REC TRACK 2] button. Each time the corresponding button is pressed, playback/mute is switched.

3 Press the [+ / YES], [- / NO] buttons to select the User Song you want to record.

4 Same as in Steps 3 to 5 (page 51) in "Quick Recording."

When playing back the recorded Song, pressing [REC TRACK 1] or [REC TRACK 2] button allows you to mute Track 1 or Track 2. Each time the button is pressed, playback/mute is switched.

Clearing a User Song

1 Press the [SONG] button then select the desired User Song by using the Number buttons.

2 Press and hold the [REC] button for longer than a second.

A confirmation message appears.




Hold for longer than a second.

To cancel the operation, press the [- / NO] button.

3 Press the [+ / YES] button.

A confirmation message appears again.



To cancel the operation, press the [- / NO] button.

4 Press the [+ / YES] button to clear the Song.


A "Writing!" message appears while the Song is being cleared.

Memorizing Your Favorite Panel Settings



This instrument has a Registration Memory feature that lets you memorize your favorite settings for easy recall whenever they're needed. Up to nine complete setups can be memorized and assigned to each number button 1–9. (Factory settings are recorded to 1-9.)

Recalling Panel Settings from the Registration Memory

- 1 Press the [REGIST MEMORY] button.
“LoadNo.?” appears on the display.



- 2 Press one of the [1]–[9] buttons to call up the panel settings you memorized.
The recalled Registration Memory number and the Voice Name in the Memory appear on the display.



The Registration Memory number can be changed by pressing one of the other [1]–[9] buttons. To exit from Registration Memory, press the [REGIST MEMORY] button.

Factory settings

Registration Memory Number	Voice Name in Memory
R01	S.Art Lite Nylon Guitar Harmonics
R02	S.Art Lite Steel Guitar Harmonics
R03	S.Art Lite Distortion Guitar
R04	S.Art Lite Slap Bass
R05	S.Art Lite Strings
R06	S.Art Lite Gospel Choir
R07	S.Art Lite Tenor Sax
R08	S.Art Lite Brass Section
R09	S.Art Lite Flute

Parameters that are memorized to Registration Memory

- **Style settings***
Style number, ACMP on/off, Style volume, Tempo, Main A/B, Fingering Type, Smart Chord Key
- **Voice settings**
Main Voice settings: Voice number and all settings of the related Functions
Dual Voice settings: Dual on/off and all settings of the related Functions
Split Voice settings: Split on/off and all settings of the related Functions
- **Effect settings:** Reverb Type, Reverb level, Chorus Type, DSP on/off, DSP Type, Sustain on/off
- **Harmony/Arpeggio settings:** Harmony/Arpeggio on/off and all settings of the related Functions
- **Other settings:** Transpose, Split Point, All settings for the Function “DUO”, Pedal Function

* When a Song is selected, the Style settings cannot be recorded or called up.

Memorizing Panel Settings to the Registration Memory

- 1 Make the desired settings such as those for Voice and Style.
- 2 Press and hold down the [REGIST MEMORY] button for longer than a second. "MemNo.?" appears on the display.




Hold for longer than a second.

Flashes after the [REGIST MEMORY] button is pressed and held for longer than a second.

- 3 Press one of the [1]–[9] buttons to memorize the current panel settings.

If you select a Registration Memory number that already contains data, an "Overwr?" message appears in the display. To overwrite, press the [+ / YES] button; to cancel, press [- / NO].




When memorizing is completed, "Mem OK" is displayed.

NOTICE

- If you select a Registration Memory number that already contains data, the previous data is deleted and overwritten by the new data.
- To restore all Registration Memories to the factory settings, execute Backup Clear operation (page 59).
- Do not turn off the power while memorizing settings to the Registration Memory, otherwise the data may be damaged or lost.

Deleting the Registration Memory


- 1 Hold down the [REGIST MEMORY] button for longer than a second. "MemNo.?" is shown in the display.



Hold for longer than a second.

Flashes after the [REGIST MEMORY] button is pressed and held for longer than a second.

- 2 Hold down the [1]–[9] buttons corresponding to the Registration Memory number you want to delete for longer than a second.



"ClrRegX?" ("X" represents the Registration Memory number) is shown in the display.

- 3 Press the [+ / YES] button to delete the Registration Memory.

Press the [- / NO] button to cancel deleting the Registration Memory. When deleted, the Registration Memory number on the display disappears.



Disabling Recall of Specific Items (Freeze)


Registration Memory lets you recall all the panel settings you made with a single button press. However, depending on the situation when you perform, there may be some settings you do not want to recall. When you want to switch the Voice settings but still maintain the Style settings, for example, you can "freeze" only the Style settings and have those Style settings remain, even when you select another Registration Memory number. Select the items you want to freeze via Function numbers 048, 049, and 050 (page 63).

Selecting an EQ Setting for your Favorite Sound

Six different master equalizer (EQ) settings let you create the optimum sound when listening through different reproduction systems—the instrument’s internal speakers, headphones, or an external speaker system.

- 1 Press the [FUNCTION] button several times until the “MasterEQ” (Function 025; page 61) item appears on the display.

“MasterEQ” is shown in the display for a few seconds, and the current Master EQ type appears.



- 2 Use the [+ / YES] or [- / NO] button to select the desired Master EQ type.

Master EQ types

1	Speaker	Optimum for listening via the instrument’s built-in speakers.
2	Headphone	Optimum for headphones, or for listening via external speakers.
3	Boost	Features more powerful sound.
4	Piano	Optimum for piano solo performance.
5	Bright	Lowers the mid range for a brighter sound.
6	Mild	Lowers the high range for a softer sound.

Connecting to Other Devices

CAUTION

- Before connecting, turn off the power of both this instrument and the external audio device. Also, before turning the power on or off, make sure to set all volume levels to minimum (0). Otherwise, damage to the devices, electrical shock, or even permanent hearing loss may occur.

Playing an External Audio Device with the Built-in Speakers

You can output the sound of an audio device, such as a smartphone, with the built-in speakers of this instrument by connecting it via a cable. This lets you play the keyboard along with playback of your music player.

NOTICE

- To avoid damage to the external audio device and this instrument, first turn on the power to the external device, and then to the instrument. When turning off the power, first turn off the power to the instrument, and then to the external device.


NOTE

- If you are using a computer or a smart device such as a smartphone or tablet, you can also connect it to the [USB TO HOST] terminal (see "Connecting to a Computer" on page 57).

1 Turn off the power for both the external audio device and this instrument.

2 Connect the audio device to the instrument's [AUX IN] jack.

Use the cable (no resistance) which has the stereo-mini plug at one side for connecting to this instrument and the plug matching the output jack of the external audio device at the other side.



3 Turn on the external audio device, then this instrument.

4 Play back the connected external audio device.

The sound of the audio device is output through the speakers of this instrument.

5 Adjust the volume balance between the external audio device and this instrument.

Adjust the audio playback volume on the audio device, then adjust the entire volume by rotating the [MASTER VOLUME] control of the instrument.

NOTE

- You can adjust the level of the input from the external audio device by calling up "AuxInVol" via Function number 043 (page 62) and using the [0]-[9], [+ / YES], [- / NO] buttons. If you increase the volume to more than 50, the audio device sound may be distorted.


6 Play the keyboard along with the sound of the audio device.

You can cancel or lower the volume of the melody part of audio playback. For details, refer to page 58.

7 After finishing the performance, stop playback of the audio device.

Connecting to a Computer

By connecting the [USB TO HOST] terminal of this instrument to a computer via a USB cable, you can perform the following convenient functions.



NOTE

- Use an AB type USB cable of less than 3 meters.
- USB 3.0 cables cannot be used.

Transferring MIDI Files, such as Song or Style Files

You can play Song files transferred from a computer to the instrument (page 19), or take User Songs (page 51) recorded on the instrument and transfer them to the computer for further editing and/or saving.

You need to turn the function settings “Storage Mode” (Function 059; page 63) on before making the file transfer. For details, refer to “Computer-related Operations” on the website (page 8).

●Files that can be transferred

- Song files (Extension: .MID)
Song files created on other instruments or computers can be transferred to this instrument. Note that user Songs created with this instrument cannot be transferred to a computer as a single file.
- Style files (Extension: .STY)
This instrument does not have a function for creating Style files, but you can import a style file created on another device. The maximum capacity per file is 50KB. Files that exceed the limit will not be recognized on this instrument.
- Backup files (Extension: .BUP)
* You can transfer the data of “Parameters backed up as needed” (excluding “Passing Status of Keys to Success”) and “Parameters backed up when the power is turned off” on page 59 to the computer and save the data as a single backup file.

NOTE

- Files up to a total of about 1.4 MB can be transferred to this instrument.
- If you transfer a Style file to this instrument, you need to register it before using it on the instrument. For details, refer to “Registering a Style File” (page 50).
- Files transferred to the instrument are listed in the instrument in the order of symbol, number and alphabet.

NOTE

- While Storage Mode is set to on, you cannot play the instrument, nor can you transmit/receive MIDI or Audio data. Set Storage Mode to on only when transferring files.

Transmitting/Receiving MIDI Data

The USB cable connection to a computer lets you listen to MIDI Songs played back on the computer or record your performance on the instrument as MIDI data to the computer.

Transmitting/Receiving Audio Data (USB Audio Interface)

The USB cable connection to a computer also lets you play the audio data on the computer with high sound quality on the instrument or record your performance on the instrument as an Audio data to the computer.

A dedicated driver must be installed for transmitting/receiving Audio data. For details, refer to “Computer-related Operations” on the website (page 8).

NOTE

- The volume can be adjusted both on the computer and by using the instrument’s [MASTER VOLUME] dial. You can also adjust the level of the audio input sound via [USB TO HOST] terminal by calling up “USBINVol” via Function number 044 (page 62) and using the [0]–[9], [+YES], [-INO] buttons.
- When outputting the audio playback from the instrument to the computer—for example, when recording the audio input sound from the [USB TO HOST] terminal with the performance played on the instrument—you cannot adjust the level of the audio data with the [MASTER VOLUME] dial.
- If you are using the instrument with a music production application, such as a DAW (Digital Audio Workstation), set “Loopback” (Function 045; page 62) to off. If this is instead set to on, a mix of the audio data and the sound of the instrument is sent to DAW, which may cause howling and unexpected loud sounds.

Connecting a Smart Device

By connecting a smart device such as a smartphone or tablet to the instrument, you can take advantage of various functions. For details on connections, refer to “Smart Device Connection Manual” on the website (page 8). For information about the compatible smart devices and apps, access the following page:
<https://www.yamaha.com/kbdapps/>


NOTE

- If you are using the instrument with a music production application such as a DAW (Digital Audio Workstation), set “Loop-back” (Function 045; page 62) to off. If it is set to on, a mix of the audio data and the sound of the instrument is sent to DAW, which may cause howling and unexpected loud sounds.
- Use an AB type USB cable of less than 3 meters.
- USB 3.0 cables cannot be used.
- You can adjust the level of the audio input sound via [USB TO HOST] terminal by function settings “USBINVol” (Function 044; page 62).

Lowering the volume of a melody part (Melody Suppressor function)

When you output the audio sound of an external audio device or a computer connected to the [AUX IN] jack or the [USB TO HOST] terminal through this instrument, you can cancel or lower the volume of the melody part of audio playback. You can use the function to practice the melody part along with the audio playback.

- 1 Play back audio on the connected external device.
- 2 Press the [FUNCTION] button several times to call up “MelodySP” (Function 046; page 62).



- 3 Press the [+ / YES] button to select “on.”


NOTE

- When the instrument is connected to the [USB TO HOST] terminal, and Audio Loop Back (Function 045; page 62) is set to OFF, the Melody Suppressor function cannot be used.

- 4 To cancel the Melody Suppressor function, press the [- / NO] button to select “off.”

When the melody or vocal sound may not be canceled (or lowered) as expected

- 1 Press the [FUNCTION] button several times to call up “SupprPan” (Function 047; page 62) while the Melody Suppressor function is turned on.



- 2 Adjust the pan position of the sound to be cancelled (lowered) by using the [+ / YES], [- / NO] buttons.

NOTE

- Depending on the particular music content, the melody or vocal sound may not be canceled as expected even if the Melody Suppressor is turned on.

Backup and Initialization

Backup Parameters

The following Backup parameters will be maintained even if the power is turned off.

Parameters backed up as needed

- User Songs (page 51)
- Style Number 206–215 (page 50)

Parameters backed up when the power is turned off

- Registration Memory (page 53)
- Passing Status of Keys to Success (page 37)
- Function Settings: (page 60)
 - Tuning, Split Point, Touch Response, Style Volume, Song Volume, Metronome Volume, Your Tempo, Demo Group, Demo Play Mode, Master EQ type, Sustain, Auto Power Off, Battery Type, Guide, Audio Loop Back, Fingering Type, [AUX IN] Audio Volume, [USB TO HOST] Audio Volume, Style Freeze, Transpose Freeze, Voice Freeze

In addition to the Backup parameters above, all the data (including Style data that have not been loaded) transferred from the connected computer will be maintained even if you turn off the power.

Backup parameters other than “Passing Status of Keys to Success” can be transferred and saved to a computer as a single Backup file (with the extension: .BUP). This backup file can be loaded to the instrument for future.

For details on using a computer with this instrument, refer to “Computer-related Operations” on the web-site (page 8).

NOTICE

- *Backup is executed automatically when the power is turned off. When the power is turned off in the following cases, backup is not executed.*
 - Disconnected AC adaptor
 - Power failure
 - Low or no battery power

Error during Backup Operation

When connecting to a computer with Storage Mode (Function 059; page 63) set to on, the memory space on the instrument may be insufficient for creating a backup file for transferring to the computer. In this situation, the error message “Not enough storage for backup” scrolls on the display. If you want to save a backup file to the computer, delete unnecessary Song files or Style files on this instrument to ensure sufficient memory space, and then set Storage Mode to off and back to on again. A backup file will be created.

If you do not save a backup file on the computer, there is no problem if an error message is displayed, and you can ignore the message.

NOTE


- *The size of a backup file varies depending on the amount of data stored on the instrument. The maximum capacity is about 620KB.*
- *Even if a backup file for transferring to a computer is not created, the backup data is retained in the instrument.*


Initialization

You can initialize your original data via the following two methods.


Backup Clear


This operation initializes the backup parameters and the Registration Memories.

While holding down the highest white key, press the [] (Standby/On) switch to turn the power on.



Flash Clear

This operation deletes all the Songs and Styles that have been transferred from a computer. Note that Style data registered to Style numbers 206–215 will be maintained. While simultaneously holding the highest white key and the three highest black keys, press the [] (Standby/On) switch to turn the power on.



NOTICE


- *Keep in mind that Backup Clear and Flash Clear also delete the data you have purchased. Be sure to save the important data to a computer.*

The Functions

The Functions settings provide access to a range of detailed instrument parameters such as Tuning, Split Point, Voices and Effects.

1 Press the [FUNCTION] button several times until the desired item appears.

Each time the [FUNCTION] button is pressed, the Function number increases one by one. To decrease the Function number by one, simultaneously hold down the [FUNCTION] button and press the [-/NO] button briefly. Simply pressing only the [+ /YES] or [-/NO] button does not change the Function number.




After a few seconds, the Function name may be replaced with the setting value depending on the selected Function.

NOTE

- When the Function settings display does not appear, press one of the [VOICE], [SONG] or [STYLE] buttons, and then press the [FUNCTION] button again.
- The Function number does not appear in the display during Song, Style or Metronome playback. The beat value appears instead.

2 Set the value by using the number buttons [0]–[9], [+ /YES], [- /NO].



3 To exit from the Function settings, press one of these buttons; [VOICE], [SONG] or [STYLE].

Function List

Function Number	Function name	Display	Range/Settings	Default Value	Descriptions
Overall					
001	Transpose	<i>TrAnSPoS</i>	-12-12	00	Determines the pitch of the instrument in semitone increments.
002	Tuning	<i>Tuning</i>	427.0Hz-453.0Hz	440.0Hz	Determines the fine tuning of the pitch of the entire instrument in approx. 0.2Hz increments.
003	Split Point	<i>SPlitPnt</i>	036-096 (C1-C6)	54 (F#2)	Determines the highest key for the Split Voice and sets the Split "point"—in other words, the key that separates the Split (lower) and Main (upper) Voices. This setting is applied to the Accompaniment Split Point setting (page 45).
004	Touch Response	<i>TouchRes</i>	1 (Soft), 2 (Medium), 3 (Hard), 4 (Fixed)	2 (Medium)	Refer to page 26.
Main Voice (page 24)					
005	Volume	<i>M. Volume</i>	000-127	*	Determines the volume of the keyboard performance when performing along with a Song or a Style.
006	Octave	<i>M. Octave</i>	-2 - +2	*	Determines the octave range for the Main Voice.
007	Chorus Depth	<i>M. Chorus</i>	000-127	*	Determines how much of the Main Voice's signal is sent to the Chorus effect.

Function Number	Function name	Display	Range/Settings	Default Value	Descriptions
Dual Voice (page 25)					
008	Dual Voice	<i>D.Voice</i>	001–622	*	Determines the Dual Voice.
009	Volume	<i>D.Volume</i>	000–127	*	Determines the volume of the Dual Voice.
010	Octave	<i>D.Octave</i>	-2 – +2	*	Determines the octave range for the Dual Voice.
011	Chorus Depth	<i>D.Chorus</i>	000–127	*	Determines how much of the Dual Voice's signal is sent to the Chorus effect.
Split Voice (page 25)					
012	Split Voice	<i>S.Voice</i>	001–622	*	Determines the Split Voice.
013	Volume	<i>S.Volume</i>	000–127	*	Determines the volume of the Split Voice.
014	Octave	<i>S.Octave</i>	-2 – +2	*	Determines the octave range for the Split Voice.
015	Chorus Depth	<i>S.Chorus</i>	000–127	*	Determines how much of the Split Voice's signal is sent to the Chorus effect.
Style (page 44)					
016	Style Volume	<i>StyleVol</i>	000–127	100	Determines the volume of the Style while a Style is selected (page 45).
017	Fingering Type	<i>FingType</i>	1 (SmartChd) 2 (Multi)	1 (SmartChd)	Determines the method of chord detection in the Accompaniment Section when playing with a Style.
018	Smart Chord Key	<i>S.ChdKey</i>	FL7 (7 Flats ♭) – SP0 (No Key Signature) – SP7 (7 Sharps #)	SP0 (No Key Signature)	Determines the Key Signature when the Fingering Type is set to "SmartChd." For example, if there are 2 sharps (#) in your music score, press the [+]/YES/[–]/NO buttons until "SP2" appears on the display.
Song (page 31)					
019	Song Volume	<i>SongVol</i>	000–127	100	Determines the volume of the Song when a Song is selected (page 32).
Effects					
020	Reverb Type	<i>Reverb</i>	1–4 (Hall 1–4) 5 (Cathedral) 6–8 (Room 1–3) 9–10 (Stage 1–2) 11–12 (Plate 1–2) 13 (Off)	**	Determines the Reverb type, including Off (page 91).
021	Reverb Level	<i>RevLevel</i>	000–127	064	Determines how much of the Voice's signal is sent to the Reverb effect.
022	Chorus Type	<i>Chorus</i>	1 (Chorus1) 2 (Chorus2) 3 (Chorus3) 4 (Flanger1) 5 (Flanger2) 6 (Off)	**	Determines the Chorus type, including Off (page 91).
023	DSP Type	<i>DSPType</i>	01–38	*	Determines the DSP Type (page 91).
024	Sustain	<i>Sustain</i>	ON/OFF	OFF	Determines whether the Sustain function is on or off (page 27).
025	Master EQ Type	<i>MasterEQ</i>	1 (Speaker) 2 (Headphone) 3 (Boost) 4 (Piano) 5 (Bright) 6 (Mild)	1 (Speaker)	Determines what type of equalization is applied to the speaker output or headphone output for optimum sound in different listening situations (page 55).
Harmony/Arpeggio (page 28)					
026	Harmony/Arpeggio Type	<i>Harm/Arp</i>	001–026 (Harmony) 027–176 (Arpeggio)	*	Determines the Harmony type or Arpeggio type.
027	Harmony Volume	<i>HarmVol</i>	000–127	*	Determines the volume of the Harmony effect.
028	Arpeggio Velocity	<i>ArpVelo</i>	1 (Original) 2 (Key)	**	Determines the Arpeggio velocity. If "Key" is selected, arpeggios will be played back at a volume matching the strength at which you play the keyboard. If "Original" is selected, arpeggios will be played back at their original volume regardless of your playing strength.
Pedal (pages 27, 29)					
029	Pedal Function	<i>PdlFunc</i>	1 (Sustain) 2 (Arp Hold) 3 (Sus+ArpH) 4 (Articulation)	1 (Sustain)	Sustain: Sustain will be produced while the pedal is held down. Arp Hold: Arpeggio playback will continue while the pedal is held down. Sus + ArpH: Sustain will be produced and Arpeggio playback will continue while the pedal is held down. Articulation: Articulation effect will be produced while the pedal is held down.

Function Number	Function name	Display	Range/Settings	Default Value	Descriptions
Metronome (page 24)					
030	Time Signature Numerator	<i>TimeSigN</i>	00-60	**	Determines the time signature of the Metronome.
031	Time Signature Denominator	<i>TimeSigD</i>	Half note, Quarter note, Eighth note, Sixteenth note	**	Determines the length of each Metronome beat.
032	Metronome Volume	<i>MetroVol</i>	000-127	100	Determines the volume of the Metronome.
Lesson (page 35)					
033	Lesson Track (R)	<i>R-Part</i>	01-16	01	Determines the track number for your right hand lesson. The setting is only effective for Songs in SMF format 0 transferred from a computer. Select a Song you want to use for the lessons, select the "R-Part," and then use the number buttons [0]-[9], [+ /YES] and [- /NO] to select the channel you want to play back as the specified right-hand part. We recommend that you select channel 1 for the right-hand part.
034	Lesson Track (L)	<i>L-Part</i>	01-16	02	Determines the track number for your left hand lesson. The setting is only effective for Songs in SMF format 0 transferred from a computer. Select a Song you want to use for the lessons, select the "L-Part," and then use the number buttons [0]-[9], [+ /YES] and [- /NO] to select the channel you want to play back as the specified left-hand part. We recommend that you select channel 2 for the left part.
035	Your Tempo	<i>YourTemp</i>	ON/OFF	ON	This parameter is for Lesson 3 "Waiting." When this is set to ON, playback tempo will change for matching the speed you are playing at. When this is set to OFF, playback tempo will be maintained regardless of the speed you are playing at.
036	Guide	<i>Guide</i>	ON/OFF	ON	Determines whether the Guide note sounds (ON) or not (OFF) during the "Waiting" lesson.
Light Guide (Lighting Keyboard)					
037	Light Guide	<i>Light</i>	ON/OFF	ON	Turns the Light Guide function (page 36) on/off.
038	Light Part 1 Setting	<i>LightPt1</i>	01-16	01	Determines the 1st part (channel) which lights the keyboard when playing a MIDI Song contained on the computer with this instrument.
039	Light Part 2 Setting	<i>LightPt2</i>	01-16	02	Determines the 2nd part (channel) which lights the keyboard when playing a MIDI Song contained on the computer with this instrument.
MIDI					
040	Local Control	<i>Local</i>	ON/OFF	ON	Determines whether the instrument's keyboard controls the internal tone generator (ON) or not (OFF). When you are recording your keyboard performance to the application software on the computer via MIDI, set this parameter to OFF.
041	External Clock	<i>ExtClock</i>	ON/OFF	OFF	Determines whether the instrument synchronizes to the internal clock (OFF) or an external clock (ON). When you are recording your keyboard performance to the application software on the computer via MIDI, set this parameter to ON.
042	Initial Send	<i>InitSend</i>	YES/NO	-	Allows you to send the data of the panel settings to a computer. Press [+ /YES] to send, or press [- /NO] to cancel.
Audio (pages 56, 57, 58)					
043	[AUX IN] Audio Volume	<i>RuxInVol</i>	000-127	050	Determines the volume of audio playback, input from the [AUX IN] jack (page 56).
044	[USB TO HOST] Audio Volume	<i>USBInVol</i>	000-127	100	Determines the volume of audio playback, input from the [USB TO HOST] terminal (page 57).
045	Audio Loop Back	<i>Loopback</i>	ON/OFF	ON	Determines whether Audio sound input from the [USB TO HOST] terminal is returned to the computer or not with the performance played on the instrument. If you want to output only the sound played on this instrument to the computer, set this parameter to OFF.
046	Melody Suppressor	<i>MelodySP</i>	ON/OFF	OFF	When you output the audio sound of an external audio device or a computer connected to the [AUX IN] jack or the [USB TO HOST] terminal through this instrument, select "ON" to cancel or lower the volume of the melody part of audio playback (page 58).
047	Suppressor Pan	<i>SupprPan</i>	L63-C-R63	C	Determines the position of the playback sound of the external audio device to be canceled or lowered (page 58).

Function Number	Function name	Display	Range/Settings	Default Value	Descriptions
Regist Freeze (page 54)					
048	Style Freeze	<i>StyleFrz</i>	ON/OFF	OFF	When you want to call up the Registration Memory without overwriting the current Style setting, select "ON."
049	Transpose Freeze	<i>TransFrz</i>	ON/OFF	OFF	When you want to call up the Registration Memory without overwriting the current Transpose setting, select "ON."
050	Voice Freeze	<i>VoiceFrz</i>	ON/OFF	OFF	When you want to call up the Registration Memory without overwriting the current Voice setting, select "ON."
Duo (page 30)					
051	Duo Mode	<i>DuoMode</i>	ON/OFF	OFF	Turns the Duo mode (page 30) on/off.
052	Duo L Voice	<i>DuoLVc</i>	001–622	*	Determines the voice in the left section.
053	Duo Split Point	<i>DuoPnt</i>	036–096 (C1–C6)	066 (F#3)	Sets the key that divides the keyboard range into the left section and right section.
054	Duo R Volume	<i>DuoRVol</i>	000–127	*	Determines the volume of the right section.
055	Duo L Volume	<i>DuoLVol</i>	000–127	*	Determines the volume of the left section.
056	Duo R Octave	<i>DuoROct</i>	-3 – +3	*	Determines the pitch of the right section in octave units.
057	Duo L Octave	<i>DuoLOct</i>	-3 – +3	*	Determines the pitch of the left section in octave units.
058	Duo Type	<i>DuoType</i>	1 (Balance) 2 (Separate)	2 (Separate)	This function is effective in Duo Mode (page 30). Balance: The performance sounds of the left section and the right section will sound from both the left and right speakers. Separate: The performance sound of the left section will sound from the left speaker, and the performance sound of the right section will sound from the right speaker.
Storage					
059	Storage Mode	<i>Storage</i>	ON/OFF	OFF	When transferring Song or Style files between the instrument and the computer, set the Storage Mode to ON. While the Storage Mode is ON, you cannot play the instrument.
Style File					
060	Style Register	<i>StyleReg</i>	001–nnn	–	Select and register a Style file from flash files that are loaded from computer (page 50).
Demo (page 33)					
061	Demo Group	<i>DemoGrp</i>	1 (Demo) 2 (Preset) 3 (User) 4 (Download)	1 (Demo)	Determines the repeat playback group.
062	Demo Play Mode	<i>PlayMode</i>	1 (Normal) 2 (Random)	1 (Normal)	Determines the repeat playback mode.
Auto Power Off (page 15)					
063	Auto Power Off Time	<i>AutoOff</i>	OFF, 5/10/15/30/60/120 (minutes)	30 minutes	Specifies the time that will elapse before the instrument's power is automatically turned off.
Battery (page 14)					
064	Battery Type	<i>Battery</i>	1 (Alkaline) 2 (Ni-MH)	1 (Alkaline)	Selects the type of batteries you have installed to this instrument. Alkaline: Alkaline battery/manganese battery Ni-MH: Rechargeable battery

* The appropriate value is automatically set for each Voice combination.

** The appropriate value is automatically set for each Song, Style or Arpeggio.

Troubleshooting

Problem	Possible Cause and Solution
When the instrument is turned on or off, a popping sound is temporarily produced.	This is normal and indicates that the instrument is receiving electrical power.
When using a mobile phone, noise is produced.	Using a mobile phone in close proximity to the instrument may produce interference. To prevent this, turn off the mobile phone or use it further away from the instrument.
Noise is heard from the instrument's speakers or headphones when using the instrument with an application on a smart device.	When you use the instrument along with the application on your smart device, we recommend that you set "Airplane Mode" to "ON" on your smart device in order to avoid noise caused by communication.
There is no sound even when the keyboard is played or when a Song or Style is being played back.	Check that nothing is connected to the [PHONES/OUTPUT] jack on the rear panel. When a set of headphones is plugged into this jack, no sound is output.
	Check the Local Control on/off setting. (See page 62 Function 040.) Make sure Local Control is set to ON.
The instrument does not respond when the instrument is operated.	Is Storage Mode set to ON? Make sure Storage Mode is set to OFF; refer to "Storage" on page 63 (Function 059).
Playing keys in the right hand area of the keyboard does not produce any sound.	When using the Dictionary function (page 49), the keys in the right hand area are used only for entering the chord root and type.
Not all of the voices seem to sound, or the sound seems to be cut off.	The instrument is polyphonic up to a maximum of 48 notes—including Dual voice, Split Voice, Style, Song, and Metronome. Notes exceeding this limit will not sound.
The harmony doesn't sound.	The method of sounding the Harmony effect (001–026) differs depending on the selected type. For Types 001–005, turn the Auto Accompaniment on and play it by pressing a chord in the auto accompaniment section of the keyboard, then play some keys in the right-hand side to produce the Harmony effect. You can play the types 006–026 without turning Auto Accompaniment on. However, it is necessary to play two notes simultaneously for Types 006–012.
The Style or Song does not play back when the [START/STOP] button is pressed.	Is External Clock set to ON? Make sure External Clock is set to OFF; refer to the function settings on page 62 (Function 041).
The ACMP ON indicator does not appear when the [ACMP ON/OFF] button is pressed.	<ul style="list-style-type: none"> Always press the [STYLE] button first when you are going to use any Style-related function. The ACMP ON indicator does not appear when the Duo mode is on.
The Style does not sound properly.	Make sure that the Style Volume (page 61 Function 016) is set to an appropriate level.
	Is the Split Point set to an appropriate key for the chords you are playing? Set the Split Point to an appropriate key (page 60 Function 003). Is the "ACMP" indicator showing in the display? If it is not showing, press the [ACMP ON/OFF] button so that it does show.
The Style does not sound as you play a chord.	<p>If the Fingering Type (Function 017; page 61) is set to Multi, the following conditions will occur.</p> <ul style="list-style-type: none"> The auto accompaniment will sometimes not change when related chords are played in sequence (e.g., some minor chords followed by the minor seventh). Two-note fingerings will produce a chord based on the previously played chord. Playing two same root keys in the adjacent octaves produces accompaniment based only on the root.
The footswitch (for sustain) seems to produce the opposite effect. For example, pressing the foot-switch cuts off the sound and releasing it sustains the sounds.	The polarity of the footswitch is reversed. Make sure that the footswitch plug is properly connected to the [SUSTAIN] jack before turning on the power.
The sound of the voice changes from note to note.	This is normal. The AWM tone generation method uses multiple recordings (samples) of an instrument across the range of the keyboard; thus, the actual sound of the voice may be slightly different from note to note.

Problem	Possible Cause and Solution
<ul style="list-style-type: none"> • The volume is too soft. • The sound quality is poor. • The rhythm stops unexpectedly or will not play. • The recorded data of the Song, etc. does not play correctly. • The LCD display suddenly goes dark, and all panel settings are reset. 	<p>The batteries are low or dead. Replace all six batteries with completely new ones, or use the included AC adaptor.</p>
<p>Power suddenly and unexpectedly turns off.</p>	<p>This is normal and the Auto Power Off function may have been activated (page 15). If you need to disable the Auto Power Off function, select "Off" in the Function settings (Function 063; page 63).</p>
<p>When the instrument is turned on, power is turned off suddenly and unexpectedly.</p>	<p>The protection circuit has been activated due to over current. This may occur when an AC adaptor other than the one specified is used, or an AC adaptor is damaged. Use the specified adaptor (page 94) only. If it should appear to be malfunctioning, discontinue use immediately and have it inspected by qualified Yamaha service personnel.</p>
<p>The application on your smart device doesn't recognize the instrument.</p>	<p>Is Storage Mode set to ON? Make sure that Storage Mode is set to OFF; refer to the function settings on page 63 (Function 059).</p>

Song Book Sample

This score is provided with the part of the Song Book (free downloadable scores).
The Song Book contains not only the scores for all internal songs (excepting for a Demo Song and some Songs due to copyright issues) but also music terms and important points for your practice. To obtain this Song Book, access the Yamaha website and download it from the product web page.

Yamaha Global Site <https://www.yamaha.com>

* The Song Book is provided in English, French, German and Spanish.
This example introduces part of the English Song Book.

Für Elise

L. v. Beethoven

Basic

Song No.075

Für Elise ~ With Step Map ~68

Für Elise is an all-time classical favorite.

The beautiful, well-known melody is repeated a number of times.


In each step you won't be practicing alone. You have a wonderful orchestra to back you up!

First, listen to the example a few times. It won't be long before you'll want to start playing it yourself!

Step 01	Warm-up Exercise - "The Semitone Mystery"	70
Step 02	Diligent Practice Time	71
Step 03	Warm-up Exercise - "Basic Accompaniment"	72
Step 04	Diligent Practice Time	72
Step 05	First Half Review	73
Step 06	Diligent Practice Time	73
Step 07	Warm-up Exercise - "The Jump Competition"	74
Step 08	"EEEEEE!"	74
Step 09	"Left! Right! Left! Right!"	75
Step 10	Second Half Review	75
Step 11	Play the Whole Song!	75


Before Playing...

◇ Sit Correctly



Sit near the middle of the keyboard.

◇ Finger Numbering



Reading the Score

◇ The Keyboard, Staff Lines, and Clef

◇ Notes and Rests

Whole note			Whole note rest	
Dotted half note			Dotted half note rest	
Half note			Half note rest	
Dotted quarter note			Dotted quarter note rest	
Quarter note			Quarter note rest	
Eighth note			Eighth note rest	
Sixteenth note			Sixteenth note rest	

◇ Accidentals

- # (Sharp) Raise a semitone
- b (Flat) Lower a semitone
- ♮ (Natural) Return to normal pitch

◇ Time Signatures and Counting Time

4/4 time 	2/2 time 	2/4 time
3/4 time 	6/8 time 	9/8 time

Song No.075

Basic

Für Elise

~ With Step Map ~

Play with both hands as if gently telling a story. It might help to sing or hum the melody as you play.
 Similar melody lines and rhythms are repeated in this song, so there aren't as many sections to practice as you might think. Enjoy learning each section as you build proficiency.

Step 05 From here... ▶

Andante
pp

Step 01
Step 02


Step 04

Step 03

Step 02


4/12

Step 05 ...to here Step 10 From here...



1. 2. Step 06 *mf*

Step 08 Step 09



19 *p* *pp*

Step 07



23 4

Step 10 ...to here



27 4

Song No.075  Für Elise **Basic**



Step 01



Warm-up Exercise - "The Semitone Mystery"

Let's start with a warm-up exercise using three fingers of the right hand. We'll start by ascending and descending the white and black keys. Check out the illustrations until you understand how the fingers are supposed to move, then get started!

You'll find it easier to play if you bend your fingers slightly.



Go back to the beginning and play it again.

Step 02




Diligent Practice Time

Right! Now that we're warmed up let's try playing along with the orchestra in 3/4 time.
 The melody will be built up little by little.
 Compare each line... notice that many of the shapes formed by the notes are very similar.



Short break



Almost done ♪


Song No.075  Für Elise **Basic**

Step 03



Warm-up Exercise - "Basic Accompaniment"

And now a warm-up exercise for the left hand.
It's important to spread your fingers widely from the start.
Don't play the black keys too strongly.



Step 04



Diligent Practice Time

Connect the notes smoothly, as if the left hand were passing them to the right hand. You'll be able to play smoothly if you move the left hand into position for the next phrase as soon as it finishes playing the first phrase.

Step 05**First Half Review**

You've reached the halfway step! Have you learned all the material provided in the preceding steps? Now let's go back and play through all the first-half exercises. If you find that you're having trouble playing any of the material, go back and review the steps using the Step Map as a guide.

Step 06**Diligent Practice Time**

OK, let's begin the second half!

You'll be able to play the melody nicely if you lift your fingers from the keyboard between the slurs.

It might be easier to grasp the key release timing if you sing along with the melody.

Don't panic and play too strongly where the left hand has to play short notes.

Always have left-hand finger 5 ready to play the next note!

Song No.075  Für Elise **Basic**

Step 07




Jump to the next E!

Warm-up Exercise - "The Jump Competition"

The first note has a staccato dot.

Spread your fingers wide and jump quickly to the next note!



Step 08



"EEEEEE!"

The only note in this step is E!

Make the connection between the left and right hands as smooth as possible.

Step 09**“Left! Right! Left! Right!”**

Play “D[♯] E” repeatedly, alternating the left and right hands.

Have the next hand ready in position to play D[♯] so you won't have to rush.

Step 10**Second Half Review**

Try playing all the way through the second half.

As we did after the first half, if there are places you can't play with confidence go back and review the steps.

Step 11**Play the Whole Song!**

This is the finishing step!

Don't be afraid of making mistakes. Just concentrate on playing the entire song from start to finish.

Practice this with the lessons learned in each step in mind, and gradually you'll master the whole song.

Voice List

Maximum Polyphony

The instrument has 48-note maximum polyphony. This means that it can play a maximum of up to 48 notes at once, regardless of what functions are used. Auto accompaniment uses a number of the available notes, so when auto accompaniment is used the total number of available notes for playing on the keyboard is correspondingly reduced. The same applies to the Split Voice and Song functions. If the maximum polyphony is exceeded, earlier played notes will be cut off and the most recent notes have priority (last note priority).

NOTE

- The Voice List includes MIDI program change numbers for each voice. Use these program change numbers when playing the instrument via MIDI from an external device.
- Program change numbers are often specified as numbers "0-127." For these cases, it is necessary to subtract 1 from the intended program change number to select the appropriate sound, because this list uses a "1-128" numbering system. For example, to select program change number 38 in the list below, transmit program change number 37.
- Some voices may sound continuously or have a long decay after the notes have been released while the sustain pedal (footswitch) is held.

Panel Voice List

Voice No.	Bank Select		MIDI Program Change# (1-128)	Voice Name
	MSB (0-127)	LSB (0-127)		
PIANO				
1	0	115	1	Live! Concert Grand Piano
2	0	112	1	Grand Piano
3	0	112	2	Bright Piano
4	0	112	7	Harpischord
5	0	112	4	Honky Tonk Piano
6	0	112	3	MIDI Grand Piano
7	0	113	3	CP80
E.PIANO				
8	0	118	5	Cool! SuitcaseEP
9	0	118	6	JazzChorusEP
10	0	120	5	PhaseEP
11	0	119	5	Cool! TremoloEP
12	0	121	5	Cool! ElectricPiano
13	0	117	5	StageEP
14	0	114	5	Cool! Galaxy Electric Piano
15	0	113	6	Hyper Tines
16	0	112	5	Funky Electric Piano
17	0	112	6	DX Modern Electric Piano
18	0	114	6	Venus Electric Piano
19	0	112	8	Clavi
20	0	113	8	WahClavi
ORGAN				
21	0	118	19	Cool! Organ
22	0	117	19	Cool! Rotor Organ
23	0	112	17	Jazz Organ 1
24	104	49	17	Jazz Organ 1+RotaryFast
25	0	113	17	Jazz Organ 2
26	104	50	17	Jazz Organ 2+RotaryFast
27	0	112	19	Rock Organ
28	0	120	19	Octave Shift Organ
29	0	114	19	Purple Organ
30	0	112	18	Click Organ
31	0	116	17	Bright Organ
32	0	127	19	Theater Organ
33	0	121	20	16'+2' Organ
34	0	120	20	16'+4' Organ
35	0	113	20	Chapel Organ
36	0	112	20	Pipe Organ
37	0	112	21	Reed Organ
ACCORDION				
38	0	112	22	Musette Accordion
39	0	113	22	Traditional Accordion
40	0	113	24	Bandoneon
41	0	113	23	Modern Harp
42	0	114	23	Blues Harp
43	0	115	23	Harmonica

Voice No.	Bank Select		MIDI Program Change# (1-128)	Voice Name
	MSB (0-127)	LSB (0-127)		
GUITAR				
44	8	96	1	S.Art Lite Nylon Guitar Harmonics ***
45	8	96	2	S.Art Lite Steel Guitar Harmonics ***
46	8	97	1	S.Art Lite Nylon Guitar Slide ***
47	8	97	2	S.Art Lite Steel Guitar Slide ***
48	8	96	6	S.Art Lite Distortion Guitar ***
49	0	116	25	Dynamic Nylon Guitar
50	0	118	30	Dynamic Overdriven
51	0	121	31	Dynamic Distortion Guitar
52	0	122	25	Nylon Guitar
53	0	112	25	Classical Guitar
54	104	25	26	Steel Guitar
55	0	112	26	Folk Guitar
56	0	112	27	Jazz Guitar
57	0	117	28	60s Clean Guitar
58	0	113	26	12Strings Guitar
59	0	112	28	Clean Guitar
60	0	127	28	Wah Guitar
61	0	113	27	Octave Guitar
62	0	112	29	Muted Guitar
63	0	112	30	Overdriven Guitar
64	0	112	31	Distortion Guitar
65	0	127	31	Wah Distortion Guitar
BASS				
66	8	96	18	S.Art Lite Slap Bass ***
67	0	116	34	Dynamic Electric Bass
68	0	112	34	Finger Bass
69	0	112	33	Acoustic Bass
70	0	112	35	Pick Bass
71	0	112	36	Fretless Bass
72	0	112	37	Slap Bass
73	0	121	40	Funk Bass
74	0	112	39	Synth Bass
75	0	113	39	Hi-Q Bass
76	0	113	40	Dance Bass
STRINGS				
77	8	96	50	S.Art Lite Strings ***
78	0	117	50	Live! Strings
79	104	23	49	Studio Strings
80	0	112	49	Strings
81	0	112	50	Chamber Strings
82	0	115	50	Marcato Strings
83	0	113	50	Slow Strings
84	0	112	45	Tremolo Strings
85	0	112	51	Synth Strings

Voice No.	Bank Select		MIDI Program Change# (1-128)	Voice Name
	MSB (0-127)	LSB (0-127)		
86	0	112	46	Pizzicato Strings
87	0	116	46	Orchestra Pizzicato Strings
88	0	113	41	Sweet! Violin
89	0	112	41	Violin
90	0	112	43	Cello
91	0	112	44	Contrabass
92	0	112	47	Harp
93	0	112	56	Orchestra Hit
CHOIR				
94	8	96	55	S.Art Lite Gospel Choir ***
95	0	112	53	Choir
96	104	12	54	Gospel Hm
97	104	13	54	Gospel Wow
98	0	113	53	Vocal Ensemble
99	0	112	55	Air Choir
100	0	112	54	Vox Humana
SAXOPHONE				
101	8	96	83	S.Art Lite Tenor Sax ***
102	0	122	67	Sax Section
103	0	117	67	Sweet! Tenor Sax
104	0	112	67	Tenor Sax
105	0	112	66	Alto Sax
106	0	112	65	Soprano Sax
107	0	112	68	Baritone Sax
108	0	114	67	Breathy Tenor Sax
109	0	116	66	Small Sax Section
110	0	112	72	Clarinet
111	0	112	69	Oboe
112	0	112	70	English Horn
113	0	112	71	Bassoon
TRUMPET				
114	0	112	57	Trumpet
115	0	127	57	Distortion Trumpet
116	0	112	58	Trombone
117	0	113	58	Trombone Section
118	0	112	60	Muted Trumpet
119	0	112	61	French Horn
120	0	112	59	Tuba
BRASS				
121	8	96	57	S.Art Lite Brass Section ***
122	0	117	63	Live! Brass
123	0	112	62	Brass Section
124	0	113	62	Big Band Brass
125	0	116	62	Octave Brass
126	0	113	63	80s Brass
127	0	119	62	Mellow Horns
128	0	115	63	Funky Brass
129	0	114	63	Techno Brass
130	0	112	63	Synth Brass
FLUTE				
131	8	96	74	S.Art Lite Flute ***
132	0	114	74	Sweet! Flute
133	0	115	74	Sweet! Classical Flute
134	0	112	74	Flute
135	0	112	73	Piccolo
136	0	112	76	Pan Flute
137	0	112	75	Recorder
138	0	112	80	Ocarina
SYNTH				
139	104	20	91	Gemini
140	104	21	91	Hands Up!
141	0	112	81	Square Lead

Voice No.	Bank Select		MIDI Program Change# (1-128)	Voice Name
	MSB (0-127)	LSB (0-127)		
142	0	112	82	Sawtooth Lead
143	0	108	82	RS Tech Saw
144	0	112	88	Under Heim
145	0	112	85	Portatone
146	0	115	82	Analogon 1
147	0	119	82	Fargo 1
148	104	53	82	Analogon 2
149	104	54	82	Fargo 2
150	0	112	86	Voice Lead
151	0	121	82	Funky Lead
152	0	118	89	Sweet Heaven
153	0	121	89	Dream Heaven
154	0	113	89	Symbion
155	0	112	99	Stardust
156	0	112	101	Brightness
157	0	112	92	Xenon Pad
158	0	112	95	Equinox
159	0	112	89	Fantasia
160	0	113	90	Dark Moon
161	0	113	101	Bell Pad
162	0	126	90	RS Analog Pad
163	0	116	91	RS Short Resonance
PERCUSSION				
164	0	112	12	Vibraphone
165	0	113	12	Jazz Vibes
166	0	112	13	Marimba
167	0	112	14	Xylophone
168	0	112	115	Steel Drums
169	0	112	9	Celesta
170	0	112	11	Music Box
171	0	112	15	Tubular Bells
172	0	112	48	Timpani
WORLD				
173	0	112	106	Banjo
174	0	0	111	Fiddle
175	0	0	110	Bagpipe
176	0	0	16	Dulcimer 1
177	0	35	16	Dulcimer 2
178	0	96	16	Cimbalom
179	0	121	16	Santur
180	0	97	108	Kanoon
181	0	98	106	Oud
182	0	96	106	Rabab
183	0	0	109	Kalimba
184	0	113	21	Harmonium 1 (Single Reed)
185	0	114	21	Harmonium 2 (Double Reed)
186	0	115	21	Harmonium 3 (Triple Reed)
187	0	114	105	Tanpura
188	0	96	112	Pungi
189	0	117	74	Bansuri
190	0	0	105	Sitar 1
191	0	32	105	Detuned Sitar
192	0	35	105	Sitar 2
193	0	0	112	Shehnai
194	0	97	106	Gopichant
195	0	116	117	Tabla
196	0	115	111	Er Hu
197	0	118	74	Di Zi
198	0	116	106	Pi Pa
199	0	113	108	Gu Zheng
200	0	40	47	Yang Qin
201	0	120	111	Morin Khuur

Voice No.	Bank Select		MIDI Program Change# (1-128)	Voice Name
	MSB (0-127)	LSB (0-127)		
202	0	124	74	Suling
203	0	0	107	Shamisen
204	0	0	108	Koto
205	0	96	108	Taisho-kin
DUAL*				
206	-	-	-	Octave Piano
207	-	-	-	Piano & Strings
208	-	-	-	Piano Pad
209	-	-	-	Octave Harpsichord
210	-	-	-	Tiny Electric Piano
211	-	-	-	Electric Piano Pad
212	-	-	-	Full Organ
213	-	-	-	Octave Jazz Guitar
214	-	-	-	Octave Strings
215	-	-	-	Orchestra Section
216	-	-	-	Octave Pizzicato Strings
217	-	-	-	Strings Session
218	-	-	-	Brass Tutti
219	-	-	-	Orchestra Tutti
220	-	-	-	Octave French Horns
221	-	-	-	Octave Harp
222	-	-	-	Orchestra Hit & Timpani
223	-	-	-	Octave Choir
224	-	-	-	Jazz Brass Section
225	-	-	-	Jazz Section
226	-	-	-	Ballroom Sax Ensemble
227	-	-	-	Ballroom Brass
228	-	-	-	Flute & Clarinet
229	-	-	-	Trumpet & Trombone
230	-	-	-	Fat Synth Brass
231	-	-	-	Octave Lead
232	-	-	-	Super 5th Lead
SOUND EFFECTS				
233	0	0	121	Fret Noise
234	0	0	122	Breath Noise
235	0	0	123	Seashore
236	0	0	124	Bird Tweet
237	0	0	125	Telephone Ring
238	0	0	126	Helicopter
239	0	0	127	Applause
240	0	113	116	Hand Clap
241	0	0	128	Gunshot
DRUM KITS				
242	127	0	88	Power Kit
243	127	0	1	Standard Kit 1
244	127	0	2	Standard Kit 2
245	127	0	9	Room Kit
246	127	0	17	Rock Kit
247	127	0	25	Electronic Kit
248	127	0	26	Analog Kit
249	127	0	113	Dance Kit
250	127	0	33	Jazz Kit
251	127	0	41	Brush Kit
252	127	0	49	Symphony Kit
253	126	0	128	StdKit 1 + Chinese Perc.
254	126	0	40	Indian Kit 1
255	126	0	115	Indian Kit 2
256	126	0	55	StdKit 1 + Indonesian Perc. 1
257	126	0	56	StdKit 1 + Indonesian Perc. 2
258	126	0	57	StdKit 1 + Indonesian Perc. 3
259	126	0	37	Arabic Kit
260	126	0	41	Cuban Kit

Voice No.	Bank Select		MIDI Program Change# (1-128)	Voice Name
	MSB (0-127)	LSB (0-127)		
261	126	0	1	SFX Kit 1
262	126	0	2	SFX Kit 2
263	126	0	113	Sound Effect Kit
ARPEGGIO**				
264	-	-	-	Concerto
265	-	-	-	Latin Rock
266	-	-	-	Brass Section
267	-	-	-	Piano Ballad
268	-	-	-	Synth Sequence
269	-	-	-	Guitarist
270	-	-	-	Pickin'
271	-	-	-	Spanish
272	-	-	-	Funky Clavi
273	-	-	-	Harpeggio
274	-	-	-	Finger Bass Left
275	-	-	-	Combo Jazz Left
276	-	-	-	Pau's Bass Left
277	-	-	-	Trance Bass Left
278	-	-	-	Acid Bass Left
279	-	-	-	Piano Ballad Left
280	-	-	-	Salsa Piano Left
281	-	-	-	Piano Arpeggio Left
282	-	-	-	Guitar Arpeggio Left
283	-	-	-	Strum Left

* When you select a Voice of the DUAL category, two voices sound at the same time.

** Selecting a Voice number between 264 and 283 will turn on Arpeggio.

*** S.Art Lite voice (page 27)

XGlite Voice List

Voice No.	Bank Select		MIDI Program Change# (1-128)	Voice Name
	MSB (0-127)	LSB (0-127)		
XG PIANO				
284	0	0	1	Grand Piano
285	0	1	1	Grand Piano KSP
286	0	40	1	Piano Strings
287	0	41	1	Dream
288	0	0	2	Bright Piano
289	0	1	2	Bright Piano KSP
290	0	0	3	Electric Grand Piano
291	0	1	3	Electric Grand Piano KSP
292	0	32	3	Detuned CP80
293	0	0	4	Honky Tonk Piano
294	0	1	4	Honky Tonk Piano KSP
295	0	0	5	Electric Piano 1
296	0	1	5	Electric Piano 1 KSP
297	0	32	5	Chorus Electric Piano 1
298	0	0	6	Electric Piano 2
299	0	1	6	Electric Piano 2 KSP
300	0	32	6	Chorus Electric Piano 2
301	0	41	6	DX + Analog Electric Piano
302	0	0	7	Harpsichord 1
303	0	1	7	Harpsichord KSP
304	0	35	7	Harpsichord 2
305	0	0	8	Clavi
306	0	1	8	Clavi KSP
XG CHROMATIC				
307	0	0	9	Celesta
308	0	0	10	Glockenspiel
309	0	0	11	Music Box 1
310	0	64	11	Music Box 2
311	0	0	12	Vibraphone
312	0	1	12	Vibraphone KSP
313	0	0	13	Marimba
314	0	1	13	Marimba KSP
315	0	64	13	Sine Marimba
316	0	97	13	Balimba
317	0	98	13	Log Drums
318	0	0	14	Xylophone
319	0	0	15	Tubular Bells
320	0	96	15	Church Bells
321	0	97	15	Carillon
XG ORGAN				
322	0	0	17	Drawbar Organ 1
323	0	32	17	Detuned Drawbar Organ
324	0	33	17	60s Drawbar Organ 1
325	0	34	17	60s Drawbar Organ 2
326	0	35	17	70s Drawbar Organ 1
327	0	37	17	60s Drawbar Organ 3
328	0	40	17	16+2'2/3 Organ
329	0	64	17	Organ Bass
330	0	65	17	70s Drawbar Organ 2
331	0	66	17	Cheezy Organ
332	0	67	17	Drawbar Organ 2
333	0	0	18	Percussive Organ 1
334	0	24	18	70s Percussive Organ
335	0	32	18	Detuned Percussive Organ
336	0	33	18	Light Organ
337	0	37	18	Percussive Organ 2
338	0	0	19	Rock Organ
339	0	64	19	Rotary Organ
340	0	65	19	Slow Rotary Organ
341	0	66	19	Fast Rotary Organ

Voice No.	Bank Select		MIDI Program Change# (1-128)	Voice Name
	MSB (0-127)	LSB (0-127)		
342	0	0	20	Church Organ 1
343	0	32	20	Church Organ 3
344	0	35	20	Church Organ 2
345	0	40	20	Notre Dame
346	0	64	20	Organ Flute
347	0	65	20	Tremolo Organ Flute
348	0	0	21	Reed Organ
349	0	40	21	Puff Organ
350	0	0	22	Accordion
351	0	0	23	Harmonica 1
352	0	32	23	Harmonica 2
353	0	0	24	Tango Accordion 1
354	0	64	24	Tango Accordion 2
XG GUITAR				
355	0	0	25	Nylon Guitar 1
356	0	25	25	Nylon Guitar 3
357	0	43	25	Velocity Guitar Harmonics
358	0	96	25	Ukulele
359	0	0	26	Steel Guitar
360	0	35	26	12-string Guitar
361	0	40	26	Nylon & Steel Guitar
362	0	41	26	Steel Guitar with Body Sound
363	0	96	26	Mandolin
364	0	0	27	Jazz Guitar
365	0	32	27	Jazz Amp
366	0	0	28	Clean Guitar
367	0	32	28	Chorus Guitar
368	0	0	29	Muted Guitar
369	0	40	29	Funk Guitar
370	0	41	29	Muted Steel Guitar
371	0	45	29	Jazz Man
372	0	0	30	Overdriven Guitar
373	0	43	30	Guitar Pinch
374	0	0	31	Distortion Guitar
375	0	40	31	Feedback Guitar 1
376	0	41	31	Feedback Guitar 2
377	0	0	32	Guitar Harmonics 1
378	0	65	32	Guitar Feedback
379	0	66	32	Guitar Harmonics 2
XG BASS				
380	0	0	33	Acoustic Bass
381	0	40	33	Jazz Rhythm
382	0	45	33	Velocity Crossfade Upright Bass
383	0	0	34	Finger Bass 1
384	0	18	34	Finger Bass Dark
385	0	40	34	Bass & Distorted Electric Guitar
386	0	43	34	Finger Slap Bass
387	0	45	34	Finger Bass 2
388	0	65	34	Modulated Bass
389	0	0	35	Pick Bass
390	0	28	35	Muted Pick Bass
391	0	0	36	Fretless Bass 1
392	0	32	36	Fretless Bass 2
393	0	33	36	Fretless Bass 3
394	0	34	36	Fretless Bass 4
395	0	0	37	Slap Bass 1
396	0	32	37	Punch Thumb Bass
397	0	0	38	Slap Bass 2
398	0	43	38	Velocity Switch Slap
399	0	0	39	Synth Bass 1
400	0	40	39	Techno Synth Bass

Voice List

Voice No.	Bank Select		MIDI Program Change# (1-128)	Voice Name
	MSB (0-127)	LSB (0-127)		
401	0	0	40	Synth Bass 2
402	0	6	40	Mellow Synth Bass
403	0	12	40	Sequenced Bass
404	0	18	40	Click Synth Bass
405	0	19	40	Synth Bass 2 Dark
406	0	40	40	Modular Synth Bass
407	0	41	40	DX Bass
XG STRINGS				
408	0	0	41	Violin
409	0	8	41	Slow Violin
410	0	0	42	Viola
411	0	0	43	Cello
412	0	0	44	Contrabass
413	0	0	45	Tremolo Strings
414	0	8	45	Slow Tremolo Strings
415	0	40	45	Suspense Strings
416	0	0	46	Pizzicato Strings
417	0	0	47	Orchestral Harp
418	0	0	48	Timpani
XG ENSEMBLE				
419	0	0	49	Strings 1
420	0	3	49	Stereo Strings
421	0	8	49	Slow Strings
422	0	35	49	60s Strings
423	0	40	49	Orchestra 1
424	0	41	49	Orchestra 2
425	0	42	49	Tremolo Orchestra
426	0	45	49	Velocity Strings
427	0	0	50	Strings 2
428	0	3	50	Stereo Slow Strings
429	0	8	50	Legato Strings
430	0	40	50	Warm Strings
431	0	41	50	Kingdom
432	0	0	51	Synth Strings 1
433	0	64	51	Synth Strings 4
434	0	0	52	Synth Strings 2
435	0	0	53	Choir Aahs
436	0	3	53	Stereo Choir
437	0	32	53	Mellow Choir
438	0	40	53	Choir Strings
439	0	0	54	Voice Oohs
440	0	0	55	Synth Voice 1
441	0	40	55	Synth Voice 2
442	0	41	55	Choral
443	0	64	55	Analog Voice
444	0	0	56	Orchestra Hit 1
445	0	35	56	Orchestra Hit 2
446	0	64	56	Impact
XG BRASS				
447	0	0	57	Trumpet
448	0	32	57	Warm Trumpet
449	0	0	58	Trombone 1
450	0	18	58	Trombone 2
451	0	0	59	Tuba
452	0	0	60	Muted Trumpet
453	0	0	61	French Horn 1
454	0	6	61	French Horn Solo
455	0	32	61	French Horn 2
456	0	37	61	Horn Orchestra
457	0	0	62	Brass Section
458	0	35	62	Trumpet & Trombone Section
459	0	0	63	Synth Brass 1






























Voice No.	Bank Select		MIDI Program Change# (1-128)	Voice Name
	MSB (0-127)	LSB (0-127)		
460	0	20	63	Resonant Synth Brass
461	0	0	64	Synth Brass 2
462	0	18	64	Soft Brass
463	0	41	64	Choir Brass
XG REED				
464	0	0	65	Soprano Sax
465	0	0	66	Alto Sax
466	0	40	66	Sax Section
467	0	0	67	Tenor Sax
468	0	40	67	Breathy Tenor Sax
469	0	0	68	Baritone Sax
470	0	0	69	Oboe
471	0	0	70	English Horn
472	0	0	71	Bassoon
473	0	0	72	Clarinet
XG PIPE				
474	0	0	73	Piccolo
475	0	0	74	Flute
476	0	0	75	Recorder
477	0	0	76	Pan Flute
478	0	0	77	Blown Bottle
479	0	0	79	Whistle
480	0	0	80	Ocarina
XG SYNTH LEAD				
481	0	0	81	Square Lead 1
482	0	6	81	Square Lead 2
483	0	8	81	LM Square
484	0	18	81	Hollow
485	0	19	81	Shroud
486	0	64	81	Mellow
487	0	65	81	Solo Sine
488	0	66	81	Sine Lead
489	0	0	82	Sawtooth Lead 1
490	0	6	82	Sawtooth Lead 2
491	0	8	82	Thick Sawtooth
492	0	18	82	Dynamic Sawtooth
493	0	19	82	Digital Sawtooth
494	0	20	82	Big Lead
495	0	24	82	Heavy Synth
496	0	96	82	Sequenced Analog
497	0	0	83	Calliope Lead
498	0	65	83	Pure Lead
499	0	0	84	Chiff Lead
500	0	0	85	Charang Lead
501	0	64	85	Distorted Lead
502	0	0	86	Voice Lead
503	0	0	87	Fifths Lead
504	0	35	87	Big Five
505	0	0	88	Bass & Lead
506	0	16	88	Big & Low
507	0	64	88	Fat & Perky
508	0	65	88	Soft Whirl
XG SYNTH PAD				
509	0	0	89	New Age Pad
510	0	64	89	Fantasy
511	0	0	90	Warm Pad
512	0	0	91	Poly Synth Pad
513	0	0	92	Choir Pad
514	0	66	92	Itopia
515	0	0	93	Bowed Pad
516	0	0	94	Metallic Pad
517	0	0	95	Halo Pad






















Voice No.	Bank Select		MIDI Program Change# (1-128)	Voice Name
	MSB (0-127)	LSB (0-127)		
518	0	0	96	Sweep Pad
XG SYNTH EFFECTS				
519	0	0	97	Rain
520	0	64	97	Harmo Rain
521	0	65	97	African Wind
522	0	66	97	Carib
523	0	0	98	Sound Track
524	0	27	98	Prologue
525	0	0	99	Crystal
526	0	12	99	Synth Drum Comp
527	0	14	99	Popcorn
528	0	18	99	Tiny Bells
529	0	35	99	Round Glockenspiel
530	0	40	99	Glockenspiel Chimes
531	0	41	99	Clear Bells
532	0	42	99	Chorus Bells
533	0	65	99	Soft Crystal
534	0	70	99	Air Bells
535	0	71	99	Bell Harp
536	0	72	99	Gamelimba
537	0	0	100	Atmosphere
538	0	18	100	Warm Atmosphere
539	0	19	100	Hollow Release
540	0	40	100	Nylon Electric Piano
541	0	64	100	Nylon Harp
542	0	65	100	Harp Vox
543	0	66	100	Atmosphere Pad
544	0	0	101	Brightness
545	0	0	102	Goblins
546	0	64	102	Goblins Synth
547	0	65	102	Creep
548	0	67	102	Ritual
549	0	68	102	To Heaven
550	0	70	102	Night
551	0	71	102	Glisten
552	0	96	102	Bell Choir
553	0	0	103	Echoes
554	0	65	103	Big Pan
555	0	0	104	Sci-Fi
XG WORLD				
556	0	0	78	Shakuhachi
557	0	97	105	Tamboura
558	0	0	106	Banjo
559	0	28	106	Muted Banjo
XG PERCUSSIVE				
560	0	0	113	Tinkle Bell
561	0	96	113	Bonang
562	0	97	113	Altair
563	0	98	113	Gamelan Gongs
564	0	99	113	Stereo Gamelan Gongs
565	0	100	113	Rama Cymbal
566	0	0	114	Agogo
567	0	0	115	Steel Drums
568	0	97	115	Glass Percussion
569	0	98	115	Thai Bells
570	0	0	116	Woodblock
571	0	96	116	Castanets
572	0	0	117	Taiko Drum
573	0	96	117	Gran Cassa
574	0	0	118	Melodic Tom 1
575	0	64	118	Melodic Tom 2
576	0	65	118	Real Tom

Voice No.	Bank Select		MIDI Program Change# (1-128)	Voice Name
	MSB (0-127)	LSB (0-127)		
577	0	66	118	Rock Tom
578	0	0	119	Synth Drum
579	0	64	119	Analog Tom
580	0	65	119	Electronic Percussion
581	0	0	120	Reverse Cymbal
XG SOUND EFFECTS				
582	64	0	1	Cutting Noise 1
583	64	0	2	Cutting Noise 2
584	64	0	4	String Slap
585	64	0	17	Flute Key Click
586	64	0	33	Shower
587	64	0	34	Thunder
588	64	0	35	Wind
589	64	0	36	Stream
590	64	0	37	Bubble
591	64	0	38	Feed
592	64	0	49	Dog
593	64	0	50	Horse
594	64	0	51	Bird Tweet 2
595	64	0	56	Maou
596	64	0	65	Phone Call
597	64	0	66	Door Squeak
598	64	0	67	Door Slam
599	64	0	68	Scratch Cut
600	64	0	69	Scratch Split
601	64	0	70	Wind Chime
602	64	0	71	Telephone Ring 2
603	64	0	81	Car Engine Ignition
604	64	0	82	Car Tires Squeal
605	64	0	83	Car Passing
606	64	0	84	Car Crash
607	64	0	85	Siren
608	64	0	86	Train
609	64	0	87	Jet Plane
610	64	0	88	Starship
611	64	0	89	Burst
612	64	0	90	Roller Coaster
613	64	0	91	Submarine
614	64	0	97	Laugh
615	64	0	98	Scream
616	64	0	99	Punch
617	64	0	100	Heartbeat
618	64	0	101	Footsteps
619	64	0	113	Machine Gun
620	64	0	114	Laser Gun
621	64	0	115	Explosion
622	64	0	116	Firework

Standard Kit 1 List

• For drum kits other than Standard Kit 1, refer to “Drum Kit List” on the website (page 8).

		Voice No. 243	
		Standard Kit 1	
C1	C#1	C 1	 Seq Click H
		C# 1	 Brush Tap
D1		D 1	 Brush Swirl
	D#1	D# 1	 Brush Slap
E1		E 1	 Brush Tap Swirl
F1	F#1	F 1	 Snare Roll
		F# 1	 Castanet
G1	G#1	G 1	 Snare Soft
		G# 1	 Sticks
A1	A#1	A 1	 Bass Drum Soft
		A# 1	 Open Rim Shot
B1		B 1	 Bass Drum Hard
C2	C#2	C 2	 Bass Drum
		C# 2	 Side Stick
D2	D#2	D 2	 Snare
		D# 2	 Hand Clap
E2		E 2	 Snare Tight
F2	F#2	F 2	 Floor Tom L
		F# 2	 Hi-Hat Closed
G2	G#2	G 2	 Floor Tom H
		G# 2	 Hi-Hat Pedal
A2	A#2	A 2	 Low Tom
		A# 2	 Hi-Hat Open
B2		B 2	 Mid Tom L
C3	C#3	C 3	 Mid Tom H
		C# 3	 Crash Cymbal 1
D3	D#3	D 3	 High Tom
		D# 3	 Ride Cymbal 1
E3		E 3	 Chinese Cymbal

		Voice No. 243	
		Standard Kit 1	
F3	F#3	F 3	 Ride Cymbal Cup
		F# 3	 Tambourine
G3	G#3	G 3	 Splash Cymbal
		G# 3	 Cowbell
A3	A#3	A 3	 Crash Cymbal 2
		A# 3	 Vibraslap
B3		B 3	 Ride Cymbal 2
C4	C#4	C 4	 Bongo H
		C# 4	 Bongo L
D4	D#4	D 4	 Conga H Mute
		D# 4	 Conga H Open
E4		E 4	 Conga L
F4	F#4	F 4	 Timbale H
		F# 4	 Timbale L
G4	G#4	G 4	 Agogo H
		G# 4	 Agogo L
A4	A#4	A 4	 Cabasa
		A# 4	 Maracas
B4		B 4	 Samba Whistle H
C5	C#5	C 5	 Samba Whistle L
		C# 5	 Guiro Short
D5	D#5	D 5	 Guiro Long
		D# 5	 Claves
E5		E 5	 Wood Block H
F5	F#5	F 5	 Wood Block L
		F# 5	 Cuica Mute
G5	G#5	G 5	 Cuica Open
		G# 5	 Triangle Mute
A5	A#5	A 5	 Triangle Open
		A# 5	 Shaker
B5		B 5	 Jingle Bells
C6		C 6	 Bell Tree

Song List

Song No.	Song Name
Demo	
001	Demo (Yamaha Original)
POP	
002	Happy (Pharrell Williams)
003	It's My Life (Jon Bon Jovi/Martin Sandberg/Richie Sambora)
004	Viva La Vida (Guy Berryman/Jon Buckland/Will Champion/Chris Martin)
005	Bad Romance (Stefani Germanotta/Nadir Khayat)
006	Shape Of You (Ed Sheeran/Kevin Briggs/Kandi Burruss/Tameka Cottle/Steve Mac/Johnny McDaid)
007	Duele El Corazon (Enrique Iglesias/M. Hasibur Rahman/Francisco Saldana/Juan Luis Morera/Servando Moriche Primera Musset/Patrick Ingunza/Silverio Ramon Lozada Schwarck)
008	Titanium (David Guetta/Sia Furler/Giorgio Tuinfort/Nick Van De Wall)
009	Perfect (Ed Sheeran)
010	Treasure (Bruno Mars/Ari Levine/Philip Lawrence/Fredrick Brown/Thibaut Berland/Christopher Acito)
011	Something Just Like This (Andrew Taggart/Chris Martin/Guy Berryman/Jonny Buckland/Will Champion)
FAVORITE	
012	Frère Jacques (Traditional)
013	Der Froschgesang (Traditional)
014	Aura Lee (Traditional)
015	London Bridge (Traditional)
016	Sur le pont d'Avignon (Traditional)
017	Old MacDonald Had a Farm (Traditional)
018	Nedelka (Traditional)
019	Aloha Oe (Q. Liliuokalani)
020	Sippin' Cider Through a Straw (Traditional)
021	Old Folks at Home (S. C. Foster)
022	Bury Me Not on the Lone Prairie (Traditional)
023	Santa Lucia (A. Longo)
024	If You're Happy and You Know It (Traditional)
025	Beautiful Dreamer (S. C. Foster)
026	Greensleeves (Traditional)
027	Kalinka (Traditional)
028	Holdilia Cook (Traditional)
029	Ring de Banjo (S. C. Foster)
030	La Cucaracha (Traditional)
031	Funiculi Funicula (L. Denza)
032	Largo (from the New World) (A. Dvořák)
033	Brahms' Lullaby (J. Brahms)
034	Liebesträume Nr.3 (F. Liszt)
035	Pomp and Circumstance (E. Elgar)
036	Chanson du Toreador (G. Bizet)
037	Jupiter, the Bringer of Jollity (G. Holst)

Song No.	Song Name
038	The Polovetsian Dances (A. Borodin)
039	Die Moldau (B. Smetana)
040	Salut d'Amour op.12 (E. Elgar)
041	Humoresques (A. Dvořák)
042	Symphony No.9 (from the New World - 4th movement) (A. Dvořák)
INSTRUMENT MASTER	
043	Sicilienne/Fauré (G. Fauré)
044	Swan Lake (P. I. Tchaikovsky)
045	Grand March (Aida) (G. Verdi)
046	Serenade for Strings in C major, op.48 (P. I. Tchaikovsky)
047	Pizzicato Polka (J. Strauss II)
048	Romance de Amor (Traditional)
049	Menuett BWV Anh.114 (J. S. Bach)
050	Ave Verum Corpus (W. A. Mozart)
051	Radetzky Marsch (J. Strauss I)
PIANO REPERTOIRE	
052	Wenn ich ein Vöglein wär (Traditional)
053	Die Lorelei (F. Silcher)
054	Home Sweet Home (H. R. Bishop)
055	Scarborough Fair (Traditional)
056	My Old Kentucky Home (Traditional)
057	Loch Lomond (Traditional)
058	Silent Night (F. Gruber)
059	Deck the Halls (Traditional)
060	O Christmas Tree (Traditional)
061	Sonata Pathétique 2nd Adagio Cantabile (L. v. Beethoven)
062	Ave Maria/J. S. Bach - Gounod (J. S. Bach/C. F. Gounod)
063	Jesus bleibet meine Freude (J. S. Bach)
064	Prelude op.28-15 "Raindrop" (F. Chopin)
065	Nocturne op.9-2 (F. Chopin)
066	Etude op.10-3 "Chanson de L'adieu" (F. Chopin)
067	Romanze (Serenade K.525) (W. A. Mozart)
068	Arabesque (J. F. Burgmüller)
069	La Chevaleresque (J. F. Burgmüller)
070	Für Elise (L. v. Beethoven)
071	Turkish March (W. A. Mozart)
072	24 Preludes op.28-7 (F. Chopin)
073	Annie Laurie (Traditional)
074	Jeanie with the Light Brown Hair (S. C. Foster)
LEARN TO PLAY	
075	Für Elise (Basic) (L. v. Beethoven)
076	Für Elise (Advanced) (L. v. Beethoven)
077	Twinkle Twinkle Little Star (Basic) (Traditional)
078	Twinkle Twinkle Little Star (Advanced) (Traditional)

Song No.	Song Name
079	Turkish March (Basic) (W. A. Mozart)
080	Turkish March (Advanced) (W. A. Mozart)
081	Ode to Joy (Basic) (L. v. Beethoven)
082	Ode to Joy (Advanced) (L. v. Beethoven)
083	The Entertainer (Basic) (S. Joplin)
084	The Entertainer (Advanced) (S. Joplin)
085	Londonderry Air (Basic) (Traditional)
086	Londonderry Air (Advanced) (Traditional)
087	The Last Rose of Summer (Basic) (Traditional)
088	The Last Rose of Summer (Advanced) (Traditional)
089	Amazing Grace (Basic) (Traditional)
090	Amazing Grace (Advanced) (Traditional)
FAVORITE WITH STYLE	
091	O du lieber Augustin (Traditional)
092	Mary Had a Little Lamb (Traditional)
093	When Irish Eyes Are Smiling (E. R. Ball)
094	Little Brown Jug (Traditional)
095	Ten Little Indians (Traditional)
096	On Top of Old Smoky (Traditional)
097	My Darling Clementine (P. Montrose)
098	Oh! Susanna (S. C. Foster)
099	Red River Valley (Traditional)
100	Turkey in the Straw (Traditional)
101	Muffin Man (R. A. King)
102	Pop Goes the Weasel (Traditional)
103	Grandfather's Clock (H. C. Work)
104	Camptown Races (S. C. Foster)
105	When the Saints Go Marching In (Traditional)
106	Yankee Doodle (Traditional)
107	Battle Hymn of the Republic (Traditional)
108	I've Been Working on the Railroad (Traditional)
109	American Patrol (F. W. Meacham)
110	Down by the Riverside (Traditional)
JAPANESE SONG	
111	Furusato (T. Okano)
112	Momiji (T. Okano)
113	Aogeba Totoshi (Traditional)
114	Haruga Kita (T. Okano)
115	Soushunfu (A. Nakada)
116	Akatonbo (K. Yamada)
DUET	
117	O Christmas Tree (Traditional)
118	We Wish You a Merry Christmas (Traditional)
119	Im Mai (Traditional)
120	Mary Had a Little Lamb (Traditional)
121	Yankee Doodle (Traditional)
122	Ten Little Indians (Traditional)

Song No.	Song Name
123	Scarborough Fair (Traditional)
124	Three Blind Mice (Traditional)
125	Battle Hymn of the Republic (Traditional)
126	My Darling Clementine (P. Montrose)
127	The Cuckoo (Traditional)
128	London Bridge (Traditional)
129	Close Your Hands, Open Your Hands (J. J. Rousseau)
PIANO SOLO	
130	Valse op.64-1 "Petit Chien" (F. Chopin)
131	Menuett/Beethoven (L. v. Beethoven)
132	Andante grazioso (Sonate K.331) (W. A. Mozart)
133	Melodie (Album für die Jugend) (R. Schumann)
134	Fröhlicher Landmann (Album für die Jugend) (R. Schumann)
135	Von fremden Ländern und Menschen (Kinderszenen) (R. Schumann)
136	Thema (Impromptus D.935-3) (F. Schubert)
137	Invention Nr.1 (J. S. Bach)
138	Gavotte/J. S. Bach (J. S. Bach)
139	Arietta/Grieg (E. Grieg)
140	To a Wild Rose (E. A. MacDowell)

SPECIAL APPENDIX	
TOUCH TUTOR	
141–150	Touch Tutor 01–Touch Tutor 10
CHORD STUDY	
151–162	Chord Study 01–Chord Study 12
CHORD PROGRESSION	
163–202	Maj1234–min1736

- Some Songs have been edited for length or for ease in learning, and may not be exactly the same as the original.
- A Song Book (free downloadable scores) is available that includes scores for internal Songs (excepting for a Demo Song and some Songs due to copyright issues). To obtain this Song Book, access the Yamaha website and download it from the product web page.
<https://www.yamaha.com>

Style List

Style No.	Style Name
8BEAT	
1	BritPopRock
2	8BeatModern
3	Cool8Beat
4	Happy8Beat
5	Shake8Beat
6	BoyBandPop
7	SweetPop
8	ContemporaryRock
9	StadiumRock
10	70sRock
11	HardRock 1
12	60sGuitarPop
13	8BeatAdria
14	60s8Beat
15	8Beat
16	OffBeat
17	Folkrock
18	60sRock
19	HardRock 2
20	RockShuffle
21	8BeatRock
16BEAT	
22	16Beat
23	DancehallPop
24	CinematicPop
25	PopShuffle
26	GuitarPop
27	16BeatUptempo
28	KoolShuffle
29	HipHopLight
BALLAD	
30	70sGlamPiano
31	EpicDivaBallad
32	OrchestraRockBallad
33	PianoBallad
34	LoveSong
35	6/8ModernEP
36	6/8SlowRock
37	OrganBallad
38	PopBallad
39	16BeatBallad
DANCE	
40	ClubBeat
41	SkyPop
42	AgagBeat
43	Electronica
44	FunkyHouse
45	RetroClub
46	USHipHop
47	MellowHipHop
48	Chillout

Style No.	Style Name
49	EuroTrance
50	Ibiza
51	SwingHouse
52	Clubdance
53	ClubLatin
54	Garage 1
55	Garage 2
56	TechnoParty
57	UKPop
58	HipHopGroove
59	HipShuffle
60	HipHopPop
DISCO	
61	ModernDisco
62	70sDisco
63	LatinDisco
64	SaturdayNight
65	DiscoHands
SWING&JAZZ	
66	BigBandFast
67	BigBandBallad
68	AcousticJazz
69	AcidJazz
70	JazzClub
71	Swing 1
72	Swing 2
73	Five/Four
74	Dixieland
75	Ragtime
R&B	
76	BluesRock
77	UK Soul
78	JustR&B
79	WorshipAcoustic1
80	WorshipAcoustic2
81	WorshipRockBallad
82	Soul
83	DetroitPop
84	60sRock&Roll
85	6/8Soul
86	CrocoTwist
87	Rock&Roll
88	ComboBoogie
89	6/8Blues
COUNTRY	
90	CountryPop
91	CountrySwing
92	Country2/4
93	Bluegrass
LATIN	
94	BrazilianSamba
95	BrazilianBossa

Style No.	Style Name
96	Bachata
97	CubanSon
98	Guajira
99	BossaNova
100	Forro
101	Sertanejo 1
102	Sertanejo 2
103	Baião
104	TangoArgentino
105	CumbiaPeruana
106	CumbiaColombiana
107	Vallenato
108	Joropo
109	Parranda
110	Merengue
111	ReggaetonPop
112	Reggaeton
113	Tijuana
114	PasoDuranguense
115	CumbiaGrupera
116	BaladaBanda
117	MexicanMambo
118	Mambo
119	Salsa
120	Beguine
121	Reggae
WORLD	
122	Hawaiian
123	CelticDance
124	ScottishReel
125	4/4Standart
126	Rumba2/4
127	Saeidy
128	WehdaSaghira
129	IranianElec
130	Emarati
131	AfricanGospelReggae
132	HighLife1
133	AfricanGospel
134	Makossa
135	ModernAfrobeat
136	HighLife2
137	OrganHighLife
138	IgboHighLife
139	SocaCalypso
140	Azonto
141	IndianPop
142	Bhangra
143	Bhajan
144	BollyMix
145	Tamil
146	Kerala

Style No.	Style Name
147	GoanPop
148	Rajasthan
149	Dandiya
150	Qawwali
151	FolkHills
152	ModernDangdut1
153	Keroncong
154	ModernDangdut2
155	DangdutUmum
156	DangdutSlowLegend
157	Dangdut3/4
158	KoploRampak
159	LanggamModern
160	DangdutJawa
161	Congdut
162	VietnamesePopBallad
163	Vietnamese6/8Ballad
164	XiQingLuoGu
165	YiZuMinGe
166	JingJuJieZou
BALLROOM	
167	VienneseWaltz
168	EnglishWaltz
169	Slowfox
170	Foxtrot
171	Quickstep
172	Tango
173	Pasodoble
174	Samba
175	ChaChaCha
176	Rumba
177	Jive
TRADITIONAL	
178	US March
179	6/8March
180	GermanMarch
181	PolkaPop
182	OberkrainerPolka
183	Tarantella
184	Showtune
185	ChristmasSwing
186	ChristmasWaltz
WALTZ	
187	ItalianWaltz
188	SwingWaltz
189	JazzWaltz
190	ValsMexicano
191	CountryWaltz
192	OberkrainerWalzer
193	Musette
CHILDREN	
194	Learning2/4

Style No.	Style Name
195	Learning4/4
196	Learning6/8
PIANIST	
197	Stride
198	PianoSwing
199	PianoBoogie
200	Arpeggio
201	Habanera
202	SlowRock
203	8BeatPianoBallad
204	6/8PianoMarch
205	PianoWaltz

Music Database List

MDB No.	MDB Name
ALL TIME HITS	
1	Jude Hey
2	Jumping
3	WrldRock
4	All OK
5	YourTune
6	USA Surf
7	JustCall
8	Get Home
9	GrWheel
10	lWasBorn
11	Sailing
12	BluJeans
13	Holiday
14	Imagine
15	Marriage
16	WiteShde
17	NowNever
18	Hard Day
19	USA Pie
20	Norway
21	YesterBd
22	A Magic
POP & ROCK	
23	UR Shape
24	Love Me
25	Ideal
26	SweetPop
27	Just Way
28	Speed
29	Cheerful
30	SwiftShke
31	Watches
32	PrtTmLvr
33	S Party
34	MoonShdw
35	NikitSng
36	GirlsMne
37	Radio
38	Attempt
39	OnAStrng
40	WhatWant
41	ThankFor
42	Tmbourin
43	RubyGirl
44	TopWorld
45	TeachSng
46	Each Min
47	ShakenUp
48	CrocRock
49	HurryLov
50	Champion
51	Jailhou






















MDB No.	MDB Name
52	Rock&Rll
53	HonkyTnk
54	JustU&Me
55	LveSmile
56	Wish I
BALLAD	
57	StayWith
58	DontMiss
59	HiBallad
60	Red Lady
61	IvoryAnd
62	TheWorld
63	Paradise
64	Whisper
65	Woman
66	CndleWnd
67	Fly Away
68	Love You
69	SavingAl
70	InTheDrk
71	Say You
72	Way Were
73	Inspiring
OLDIES	
74	Diana's
75	Tonight
76	SandLter
77	No Rain
78	Ghetto
79	PrettyWm
80	Sherry
81	Sally's
DANCE & DISCO	
82	SkyStars
83	Bad Love
84	PokerPop
85	FevrNite
86	StyAlive
87	Westerly
88	Run Free
89	DISCO
90	JoelLife
91	Coupled
92	SingBack
93	Janeiro
94	BoomRoom
95	DontHide
96	RewCraig
97	LondonRU
98	WerUBeen
99	MkeMusic
100	10,2 Sun
101	Trust

MDB No.	MDB Name
102	MarieCib
SWING & JAZZ	
103	Moon Of
104	Patrol
105	Rhythm
106	CatSwing
107	Misbehav
108	Safari
109	SoWhatsIs
110	TimeGone
111	TasteHny
112	Two Foot
113	Blk&White
114	EnterRag
115	TakeFour
116	Birdland
117	MistyFln
COUNTRY	
118	OnTheRd
119	BlueSong
120	InMyMind
121	RoadHome
122	GreenGrs
123	EverNeed
124	Lucille
125	Tennesse
LATIN	
126	LoveAmor
127	Brasil
128	ChryPink
129	MyShadow
130	BosaWave
131	DntWorry
132	I'm Pola
133	Mambo Jm
134	One Note
135	PasoCani
136	Beguine
137	Tijuana
138	Puntuali
139	Cielito
140	The Liar
141	Unfrgivr
ENTERTAINMENT	
142	Raindrop
143	Califrag
144	CatMemry
145	MyPrince
146	Showbiz
147	JinglBel
148	SilentNt
149	Christms
150	Favorite

MDB No.	MDB Name
151	RedRdolf
152	Moon Wlz
153	AroundWd
WALTZ & TRAD	
154	DadClock
155	RockBaby
156	SomeLara
157	Doodah!
158	Dreamer
159	Birthday
160	Sunshine
161	Tex Rose
162	ThePolka
163	Yankee's
164	DanubeWz
165	D'amor
166	Reine de
167	MnchHaus
168	Comrades
169	Van Maas
170	ClariPka

Effect Type List

Harmony Types

No.	Harmony Type	Description	
001	Duet	<p>If you want to sound one of the harmony types 01–05, play keys to the right side of the Split Point while playing chords in the left side of the keyboard after turning Auto Accompaniment on. One, two or three notes of harmony are automatically added to the note you play. When playing back a Song that includes chord data, harmony is applied whichever keys are played.</p>	
002	Trio		
003	Block		
004	Country		
005	Octave		
006	Trill 1/4 note		<p>If you keep holding down two different notes, the notes alternate (in a trill) continuously. (The trill speed differs depending on the selected type.)</p>
007	Trill 1/6 note		
008	Trill 1/8 note		
009	Trill 1/12 note		
010	Trill 1/16 note		
011	Trill 1/24 note		
012	Trill 1/32 note		<p>If you keep holding down a note, the note is repeated continuously. (The repeat speed differs depending on the selected type.)</p>
013	Tremolo 1/4 note		
014	Tremolo 1/6 note		
015	Tremolo 1/8 note		
016	Tremolo 1/12 note		
017	Tremolo 1/16 note		
018	Tremolo 1/24 note		
019	Tremolo 1/32 note		<p>If you play a note, echo is applied to the note played. (The echo speed differs depending on the selected type.)</p>
020	Echo 1/4 note		
021	Echo 1/6 note		
022	Echo 1/8 note		
023	Echo 1/12 note		
024	Echo 1/16 note		
025	Echo 1/24 note		
026	Echo 1/32 note		

Arpeggio Types

Arpeggio No.	Arpeggio Name
027	UpOct
028	DownOct
029	UpDwnOct
030	SynArp1
031	SynArp2
032	SynArp3
033	SynArp4
034	SyncEcho
035	PulsLine
036	StepLine
037	Random
038	Down&Up
039	SuperArp
040	AcidLine
041	TekEcho
042	VelGruv
043	Planet
044	Trance1
045	Trance2
046	Trance3
047	ChordAlt
048	SynChrd1
049	SynChrd2
050	Syncopa
051	Hybrid1
052	Hybrid2
053	Hybrid3
054	Hybrid4
055	Hybrid5
056	PfArp1
057	PfArp2
058	PfArp3
059	PfArp4
060	PfClub1
061	PfClub2
062	PfBallad
063	PfChd8th
064	EPArp
065	PfShuffle
066	PfRock
067	Clavi1
068	Clavi2
069	RocknPf
070	70RockPf
071	SlowflPf
072	SoulPf
073	ChordUp
074	ChdDance
075	LatinRck
076	Salsa1
077	Salsa2
078	Reggae1
079	Reggae2
080	Reggae3
081	6/8R&B
082	Gospel
083	BalladEP
084	Strum1
085	Strum2
086	Strum3
087	Strum4
088	Pickin1
089	Pickin2
090	Funky

Arpeggio No.	Arpeggio Name
091	GtrChrd1
092	GtrChrd2
093	GtrChrd3
094	GtrArp
095	FngrPck1
096	FngrPck2
097	CleanGtr
098	Slowfl
099	Samba1
100	Samba2
101	Spanish1
102	Spanish2
103	Harp1
104	Harp2
105	FngrBas1
106	FngrBas2
107	FngrBas3
108	CoolFunk
109	SlapBass
110	AcidBas1
111	AcidBas2
112	FunkyBas
113	CmbJazB1
114	CmbJazB2
115	CmbJazB3
116	NewR&BBs
117	HipHopBs
118	SmoothBs
119	DreamBas
120	TranceBs
121	LatinBas
122	Strings1
123	Strings2
124	Strings3
125	Strings4
126	StrngDwn
127	StrngUp
128	OrcheStr
129	Jupiter
130	Pizz1
131	Pizz2
132	BrasSec1
133	BrasSec2
134	BrasSec3
135	FunkBras
136	SoulReed
137	DiscoLd
138	SmoothPd
139	PercArp
140	Ethnic
141	Cresendo
142	DiscoCP
143	Perc1
144	Perc2
145	R&B
146	Funk1
147	Funk2
148	Funk3
149	Soul
150	CiscHip
151	Smooth
152	NewGospl
153	CmbJazz1
154	CmbJazz2

Arpeggio No.	Arpeggio Name
155	Bebop
156	JazzHop
157	FolkRock
158	Unpluggd
159	HipHop
160	Trance
161	Dream
162	2 Step
163	ClubHs1
164	ClubHs2
165	EuroTek
166	House
167	Ibiza1
168	Ibiza2
169	Ibiza3
170	Garage
171	Samba
172	African
173	Latin
174	China
175	Indian
176	Arabic

• When playing one of the Arpeggio Types 143 to 176, select the corresponding Voice below as the Main Voice.

143–173: Select a Drum Kit (Voice No.242–252).

174 (China): Select "StdKit1 + Chinese Perc." (Voice No.253).

175 (Indian): Select "Indian Kit 1" (Voice No.254) or "Indian Kit 2" (Voice No.255).

176 (Arabic): Select "Arabic Kit" (Voice No.259).

Reverb Types

No.	Reverb Type	Description
01–04	Hall 1–4	Concert hall reverb.
05	Cathedral	Rich reverb simulating the acoustics of a cathedral. Good for pipe organ sounds.
06–08	Room 1–3	Small room reverb.
09–10	Stage 1–2	Reverb for solo instruments.
11–12	Plate 1–2	Simulated steel plate reverb.
13	Off	No effect.

Chorus Types

No.	Chorus Type	Description
1–3	Chorus 1–3	Conventional chorus program with rich, warm chorusing.
4–5	Flanger 1–2	This produces a rich, animated wavering effect in the sound.
6	Off	No effect.

NOTE

- Some Styles/Songs may have types that are not listed above.
- The Reverb/Chorus Type is reset when you select another Style/Song.

DSP Types

No.	DSP Type	Description
01	Dual Rotary Speaker Bright Slow	Simulates a rotary speaker.
02	Dual Rotary Speaker Bright Fast	
03	Rotary Speaker Slow	
04	Rotary Speaker Fast	
05	Small Stereo Distortion	Stereo distortion for guitar. Setting for distortion sound.
06	Small Stereo Overdrive	Stereo distortion for guitar. Setting for overdrive sound.
07	Small Stereo Vintage Amp	Stereo distortion for guitar. Setting for vintage sound.
08	British Combo Classic	British combo amp simulator. Setting for classic sound.
09	British Combo Top Boost	British combo amp simulator. Setting for "TOP BOOST" sound.
10	British Combo Heavy	British combo amp simulator. Setting for heavy sound.
11	British Legend Blues	British stack amp simulator. Setting for blues sound.
12	British Legend Heavy	British stack amp simulator. Setting for heavy sound.
13	British Legend Clean	British stack amp simulator. Setting for clean sound.
14	Stereo Amp Sim Crunch	Stereo amp simulator.
15	Stereo Amp Sim Blues	
16	Chorus 1	Conventional chorus program with rich, warm chorusing.
17	Chorus 3	
18	Chorus 4	
19	Chorus 5	
20	Celeste 2	A 3-phase LFO adds modulation and spaciousness to the sound.
21	Symphonic	Adds more stages to the modulation of Celeste.
22	Flanger1	Creates a sound similar to that of a jet airplane.
23	Vintage Phaser Stereo	This simulates an analog phaser, giving a strong vintage flavor to the sound. It is effective in stereo.
24	Phaser	Cyclically modulates the phase to add modulation to the sound.
25	E-Piano Phaser	Cyclically modulates the phase to add modulation to the sound. For electric piano.
26	Auto Wah	Cyclically modulates the center frequency of a wah filter.
27	Auto Wah + Distortion	Distortion can be applied to the output of Auto Wah.
28	Clavi Touch Wah	Clavinet Touch Wah
29	Tremolo	Rich Tremolo effect with both volume and pitch modulation.
30	E-Piano Tremolo	
31	Guitar Tremolo	
32	Ensemble Detune	Chorus effect without modulation, created by adding a slightly pitch-shifted sound.

Effect Type List

No.	DSP Type	Description
33	Tempo Auto Pan	Tempo-synchronized auto pan.
34	Echo	Two delayed sounds (L and R), and independent feedback delays for L and R.
35	Cross Delay	The feedback of the two delayed sounds is crossed.
36	Compressor Medium	Compressor with medium setting.
37	3Band EQ	A mono EQ with adjustable LOW, MID, and HIGH equalization.
38	Harmonic Enhancer	Adds new harmonics to the input signal to make the sound stand out.

Specifications

Product Name			EZ-300	
Size/Weight	Dimensions (W x D x H)		945 mm x 369 mm x 118 mm (37-3/16" x 14-1/2" x 4-5/8")	
	Weight		4.8 kg (10 lb 9 oz) (not including batteries)	
Control Interface	Keyboard	Number of Keys	61	
		Touch Response	Soft, Medium, Hard, Fixed	
		Light Guide	Yes	
	Display	Type	LCD	
		Backlight	Yes	
	Panel	Language	English	
Language		English		
Voices	Tone Generation	Tone Generation Technology	AWM Stereo Sampling	
	Polyphony (max.)		48	
	Preset	Number of Voices	622 (241 Panel Voices + 22 Drum/SFX kits + 20 Arpeggio + 339 XGlite Voices)	
	Compatibility		GM/XGlite	
Effects	Types	DSP	38 types	
		Reverb	12 types	
		Chorus	5 types	
		Master EQ	6 types	
	Functions	Dual	Yes	
		Split	Yes	
		Sustain	Yes	
		Harmony	26 types	
		Arpeggio	150 types	
		Melody Suppressor	Yes	
Articulation		Yes (11 Super Articulation Lite Voices)		
Accompaniment Styles	Preset	Number of Styles	205	
		Fingering	Smart Chord, Multi finger	
		Style Control	ACMP ON/OFF, SYNC START, START/STOP, INTRO/ENDING/rit., MAIN/AUTO FILL	
	External Styles		10	
	Other Features	Music Database	170	
One Touch Setting (OTS)		Yes		
Compatibility		Style File Format (SFF)		
Songs (MIDI)	Preset	Number of Preset Songs	202 (including Touch Tutor: 10, Chord Study: 12, Chord Progression: 40)	
		Recording		5
	Format	Number of Tracks	2	
		Data Capacity	Approx. 10,000 notes	
		Recording	SMF Formats 0 & 1 Original File Format	
Functions	Lesson		Keys to Success, Lesson 1-3 (Listening, Timing, Waiting), Phrase Repeat, A-B Repeat, Chord Dictionary, Touch Tutor, Chord Study, Chord Progression	
	USB Audio (USB TO HOST)		44.1 kHz, 16 bit, stereo	
	Registration Memory	Number of Buttons	9	
		Overall Controls		Metronome: Yes Tempo Range: 11-280 Transpose: -12 to 0, 0 to +12 Tuning: 427.0-440.0-453.0 Hz (approx. 0.2 Hz increments)
	Miscellaneous	Duo	Yes	
		PIANO Button	Yes ((PORTABLE GRAND) Button)	
	Storage and Connectivity	Storage	Internal Memory	Approx. 1.4 MB
		Connectivity	DC IN	12 V
Headphones/Output			Standard stereo phone jack (PHONES/OUTPUT)	
Sustain			Sustain, Articulation, Arpeggio	
AUX IN			Yes (Stereo mini jack)	
USB TO HOST			Yes	
Sound System	Amplifiers	2.5 W + 2.5 W		
	Speakers	12 cm x 2		

Specifications

Power Supply	Power Supply	AC Adaptor	Users within U.S or Europe: PA-130 or an equivalent recommended by Yamaha Others: PA-3C,PA-130 or an equivalent recommended by Yamaha
		Batteries	Six 1.5 V "AA" size alkaline (LR6), manganese (R6) or six 1.2 V "AA" size Ni-MH rechargeable batteries (HR6)
	Power Consumption		5 W (When using PA-130 AC adaptor)
	Auto Power Off		Yes (Time can be set)
Included Accessories			<ul style="list-style-type: none"> • Owner's Manual • Music Rest • AC adaptor * (PA-130 or an equivalent recommended by Yamaha) • Online Member Product Registration <ul style="list-style-type: none"> * May not be included depending on your particular area. Please check with your Yamaha dealer.
Separately Sold Accessories (May not be available depending on your area.)			<ul style="list-style-type: none"> • AC adaptor: Users within U.S. or Europe: PA-130 or an equivalent recommended by Yamaha Others: PA-3C, PA-130 or an equivalent recommended by Yamaha • Keyboard stand: L-2C • Headphones: HPH-50/HPH-100/HPH-150 • Footswitch: FC4A/FC5

* The contents of this manual apply to the latest specifications as of the publishing date. To obtain the latest manual, access the Yamaha website then download the manual file. Since specifications, equipment or separately sold accessories may not be the same in every locale, please check with your Yamaha dealer.

Index

- A**
- A-B Repeat 34
 - AC Adaptor 14
 - Arpeggio 16, 28
 - Arpeggio Type 29, 90
 - Arpeggio Velocity 61
 - Articulation 16, 27
 - Audio Device 56
 - Auto Accompaniment 21, 45
 - Auto Accompaniment Range 45
 - AUTO FILL 46
 - Auto Power Off 15, 63
 - AUX IN 56
- B**
- Backup 59
 - Backup Clear 59
 - Battery 14
 - Battery Type 15, 63
 - Beat 17
 - BGM 33
- C**
- Chord 17, 47
 - Chord Dictionary 49
 - Chord Progressions 43
 - Chord Study 42
 - Chorus 27
 - Chorus Type 61, 91
 - Clear (User Song) 52
 - Computer 19, 57
 - Computer-related Operations 8
 - Copyright 97
- D**
- DEMO 33
 - Display 17
 - Drum Kit List 8
 - DSP 26
 - DSP Type 61, 91
 - Dual 25
 - Dual Voice 25, 61
 - Duo 30
 - Duo Split Point 30, 63
- E**
- Effect 26
 - Effect Type List 89
 - ENDING 46
 - External Clock 62
- F**
- Fast Forward 33
 - Fast Reverse 33
 - Fingering Type 44
 - Flash Clear 59
 - Footswitch 16, 29
 - Freeze 54
 - Function List 60
 - Functions 23, 60
- G**
- GM System Level 1 9
 - Guide 40
- H**
- Harmony 28
 - Harmony Type 29, 89
 - Headphones 16
- I**
- Initial Send 62
 - Initialization 59
 - INTRO 46
- K**
- Key → Transpose 60
 - Keyboard Display 17
 - Keys To Success 20, 36
- L**
- Layer 25
 - Lesson 20, 35
 - Light Guide 23, 36
 - Listening 20, 39
 - Local Control 62
- M**
- MAIN 46
 - Master EQ 55
 - Master EQ types 55
 - Master Volume 16
 - Measure 17
 - Melody Suppressor 58
 - Metronome 23, 24
 - Metronome Volume 24, 62
 - MIDI Basics 8
 - MIDI Reference 8
 - Multi Finger 44
 - Music Database 50
 - Music Database List 87
 - Music Rest 16
- O**
- One Touch Setting 24
- P**
- Part 34
 - Passing Status 37
 - Pause 33
 - Pedal 16, 29
 - Phrase Repeat 20, 38
 - Pitch → Transpose 60
 - Pitch → Tuning 60
 - PORTABLE GRAND 18, 24
 - Power 14
- R**
- Random Playback 33
 - Recording 22, 51
 - Registration Memory 53
 - Reverb 27
 - Reverb Type 61, 91
 - Rhythm 45
 - rit. (ritardando) 46
- S**
- Sections 46
 - Smart Chord 44, 48
 - Smart Chord Key 44
 - Smart Device 58
 - Smart Device Connection
Manual 8
 - Song 18, 31
 - Song Book 8, 36
 - Song Book Sample 66
 - Song Category 31
 - Song List 83
 - Song Melody Voice 33
 - Song Volume 32, 61
 - Specifications 93
 - Split 25
 - Split Point 25, 45
 - Split Voice 25, 61
 - Standard Kit 1 List 82
 - Storage Mode 19, 57
 - Style 18, 21, 44
 - Style File 9, 50
 - Style List 85
 - Style Volume 45, 61
 - Sustain 16, 27
 - Synchro Start 45
- T**
- Tap function 32
 - Tempo 24, 32

Time Signature24
Timing.....20, 39
Touch Response.....26
Touch Tutor41
Track.....51, 52
Transpose60
Troubleshooting64
Tuning.....60

U

USB Audio Interface57
USB TO HOST57
User Song51

V

Voice.....18, 24
Voice List76
Volume (AUX IN)62
Volume (Dual Voice)61
Volume (Harmony).....61
Volume (Main Voice).....60
Volume (Metronome).....24, 62
Volume (Split Voice)61
Volume (USB TO HOST)62

W

Waiting.....20, 39, 43

X

XGlite.....9

Credits and Copyrights for the preset Songs

Bad Romance

Words and Music by Stefani Germanotta and Nadir Khayat

Copyright (c) 2009 Sony/ATV Music Publishing LLC and House Of Gaga Publishing Inc.

All Rights Administered by Sony/ATV Music Publishing LLC, 424 Church Street, Suite 1200, Nashville, TN 37219

International Copyright Secured All Rights Reserved

Duele El Corazon

Words and Music by Enrique Iglesias, M. Hasibur Rahman, Francisco Saldana, Juan Luis Morera, Servando Moriche Primera Mussett, Patrick Ingunza and Silverio Ramon Lozada Schwarck

Copyright (c) 2016 Kobalt Music Copyrights SARL, Xuanlu Music Inc., EMI Blackwood Music Inc., Blue Kraft Music Publishing, Sony/ATV Music Publishing LLC, Yele Publishing, Sony/ATV Bailar, Warner-Tamerlane Publishing Corp., Patrick Ingunza Music, WB Music Corp. and Azul Siete Music

All Rights for Kobalt Music Copyrights SARL and Xuanlu Music Inc. Administered Worldwide by Kobalt Music Group Ltd.

All Rights for EMI Blackwood Music Inc., Blue Kraft Music Publishing, Sony/ATV Music Publishing LLC, Yele Publishing and Sony/ATV Bailar Administered by Sony/ATV Music Publishing LLC, 424 Church Street, Suite 1200, Nashville, TN 37219

All Rights for Patrick Ingunza Music Administered by Warner-Tamerlane Publishing Corp.

All Rights for Azul Siete Music Administered by WB Music Corp.

All Rights Reserved Used by Permission

Happy

from DESPICABLE ME 2

Words and Music by Pharrell Williams

Copyright (c) 2013 EMI April Music Inc., More Water From Nazareth and Universal Pictures Global Music

All Rights on behalf of EMI April Music Inc. and More Water From Nazareth Administered by Sony/ATV Music Publishing LLC, 424 Church Street, Suite 1200, Nashville, TN 37219

All Rights on behalf of Universal Pictures Global Music Controlled and Administered by Universal Music Works

International Copyright Secured All Rights Reserved

It's My Life

Words and Music by Jon Bon Jovi, Martin Sandberg and Richie Sambora

Copyright (c) 2000 Universal Music Publishing International Ltd., Bon Jovi Publishing, GV-MXM, Sony/ATV Music Publishing LLC and Aggressive Music

All Rights for Universal Music Publishing International Ltd. and Bon Jovi Publishing Administered by Universal Music Works

All Rights for GV-MXM Administered Worldwide by Kobalt Songs Music Publishing

All Rights for Sony/ATV Music Publishing LLC and Aggressive Music Administered by Sony/ATV Music Publishing LLC, 424 Church Street, Suite 1200, Nashville, TN 37219

All Rights Reserved Used by Permission

Perfect

Words and Music by Ed Sheeran

Copyright (c) 2017 Sony/ATV Music Publishing (UK) Limited

All Rights Administered by Sony/ATV Music Publishing LLC, 424 Church Street, Suite 1200, Nashville, TN 37219

International Copyright Secured All Rights Reserved

Shape Of You

Words and Music by Ed Sheeran, Kevin Briggs, Kandi Burruss, Tameka Cottle, Steve Mac and Johnny McDaid

Copyright (c) 2017 Sony/ATV Music Publishing (UK) Limited, EMI April Music Inc., Air Control Music, Kandacy Music, Tiny Tam

Music, Shek'em Down Music, Pepper Drive Music, Tony Mercedes Music, Rokstone Music and Spirit B-Unique Polar Patrol

All Rights on behalf of Sony/ATV Music Publishing (UK) Limited, EMI April Music Inc., Air Control Music, Kandacy Music and Tiny

Tam Music Administered by Sony/ATV Music Publishing LLC, 424 Church Street, Suite 1200, Nashville, TN 37219

All Rights on behalf of Shek'em Down Music Administered by Songs Of Windswept Pacific and Hitco Music

All Rights on behalf of Songs Of Windswept Pacific and Hitco Music Administered by BMG Rights Management (US) LLC

All Rights on behalf of Pepper Drive Music Administered by Warner-Tamerlane Publishing Corp.

All Rights on behalf of Tony Mercedes Music Administered by WB Music Corp.

All Rights on behalf of Rokstone Music in the United States and Canada Administered by Universal - PolyGram International Publishing, Inc.

All Rights on behalf of Spirit B-Unique Polar Patrol Controlled and Administered by Spirit B-Unique Polar Patrol Songs

International Copyright Secured All Rights Reserved

- contains samples of "No Scrubs" by Kevin Briggs, Kandi Burruss and Tameka Cottle (c) 1999 EMI April Music Inc., Air Control Music, Kandacy Music, Tiny Tam Music, Shek'em Down Music, Pepper Drive Music and Tony Mercedes Music

Something Just Like This

Words and Music by Andrew Taggart, Chris Martin, Guy Berryman, Jonny Buckland and Will Champion
Copyright (c) 2017 Sony/ATV Music Publishing LLC, EMI April Music Inc., Nice Hair Publishing and Universal Music Publishing MGB Ltd.

All Rights on behalf of Sony/ATV Music Publishing LLC, EMI April Music Inc. and Nice Hair Publishing Administered by Sony/ATV Music Publishing LLC, 424 Church Street, Suite 1200, Nashville, TN 37219

All Rights on behalf of Universal Music Publishing MGB Ltd. Administered in the United States and Canada by Universal Music - MGB Songs

International Copyright Secured All Rights Reserved

Titanium

Words and Music by David Guetta, Sia Furler, Giorgio Tuinfort and Nick Van De Wall
Copyright (c) 2011 What A Publishing Ltd., KMR Music Royalties II SCSp, EMI Music Publishing Ltd., Sony/ATV Music Publishing LLC and Afrojack Publishing

All Rights for What A Publishing Ltd. and KMR Music Royalties II SCSp Administered Worldwide by Kobalt Songs Music Publishing
All Rights for EMI Music Publishing Ltd. and Sony/ATV Music Publishing LLC Administered by Sony/ATV Music Publishing LLC, 424 Church Street, Suite 1200, Nashville, TN 37219

All Rights for Afrojack Publishing Administered by BMG Rights Management (US) LLC

All Rights Reserved Used by Permission

Treasure

Words and Music by Bruno Mars, Ari Levine, Philip Lawrence, Fredrick Brown, Thibaut Berland and Christopher Acito
(c) 2012 BMG GOLD SONGS, MARS FORCE MUSIC, UNIVERSAL MUSIC CORP., TOY PLANE MUSIC, NORTHSIDE INDEPENDENT MUSIC PUBLISHING LLC, WB MUSIC CORP., ROC NATION MUSIC, MUSIC FAMAMANEM and SONGS MUSIC PUBLISHING, LLC o/b/o BECAUSE EDITIONS LTD.

All Rights for BMG GOLD SONGS and MARS FORCE MUSIC Administered by BMG RIGHTS MANAGEMENT (US) LLC

All Rights for TOY PLANE MUSIC Controlled and Administered by UNIVERSAL MUSIC CORP.

All Rights for ROC NATION MUSIC and MUSIC FAMAMANEM Administered by WB MUSIC CORP.

All Rights Reserved Used by Permission

Viva La Vida

Words and Music by Guy Berryman, Jonny Buckland, Will Champion and Chris Martin

Copyright (c) 2008 by Universal Music Publishing MGB Ltd.

All Rights in the United States and Canada Administered by Universal Music - MGB Songs

International Copyright Secured All Rights Reserved

Information for users on collection and disposal of old equipment and used batteries:



These symbols on the products, packaging, and/or accompanying documents mean that used electrical and electronic products and batteries should not be mixed with general household waste.

For proper treatment, recovery and recycling of old products and used batteries, please take them to applicable collection points, in accordance with your national legislation.

By disposing of these products and batteries correctly, you will help to save valuable resources and prevent any potential negative effects on human health and the environment which could otherwise arise from inappropriate waste handling.



For more information about collection and recycling of old products and batteries, please contact your local municipality, your waste disposal service or the point of sale where you purchased the items.

For business users in the European Union:

If you wish to discard electrical and electronic equipment, please contact your dealer or supplier for further information.



Information on Disposal in other Countries outside the European Union:

These symbols are only valid in the European Union. If you wish to discard these items, please contact your local authorities or dealer and ask for the correct method of disposal.

Note for the battery symbol (bottom two symbol examples):

This symbol might be used in combination with a chemical symbol. In this case it complies with the requirement set by the EU Battery Directive for the chemical involved.

Cd

Memo



**LIMITED 1-YEAR WARRANTY ON
PORTABLE KEYBOARDS
(NP, PSRE, PSREW, PSRF, PSRI, PSS, SHS, EZ, DGX230, DGX530,
YPG AND YPT SERIES)**

Thank you for selecting a Yamaha product. Yamaha products are designed and manufactured to provide a high level of defect-free performance. Yamaha Corporation of America ("Yamaha") is proud of the experience and craftsmanship that goes into each and every Yamaha product. Yamaha sells its products through a network of reputable, specially authorized dealers and is pleased to offer you, the Original Owner, the following Limited Warranty, which applies only to products that have been (1) directly purchased from Yamaha's authorized dealers in the fifty states of the USA and District of Columbia (the "Warranted Area") and (2) used exclusively in the Warranted Area. Yamaha suggests that you read the Limited Warranty thoroughly and invites you to contact your authorized Yamaha dealer or Yamaha Customer Service if you have any questions.

Coverage: Yamaha will, at its option, repair or replace the product covered by this warranty if it becomes defective, malfunctions or otherwise fails to conform with this warranty under normal use and service during the term of this warranty, without charge for labor or materials. Repairs may be performed using new or refurbished parts that meet or exceed Yamaha specifications for new parts. If Yamaha elects to replace the product, the replacement may be a reconditioned unit. You will be responsible for any installation or removal charges and for any initial shipping charges if the product(s) must be shipped for warranty service. However, Yamaha will pay the return shipping charges to any destination within the USA if the repairs are covered by the warranty. This warranty does not cover (a) damage, deterioration or malfunction resulting from accident, negligence, misuse, abuse, improper installation or operation or failure to follow instructions according to the Owner's Manual for this product; any shipment of the product (claims must be presented to the carrier); repair or attempted repair by anyone other than Yamaha or an authorized Yamaha Service Center; (b) any unit which has been altered or on which the serial number has been defaced, modified or removed; (c) normal wear and any periodic maintenance; (d) deterioration due to perspiration, corrosive atmosphere or other external causes such as extremes in temperature or humidity; (e) damages attributable to power line surge or related electrical abnormalities, lightning damage or acts of God; or (f) RFI/EMI (Interference/noise) caused by improper grounding or the improper use of either certified or uncertified equipment, if applicable. Any evidence of alteration, erasing or forgery of proof-of-purchase documents will cause this warranty to be void. This warranty covers only the Original Owner and is not transferable.

In Order to Obtain Warranty Service: Warranty service will only be provided for defective products within the Warranted Area. Contact your local authorized Yamaha dealer who will advise you of the procedures to be followed. If this is not successful, contact Yamaha at the address, telephone number or website shown below. Yamaha may request that you send the defective product to a local authorized Yamaha Servicer or authorize return of the defective product to Yamaha for repair. If you are uncertain as to whether a dealer has been authorized by Yamaha, please contact Yamaha's Service Department at the number shown below, or check Yamaha's website at www.Yamaha.com. Product(s) shipped for service should be packed securely and must be accompanied by a detailed explanation of the problem(s) requiring service, together with the original or a machine reproduction of the bill of sale or other dated, proof-of-purchase document describing the product, as evidence of warranty coverage. Should any product submitted for warranty service be found ineligible therefore, an estimate of repair cost will be furnished and the repair will be accomplished only if requested by you and upon receipt of payment or acceptable arrangement for payment.

Limitation of Implied Warranties and Exclusion of Damages: ANY IMPLIED WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE SHALL BE LIMITED IN DURATION TO THE APPLICABLE PERIOD OF TIME SET FORTH ABOVE. YAMAHA SHALL NOT BE RESPONSIBLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES OR FOR DAMAGES BASED UPON INCONVENIENCE, LOSS OF USE, DAMAGE TO ANY OTHER EQUIPMENT OR OTHER ITEMS AT THE SITE OF USE OR INTERRUPTION OF PERFORMANCES OR ANY CONSEQUENCES. YAMAHA'S LIABILITY FOR ANY DEFECTIVE PRODUCT IS LIMITED TO REPAIR OR REPLACEMENT OF THE PRODUCT, AT YAMAHA'S OPTION. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS OR THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU. This Warranty gives you specific legal rights, and you may also have other rights which vary from state to state. This is the only express warranty applicable to the product specified herein; Yamaha neither assumes nor authorizes anyone to assume for it any other express warranty.

If you have any questions about service received or if you need assistance in locating an authorized Yamaha Servicer, please contact:



CUSTOMER SERVICE
Yamaha Corporation of America
6600 Orangethorpe Avenue, Buena Park, California 90620-1373
Telephone: 800-854-1569
www.yamaha.com

Do not return any product to the above address without a written Return Authorization issued by YAMAHA.

Important Notice: Guarantee Informatic Area (EEA) and Switzerland

<p>Important Notice: Guarantee Information for customers in EEA* and Switzerland For detailed guarantee information about this Yamaha product, and Pan-EEA* and Switzerland, warranty service, please either visit the website address below (Printable file is available at our website) or contact the Yamaha representative office for your country. * EEA: European Economic Area</p>	<p>English</p>
<p>Wichtiger Hinweis: Garantie-Information für Kunden in der EWR* und der Schweiz Für nähere Garantie-Information über dieses Produkt (von Yamaha, sowie über den Pan-EMR* und Schweizer Garantien Service, besuchen Sie bitte entweder die folgende angegebene Internetadresse (eine druckfähige Version befindet sich auch auf unserer Website), oder wenden Sie sich an den für Ihr Land zuständigen Yamaha-Vertrieb. *EWR: Europäischer Wirtschaftsraum</p>	<p>Deutsch</p>
<p>Remarque importante: Informations de garantie pour les clients de l'EEE et la Suisse Pour des informations plus détaillées sur la garantie de ce produit Yamaha et sur le service de garantie applicable dans l'ensemble de l'EEE ainsi qu'en Suisse, consultez notre site Web à l'adresse ci-dessous (le fichier imprimable est disponible sur notre site Web) ou contactez directement l'adresse ci-dessous de notre pays. * EEE: Espace Economique Européen</p>	<p>Français</p>
<p>Belangrijke mededeling: Garantie-informatie voor klanten in de EER* en Zwitserland Voor gedetailleerde garantie-informatie over dit Yamaha-product en de garantienetwerk in heel de EER* en Zwitserland, gaat u naar de onderstaande website (u vindt een afdrukbare versie op onze website) of neemt u contact op met de vertegenwoordiging van Yamaha in uw land. * EER: Europees Economisch Ruimte</p>	<p>Nederlands</p>
<p>Aviso importante: información sobre la garantía para los clientes del EEE* y Suiza Para una información detallada sobre este producto Yamaha y sobre el soporte de garantía en la zona EEE* y Suiza, visite la dirección web que se incluye más abajo (la versión del archivo para imprimir está disponible en nuestro sitio web) o póngase en contacto con el representante de Yamaha en su país. * EEE: Espacio Económico Europeo</p>	<p>Español</p>
<p>Aviso importante: informazioni sulla garanzia per i clienti residenti nell'EEA* e in Svizzera Sui informazioni dettagliate sulle garanzie relative a questo prodotto Yamaha e l'assistenza in garanzia nel paese EEA*, le in Svizzera, visitate il sito web che è incluso di seguito (la versione del file in formato stampabile) oppure contattate l'ufficio di rappresentanza locale della Yamaha. * EEA: Area Economica Europea</p>	<p>Italiano</p>
<p>Aviso importante: informações sobre as garantias para clientes da AEE* e da Suíça Para obter uma informação pormenorizada sobre este produto da Yamaha e sobre o serviço de garantia na AEE* e na Suíça, visite o site a seguir (o arquivo para impressão está disponível no nosso site) ou entre em contato com o escritório de representação da Yamaha no seu país. * AEE: Área Económica Europeia</p>	<p>Português</p>
<p>Σημαντική σημείωση: Πληροφορίες εγγύησης για τους πελάτες στον ΕΟΧ* και Ελβετία Για λεπτομέρειες πληροφοριών εγγύησης σχετικά με το προϊόν Yamaha και την κάλυψη εγγύησης σε όλες τις χώρες του ΕΟΧ και την Ελβετία, επισκεφτείτε την τοποθεσία ιστοσελίδας (Εκτυπωτικό αρχείο είναι διαθέσιμο στην ιστοσελίδα μας) ή επικοινωνήστε είτε απευθείας με το γραφείο μας, *ΕΟΧ: Ευρωπαϊκό Οικονομικό Χώρος</p>	<p>Ελληνικά</p>
<p>Viktig: Garantiinformasjon for kunder i EES-området* och Schweiz För detaljerad information om detta Yamaha-produktet och garantinätverket i hela EES-området* och Schweiz, kan du antingen besöka nedanstående webbadress (en utskriftsfärdig fil finns på webbplatsen) eller kontakta Yamahas officiella representant i ditt land. * EES: Europeiska Ekonomiska Samarbetsområdet</p>	<p>Svenska</p>
<p>Viktig merknad: Garantiinformasjon for kunder i EØS* og Sveits Detaljeret garantiinformasjon om dette Yamaha-produktet og garantienetverket i hele EØS-området* og Sveits, kan fås enten ved å besøke nettstedene nedenfor (utskriftsferdig fil finnes på våre nettsider) eller kontakte Yamahas-kontorene i landet der du bor. *EØS: Det europeiske økonomiske samarbeidsområdet</p>	<p>Norsk</p>
<p>Viktig oplysning: Garantioplysninger til kunder i EØO* og Schweiz De kan finne detaljerte garantioplysninger om dette Yamaha-produkt og den tilfelles garantiensnettverk for EØO* (og Sveits) ved å besøke de webbsider, der er angitt nedenfor (der finnes en fil, som kan utskrives, på vores webste), eller ved å kontakte Yamahas nationale representasjonskontor i det land, hvor De bor. * EØO: Det Europæiske Økonomiske Område</p>	<p>Dansk</p>

<p>Tärkeä tieto: Tähtitiedot Euroopan talousalueen (ETA*) ja Sveitsin asiakkaille Tämän Yamaha-tuotteen osalta ETA-talueen ja Sveitsin takuuta koskevat yksityiskohtaiset tiedot saatte alla olevasta nettiosoitteesta. (Uusittuversio tiedostona sivustollamme.) Voitte myös ottaa yhteyttä paikalliseen Yamaha-edustajaan. ETA: Euroopan talousalue</p>	<p>Suomi</p>
<p>Ważne wiadomości: Informacje o gwarancjach w krajach EOG* i Szwajcarii Ważne wiadomości, w których są temat, warunki gwarancji, tego produktu, firmy Yamaha i usługi gwarancyjne w całym EOG* i Szwajcarii, należy odwiedzić wskazaną poniżej stronę internetową (plik gotowy do wydruku znajduje się na naszej stronie internetowej) lub skontaktować się z przedstawicielstwem firmy Yamaha w swoim kraju. * EOG — Europejski Obszar Gospodarczy</p>	<p>Polski</p>
<p>Důležité oznámení: Záruční informace pro zákazníky v EHS* a ve Švýcarsku Podrobné záruční informace o tomto produktu Yamaha a záručním servisu v celém EHS* a ve Švýcarsku naleznete na níže uvedené webové adrese (souhrn k tisku je dostupný na našich webových stránkách) nebo se můžete obrátit na zastoupení firmy Yamaha ve své zemi. * EHS: Evropský hospodářský prostor</p>	<p>Česky</p>
<p>Fotos fogylémezteszt: Garancia-információk az EGT* területén és Svájcban élő vásárlók számára A jelen Yamaha termékre vonatkozó részletes garancia-információk, valamint az EGT*-re és Svájcra kiterjedő garanciális szolgáltatás leírésének kérelmére az alábbi címre (a nyomtatandó fájlt is talál), vagy pedig feljebb részletesen az országában működő Yamaha képviselői oldalán. * EGT: Európai Gazdasági Terület</p>	<p>Magyar</p>
<p>Ölülme keel Täpsembe teabe saamiseks saate Yamaha toote garantii ning kogu Euroopa Majanduspiirkonda ja Sveitsi garantienetivõtkohta küsida meie veebisiti, alljärgnevat aadressi (meie saidil on saadaval printida fail) või pöörduda Teile regiooni Yamaha esinduse poole. * EMP: Euroopa Majanduspiirkond</p>	<p>Eesti keel</p>
<p>Latvieshu Lai saņemtu detaļāku garantijas informāciju par šo Yamaha produktu, kā arī garantijas aplikāšanu EEE* un Šveicā, lūdzam apmeklētājiet zemāk norādīto tīmekļa vietnes adresi (tīmekļa vietnē ir pieejams drukājams fails) vai sazināties ar Jūsu valstī aplikāšanu Yamaha pārstāvētību. * EEE: Eiropas Ekonomikas zona</p>	<p>Latvieshu</p>
<p>Latvianu kalba Ja reikia išsames informacijos apie šį „Yamaha“ produktą ir jo techninę priežiūrą visoje EEE* ir Šveicarijoje, apsilankykite mūsų svetainėje (spausdinamą failą rasite adresu, pateiktame žemiau) arba kreipkitės į „Yamaha“ atstovų sąrašą šaliai. * EEE – Europos ekonomikos zona</p>	<p>Lietuvių kalba</p>
<p>Slovenčina Podrobne informácie o záruke týkajúcej sa tohto produktu od spoločnosti Yamaha a garancijnom servise v EHP* a Švajčiarsku nájdete na webovej stránke uvedenej nižšie (na našej webovej stránke je k dispozícii súbor na tlač) alebo sa obráťte na zástupcu spoločnosti Yamaha vo svojej krajine. * EHP: Európsky hospodársky priestor</p>	<p>Slovenčina</p>
<p>Slovensčina Za podrobnije informacije o temi Yamahinemu izdelku ter garancijskem servisu v celotnem EGP in Švici, obiščite spletno mesto, ki je navedeno spodaj (natisljiva datoteka je na voljo na našem spletnem mestu), ali se obrnite na Yamahinega predstavnika v svoji državi. * EGP: Evropski gospodarski prostor</p>	<p>Slovensčina</p>
<p>Важно съобщение: Информация за гаранцията за купувачи в ЕИП* и Швейцария За подробни данни за гаранцията за това произведение Yamaha и за условията на гаранцията в цялото ЕИП* и Швейцария, посетете адресния сайт, който е посочен по-долу (вече готов за принтиране) или се свържете с местния представител на фирма Yamaha във вашата страна. * ЕИП: Европейско икономическо пространство</p>	<p>Български език</p>
<p>Notificare importantă: Informații despre garanție pentru clienții din SEE* și Elveția Pentru informații detaliate privind acest produs Yamaha și serviciul de garanție Pan-SEE*, și Elveția, vizitați site-ul la adresa de mai jos (fișierul imprimabil este disponibil pe site-ul nostru) sau contactați biroul reprezentanței Yamaha din țara dumneavoastră. * SEE: Spațiul Economic European</p>	<p>Limba română</p>
<p>Vážna obavěstí: Informace o jarnstvu za države EGP-a i Švýcarska Za podrobnější informace o tomto Yamahiném výrobku ter garancijném servisu v celotném EGP in Švici, obiščite spletno mesto, ki je navedeno spodaj (natisljiva datoteka je na voljo na našem spletnem mestu), ali se obrnite na Yamahinega predstavnika v svoji državi. * EGP: Evropski gospodarski prostor</p>	<p>hrvatski</p>

<https://europe.yamaha.com/warranty/>

For details of products, please contact your nearest Yamaha representative or the authorized distributor listed below.

NORTH AMERICA

CANADA

Yamaha Canada Music Ltd.
135 Milner Avenue, Toronto, Ontario M1S 3R1,
Canada
Tel: +1-416-298-1311

U.S.A.

Yamaha Corporation of America
6600 Orangefhorpe Avenue, Buena Park, CA 90620,
U.S.A.
Tel: +1-714-522-9011

CENTRAL & SOUTH AMERICA

MEXICO

Yamaha de México, S.A. de C.V.
Av. Insurgentes Sur 1647 Piso 9, Col. San José
Insurgentes, Delegación Benito Juárez, México,
D.F., C.P. 03900, México
Tel: +52-55-5804-0600

BRAZIL

Yamaha Musical do Brasil Ltda.
Praça Professor José Lannes, 40, Cjs 2 e 22, Brooklin
Paulista Novo CEP 04571-100 - São Paulo - SP,
Brazil
Tel: +55-11-3704-1377

ARGENTINA

**Yamaha Music Latin America, S.A.,
Sucursal Argentina**
Olga Cossetini 1553, Piso 4 Norte,
Madero Este-C1107CEK,
Buenos Aires, Argentina
Tel: +54-11-4119-7000

PANAMA AND OTHER LATIN AMERICAN REGIONS/ CARIBBEAN REGIONS

Yamaha Music Latin America, S.A.
Edificio Torre Davidiviana, Piso: 20
Avenida Balboa, Marbella, Corregimiento de Bella
Vista, Ciudad de Panamá, Rep. de Panamá
Tel: +507-269-5311

EUROPE

THE UNITED KINGDOM/IRELAND

Yamaha Music Europe GmbH (UK)
Sherbourne Drive, Tilbrook, Milton Keynes,
MK7 8BL, U.K.
Tel: +44-1908-366700

GERMANY

Yamaha Music Europe GmbH
Siemensstrasse 22-34, 25462 Rellingen, Germany
Tel: +49-4101-303-0

SWITZERLAND/LIECHTENSTEIN

**Yamaha Music Europe GmbH, Branch
Switzerland in Thalwil**
Seestrasse 18a, 8800 Thalwil, Switzerland
Tel: +41-44-387800

AUSTRIA/CROATIA/CZECH REPUBLIC/ HUNGARY/ROMANIA/SLOVAKIA/ SLOVENIA

Yamaha Music Europe GmbH, Branch Austria
Schleiergasse 20, 1100 Wien, Austria
Tel: +43-1-60203900

POLAND

**Yamaha Music Europe
Sp.z o.o. Oddział w Polsce**
ul. Wielicka 52, 02-657 Warszawa, Poland
Tel: +48-22-880-08-88

BULGARIA

Dinacord Bulgaria LTD.
Bul. Ikskarsko Schose 7 Targowski Zentar Ewropa
1528 Sofia, Bulgaria
Tel: +359-2-978-20-25

MALTA

Olimpus Music Ltd.
Valletta Road, Mosta MST9010, Malta
Tel: +356-2133-2093

NETHERLANDS/BELGIUM/ LUXEMBOURG

Yamaha Music Europe, Branch Benelux
Clarisshenhof 5b, 4133 AB Vianen, The Netherlands
Tel: +31-347-358040

FRANCE

Yamaha Music Europe
7 rue Ambroise Croizat, Zone d'activités de Pariest,
77183 Croissy-Beaubourg, France
Tel: +33-1-6461-4000

ITALY

Yamaha Music Europe GmbH, Branch Italy
Via Tinelli N.67/69 20855 Gerno di Lesmo (MB),
Italy
Tel: +39-039-9065-1

SPAIN/PORTUGAL

**Yamaha Music Europe GmbH Ibérica, Sucursal
en España**
Ctra. de la Coruña km. 17,200, 28231
Las Rozas de Madrid, Spain
Tel: +34-91-639-88-88

GREECE

Philippos Nakas S.A. The Music House
19th km. Leof. Lavriou 190 02 Peania - Attiki,
Greece
Tel: +30-210-6686260

SWEDEN

**Yamaha Music Europe GmbH Germany filial
Scandinavia**
JA Wettergrensgata 1, 400 43 Göteborg, Sweden
Tel: +46-31-89-34-00

DENMARK

**Yamaha Music Denmark,
Filial of Yamaha Music Europe GmbH, Tyskland**
Generatorvej 8C, ST. TH., 2860 Soborg, Denmark
Tel: +45-44-92-49-00

FINLAND

F-Musiikki Oy
Antskentie 4
FI-01510 Vantaa, Finland
Tel: +358 0-96185111

NORWAY

**Yamaha Music Europe GmbH Germany -
Norwegian Branch**
Grini Næringspark 1, 1332 Osterås, Norway
Tel: +47-6716-7800

ICELAND

Hjodfaerahusid Ehf.
Sidulma 20
IS-108 Reykjavik, Iceland
Tel: +46-34-525-5050

CYPRUS

Nakas Music Cyprus Ltd.
Nikis Ave 2k
1086 Nicosia
Tel: +357-22-511080
Major Music Center
21 Ali Riza Ave. Ortakoy
P.O.Box 475 Lefkoşa, Cyprus
Tel: (392) 227 9213

RUSSIA

Yamaha Music (Russia) LLC.
Room 37, entrance 7, bld. 7, Kievskaya street,
Moscow, 121059, Russia
Tel: +7-495-626-5005

OTHER EUROPEAN REGIONS

Yamaha Music Europe GmbH
Siemensstrasse 22-34, 25462 Rellingen, Germany
Tel: +49-4101-303-0

AFRICA

Yamaha Music Gulf FZE
JAFZA-16, Office 512, P.O.Box 17328,
Jebel Ali FZE, Dubai, UAE
Tel: +971-4-801-1500

MIDDLE EAST

TURKEY

**Yamaha Music Europe GmbH
Merkez Alimanya Türkiye Istanbul Subesi**
Mor Sumbul Sokak Varyap Meridian Business
1.Blok No:1 113-114-115
Bati Atasehir Istanbul, Turkey
Tel: +90-216-275-7960

ISRAEL

RBX International Co., Ltd.
P.O.Box 10245, Petach-Tikva, 49002
Tel: (972) 3-925-6900

OTHER REGIONS

Yamaha Music Gulf FZE
JAFZA-16, Office 512, P.O.Box 17328,
Jebel Ali FZE, Dubai, UAE
Tel: +971-4-801-1500

ASIA

THE PEOPLE'S REPUBLIC OF CHINA

Yamaha Music & Electronics (China) Co., Ltd.
2F, Yunhedasha, 1818 Xinzha-lu, Jingan-qu,
Shanghai, China
Tel: +86-400-051-7700

HONG KONG

Tom Lee Music Co., Ltd.
11/F, Silvercord Tower 1, 30 Canton Road,
Tsimshatsui, Kowloon, Hong Kong
Tel: +852-2737-7688

INDIA

Yamaha Music India Private Limited
P-401, JMD Megapolis, Sector-48, Sohna Road,
Gurgaon-122018, Haryana, India
Tel: +91-124-485-3300

INDONESIA

PT. Yamaha Musik Indonesia (Distributor)
Yamaha Music Center Bldg. Jalan Jend. Gatot
Subroto Kav. 4, Jakarta 12930, Indonesia
Tel: +62-21-520-2577

KOREA

Yamaha Music Korea Ltd.
11F, Prudential Tower, 298, Gangnam-daero,
Gangnam-gu, Seoul, 06253, Korea
Tel: +82-2-3467-3300

MALAYSIA

Yamaha Music (Malaysia) Sdn. Bhd.
No.8, Jalan Perbandaran, Kelana Jaya, 47061
Petaling Jaya, Selangor, Malaysia
Tel: +60-3-78030900

SINGAPORE

Yamaha Music (Asia) Private Limited
Block 202 Hougang Street 21, #02-00,
Singapore 530202, Singapore
Tel: +65-6740-9200

TAIWAN

Yamaha Music & Electronics Taiwan Co., Ltd.
2F., No.1, Yundang Rd., Banqiao Dist.,
New Taipei City 22063, Taiwan (R.O.C.)
Tel: +886-2-7741-8888

THAILAND

Siam Music Yamaha Co., Ltd.
3, 4, 15, 16th Fl., Siam Motors Building,
891/1 Rama 1 Road, Wangmai,
Pathumwan, Bangkok 10330, Thailand
Tel: +66-2215-2622

VIETNAM

Yamaha Music Vietnam Company Limited
15th Floor, Nam A Bank Tower, 201-203 Cach
Mang Thang Tam St., Ward 4, Dist.3,
Ho Chi Minh City, Vietnam
Tel: +84-28-3818-1122

OTHER ASIAN REGIONS

[https://asia-latinamerica-mea.yamaha.com/
index.html](https://asia-latinamerica-mea.yamaha.com/index.html)

OCEANIA

AUSTRALIA

Yamaha Music Australia Pty. Ltd.
Level 1, 80 Market Street, South Melbourne,
VIC 3205 Australia
Tel: +61-3-9693-5111

NEW ZEALAND

Music Works LTD
P.O.BOX 6246 Wellesley, Auckland 4680,
New Zealand
Tel: +64-9-634-0099

**REGIONS AND TRUST
TERRITORIES IN PACIFIC OCEAN**
[https://asia-latinamerica-mea.yamaha.com/
index.html](https://asia-latinamerica-mea.yamaha.com/index.html)

Yamaha Global Site
<https://www.yamaha.com/>
Yamaha Downloads
<https://download.yamaha.com/>

Manual Development Group
© 2020 Yamaha Corporation

Published 06/2020 POTY*.*-**A0

VDH6220