Quick Start Guide
TC-HELICON TALKBOX SYNTH

Style – Selects from the range of Talkbox and Synth sounds.

Guitar thru

Correction - Adjusts the amount of pitch correction.

MIC   OUT   POWER

TC HELICON

STYLE   CORRECTION   REVERB

CLUB

RM

OFF   100%   OFF   HALL

1. CLASSIC   5. SYNTH 1
2. MODERN   6. SYNTH 2
3. CLASSIC*   7. SYNTH 3
4. MODERN*   8. SYNTH 4

TONE

Reverb – Selects the type and amount of reverb effect.

Guitar input

Tone – Engages 'Adaptive Tone' for EQ, compression, de-essing and gating. Hold the Tone knob while turning the Correction knob to adjust the level of the current Talkbox or Synth effect.

Footswitch – Bypass the Talkbox/Synth effect with a single press. Hold the Tone button while powering on to allow the footswitch to operate in momentary mode.

USB – Accepts micro-USB cables for firmware updates.

OUT   MIC

ON   OFF

On/Off

Out – Connect to a mixer or powered speaker.

Mic – Connect your microphone.

Power – Connect a 9V / >300 mA power supply, such as the PowerPlug 9 (not included). The pedal also accepts 4 x AA batteries.

Visit tc-helicon.com to download the full manual

TC HELICON