








1





2



WH-XB700






Android™ iPhone





3






Android/iPhone



Android



http://rd1.sony.net/help/mdr/whxb700/h_zz/

