

DMX CHART



www.chauvetprofessional.com

Color Macro Chart

DMX Channel Value	Red Value	Green Value	Blue Value	Amber Value	White Value
000 ⇄ 010	0				
011 ⇄ 034	100%	0-100%	0	0	0
035 ⇄ 059	100%-0	100%	0		
060 ⇄ 084	0	100%	0-100%		
085 ⇄ 109	0	100%-0	100%		
110 ⇄ 134	0-100%	0	100%		
135 ⇄ 159	100%	0	100%-0		
160 ⇄ 184	100%	0-100%	0-100%		
185 ⇄ 209	100%-0	100%-0	100%		
210 ⇄ 255	100%	100%	100%	100%	100%

Color Temperature Chart

DMX Channel Value	Display Readout
000 ⇄ 010	--
011 ⇄ 028	1800K
029 ⇄ 046	2200K
047 ⇄ 064	2700K
065 ⇄ 082	3000K
083 ⇄ 100	3200K
101 ⇄ 118	3500K
119 ⇄ 136	4000K
137 ⇄ 154	4200K
155 ⇄ 172	4500K
173 ⇄ 190	5600K
191 ⇄ 208	6000K
209 ⇄ 226	6500K
227 ⇄ 244	7200K
245 ⇄ 255	8000K



Note: The color temperatures above are simulated renditions of the color output produced as compared to a tungsten lamp at the specified color temperature. Chauvet makes no guarantee of the color output accuracy.

DMX Values

12-Cell Personalities

12-Cell RGBAW FULL 160 CH

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇄ 255	0-100%
2	Dimmer Fine	000 ⇄ 255	0-100%
3	Red 1	000 ⇄ 255	0-100%
4	Red Fine 1	000 ⇄ 255	0-100%
5	Green 1	000 ⇄ 255	0-100%
6	Green Fine 1	000 ⇄ 255	0-100%
7	Blue 1	000 ⇄ 255	0-100%
8	Blue Fine 1	000 ⇄ 255	0-100%
9	Amber 1	000 ⇄ 255	0-100%
10	Amber Fine 1	000 ⇄ 255	0-100%
11	White 1	000 ⇄ 255	0-100%
12	White Fine 1	000 ⇄ 255	0-100%
13	Color Macros 1	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
14	Color Temperature 1	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values

Channel	Function	Value	Percent/Setting
15	Strobe 1	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
16	Red 2	000 ⇄ 255	0–100%
17	Red Fine 2	000 ⇄ 255	0–100%
18	Green 2	000 ⇄ 255	0–100%
19	Green Fine 2	000 ⇄ 255	0–100%
20	Blue 2	000 ⇄ 255	0–100%
21	Blue Fine 2	000 ⇄ 255	0–100%
22	Amber 2	000 ⇄ 255	0–100%
23	Amber Fine 2	000 ⇄ 255	0–100%
24	White 2	000 ⇄ 255	0–100%
25	White Fine 2	000 ⇄ 255	0–100%
26	Color Macros 2	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
27	Color Temperature 2	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
28	Strobe 2	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
29	Red 3	000 ⇄ 255	0–100%
30	Red Fine 3	000 ⇄ 255	0–100%
31	Green 3	000 ⇄ 255	0–100%
32	Green Fine 3	000 ⇄ 255	0–100%
33	Blue 3	000 ⇄ 255	0–100%
34	Blue Fine 3	000 ⇄ 255	0–100%
35	Amber 3	000 ⇄ 255	0–100%
36	Amber Fine 3	000 ⇄ 255	0–100%
37	White 3	000 ⇄ 255	0–100%
38	White Fine 3	000 ⇄ 255	0–100%
39	Color Macros 3	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
40	Color Temperature 3	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
41	Strobe 3	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
42	Red 4	000 ⇄ 255	0–100%
43	Red Fine 4	000 ⇄ 255	0–100%
44	Green 4	000 ⇄ 255	0–100%
45	Green Fine 4	000 ⇄ 255	0–100%
46	Blue 4	000 ⇄ 255	0–100%
47	Blue Fine 4	000 ⇄ 255	0–100%
48	Amber 4	000 ⇄ 255	0–100%
49	Amber Fine 4	000 ⇄ 255	0–100%
50	White 4	000 ⇄ 255	0–100%
51	White Fine 4	000 ⇄ 255	0–100%
52	Color Macros 4	000 ⇄ 255	Refer to the Color Macro Chart section for specific values

DMX CHART



www.chauvetprofessional.com

Channel	Function	Value	Percent/Setting
53	Color Temperature 4	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
54	Strobe 4	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
55	Red 5	000 ⇄ 255	0–100%
56	Red Fine 5	000 ⇄ 255	0–100%
57	Green 5	000 ⇄ 255	0–100%
58	Green Fine 5	000 ⇄ 255	0–100%
59	Blue 5	000 ⇄ 255	0–100%
60	Blue Fine 5	000 ⇄ 255	0–100%
61	Amber 5	000 ⇄ 255	0–100%
62	Amber Fine 5	000 ⇄ 255	0–100%
63	White 5	000 ⇄ 255	0–100%
64	White Fine 5	000 ⇄ 255	0–100%
65	Color Macros 5	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
66	Color Temperature 5	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
67	Strobe 5	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
68	Red 6	000 ⇄ 255	0–100%
69	Red Fine 6	000 ⇄ 255	0–100%
70	Green 6	000 ⇄ 255	0–100%
71	Green Fine 6	000 ⇄ 255	0–100%
72	Blue 6	000 ⇄ 255	0–100%
73	Blue Fine 6	000 ⇄ 255	0–100%
74	Amber 6	000 ⇄ 255	0–100%
75	Amber Fine 6	000 ⇄ 255	0–100%
76	White 6	000 ⇄ 255	0–100%
77	White Fine 6	000 ⇄ 255	0–100%
78	Color Macros 6	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
79	Color Temperature 6	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
80	Strobe 6	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
81	Red 7	000 ⇄ 255	0–100%
82	Red Fine 7	000 ⇄ 255	0–100%
83	Green 7	000 ⇄ 255	0–100%
84	Green Fine 7	000 ⇄ 255	0–100%
85	Blue 7	000 ⇄ 255	0–100%
86	Blue Fine 7	000 ⇄ 255	0–100%
87	Amber 7	000 ⇄ 255	0–100%
88	Amber Fine 7	000 ⇄ 255	0–100%
89	White 7	000 ⇄ 255	0–100%
90	White Fine 7	000 ⇄ 255	0–100%

Channel	Function	Value	Percent/Setting
91	Color Macros 7	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
92	Color Temperature 7	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
93	Strobe 7	000 ⇄ 009 010 ⇄ 099 100 ⇄ 109 110 ⇄ 179 180 ⇄ 189 190 ⇄ 255	No function Slow to fast No function Lighting effect, slow to fast No function Random
94	Red 8	000 ⇄ 255	0–100%
95	Red Fine 8	000 ⇄ 255	0–100%
96	Green 8	000 ⇄ 255	0–100%
97	Green Fine 8	000 ⇄ 255	0–100%
98	Blue 8	000 ⇄ 255	0–100%
99	Blue Fine 8	000 ⇄ 255	0–100%
100	Amber 8	000 ⇄ 255	0–100%
101	Amber Fine 8	000 ⇄ 255	0–100%
102	White 8	000 ⇄ 255	0–100%
103	White Fine 8	000 ⇄ 255	0–100%
104	Color Macros 8	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
105	Color Temperature 8	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
106	Strobe 8	000 ⇄ 009 010 ⇄ 099 100 ⇄ 109 110 ⇄ 179 180 ⇄ 189 190 ⇄ 255	No function Slow to fast No function Lighting effect, slow to fast No function Random
107	Red 9	000 ⇄ 255	0–100%
108	Red Fine 9	000 ⇄ 255	0–100%
109	Green 9	000 ⇄ 255	0–100%
110	Green Fine 9	000 ⇄ 255	0–100%
111	Blue 9	000 ⇄ 255	0–100%
112	Blue Fine 9	000 ⇄ 255	0–100%
113	Amber 9	000 ⇄ 255	0–100%
114	Amber Fine 9	000 ⇄ 255	0–100%
115	White 9	000 ⇄ 255	0–100%
116	White Fine 9	000 ⇄ 255	0–100%
117	Color Macros 9	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
118	Color Temperature 9	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
119	Strobe 9	000 ⇄ 009 010 ⇄ 099 100 ⇄ 109 110 ⇄ 179 180 ⇄ 189 190 ⇄ 255	No function Slow to fast No function Lighting effect, slow to fast No function Random
120	Red 10	000 ⇄ 255	0–100%
121	Red Fine 10	000 ⇄ 255	0–100%
122	Green 10	000 ⇄ 255	0–100%
123	Green Fine 10	000 ⇄ 255	0–100%
124	Blue 10	000 ⇄ 255	0–100%
125	Blue Fine 10	000 ⇄ 255	0–100%
126	Amber 10	000 ⇄ 255	0–100%
127	Amber Fine 10	000 ⇄ 255	0–100%
128	White 10	000 ⇄ 255	0–100%

DMX CHART



www.chauvetprofessional.com

Channel	Function	Value	Percent/Setting
129	White Fine 10	000 ⇄ 255	0–100%
130	Color Macros 10	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
131	Color Temperature 10	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
132	Strobe 10	000 ⇄ 009 010 ⇄ 099 100 ⇄ 109 110 ⇄ 179 180 ⇄ 189 190 ⇄ 255	No function Slow to fast No function Lighting effect, slow to fast No function Random
133	Red 11	000 ⇄ 255	0–100%
134	Red Fine 11	000 ⇄ 255	0–100%
135	Green 11	000 ⇄ 255	0–100%
136	Green Fine 11	000 ⇄ 255	0–100%
137	Blue 11	000 ⇄ 255	0–100%
138	Blue Fine 11	000 ⇄ 255	0–100%
139	Amber 11	000 ⇄ 255	0–100%
140	Amber Fine 11	000 ⇄ 255	0–100%
141	White 11	000 ⇄ 255	0–100%
142	White Fine 11	000 ⇄ 255	0–100%
143	Color Macros 11	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
144	Color Temperature 11	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
145	Strobe 11	000 ⇄ 009 010 ⇄ 099 100 ⇄ 109 110 ⇄ 179 180 ⇄ 189 190 ⇄ 255	No function Slow to fast No function Lighting effect, slow to fast No function Random
146	Red 12	000 ⇄ 255	0–100%
147	Red Fine 12	000 ⇄ 255	0–100%
148	Green 12	000 ⇄ 255	0–100%
149	Green Fine 12	000 ⇄ 255	0–100%
150	Blue 12	000 ⇄ 255	0–100%
151	Blue Fine 12	000 ⇄ 255	0–100%
152	Amber 12	000 ⇄ 255	0–100%
153	Amber Fine 12	000 ⇄ 255	0–100%
154	White 12	000 ⇄ 255	0–100%
155	White Fine 12	000 ⇄ 255	0–100%
156	Color Macros 12	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
157	Color Temperature 12	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
158	Strobe 12	000 ⇄ 009 010 ⇄ 099 100 ⇄ 109 110 ⇄ 179 180 ⇄ 189 190 ⇄ 255	No function Slow to fast No function Lighting effect, slow to fast No function Random
159	Strobe All	000 ⇄ 009 010 ⇄ 099 100 ⇄ 109 110 ⇄ 179 180 ⇄ 189 190 ⇄ 255	No function Slow to fast No function Lighting effect, slow to fast No function Random

Channel	Function	Value	Percent/Setting
160	Dimmer Speed	000 ⇄ 051	Preset dimmer speed from display menu
		052 ⇄ 101	Dimmer speed mode off
		102 ⇄ 152	Dimmer speed mode 1 (fastest)
		153 ⇄ 203	Dimmer speed mode 2
		204 ⇄ 255	Dimmer speed mode 3 (slowest)

12-Cell RGBAW Fine 120 CH

Channel	Function	Value	Percent/Setting
1	Red 1	000 ⇄ 255	0–100%
2	Red Fine 1	000 ⇄ 255	0–100%
3	Green 1	000 ⇄ 255	0–100%
4	Green Fine 1	000 ⇄ 255	0–100%
5	Blue 1	000 ⇄ 255	0–100%
6	Blue Fine 1	000 ⇄ 255	0–100%
7	Amber 1	000 ⇄ 255	0–100%
8	Amber Fine 1	000 ⇄ 255	0–100%
9	White 1	000 ⇄ 255	0–100%
10	White Fine 1	000 ⇄ 255	0–100%
11	Red 2	000 ⇄ 255	0–100%
12	Red Fine 2	000 ⇄ 255	0–100%
13	Green 2	000 ⇄ 255	0–100%
14	Green Fine 2	000 ⇄ 255	0–100%
15	Blue 2	000 ⇄ 255	0–100%
16	Blue Fine 2	000 ⇄ 255	0–100%
17	Amber 2	000 ⇄ 255	0–100%
18	Amber Fine 2	000 ⇄ 255	0–100%
19	White 2	000 ⇄ 255	0–100%
20	White Fine 2	000 ⇄ 255	0–100%
21	Red 3	000 ⇄ 255	0–100%
22	Red Fine 3	000 ⇄ 255	0–100%
23	Green 3	000 ⇄ 255	0–100%
24	Green Fine 3	000 ⇄ 255	0–100%
25	Blue 3	000 ⇄ 255	0–100%
26	Blue Fine 3	000 ⇄ 255	0–100%
27	Amber 3	000 ⇄ 255	0–100%
28	Amber Fine 3	000 ⇄ 255	0–100%
29	White 3	000 ⇄ 255	0–100%
30	White Fine 3	000 ⇄ 255	0–100%
31	Red 4	000 ⇄ 255	0–100%
32	Red Fine 4	000 ⇄ 255	0–100%
33	Green 4	000 ⇄ 255	0–100%
34	Green Fine 4	000 ⇄ 255	0–100%
35	Blue 4	000 ⇄ 255	0–100%
36	Blue Fine 4	000 ⇄ 255	0–100%
37	Amber 4	000 ⇄ 255	0–100%
38	Amber Fine 4	000 ⇄ 255	0–100%
39	White 4	000 ⇄ 255	0–100%
40	White Fine 4	000 ⇄ 255	0–100%
41	Red 5	000 ⇄ 255	0–100%
42	Red Fine 5	000 ⇄ 255	0–100%
43	Green 5	000 ⇄ 255	0–100%
44	Green Fine 5	000 ⇄ 255	0–100%
45	Blue 5	000 ⇄ 255	0–100%
46	Blue Fine 5	000 ⇄ 255	0–100%
47	Amber 5	000 ⇄ 255	0–100%

DMX CHART



www.chauvetprofessional.com

Channel	Function	Value	Percent/Setting
48	Amber Fine 5	000 ⇄ 255	0–100%
49	White 5	000 ⇄ 255	0–100%
50	White Fine 5	000 ⇄ 255	0–100%
51	Red 6	000 ⇄ 255	0–100%
52	Red Fine 6	000 ⇄ 255	0–100%
53	Green 6	000 ⇄ 255	0–100%
54	Green Fine 6	000 ⇄ 255	0–100%
55	Blue 6	000 ⇄ 255	0–100%
56	Blue Fine 6	000 ⇄ 255	0–100%
57	Amber 6	000 ⇄ 255	0–100%
58	Amber Fine 6	000 ⇄ 255	0–100%
59	White 6	000 ⇄ 255	0–100%
60	White Fine 6	000 ⇄ 255	0–100%
61	Red 7	000 ⇄ 255	0–100%
62	Red Fine 7	000 ⇄ 255	0–100%
63	Green 7	000 ⇄ 255	0–100%
64	Green Fine 7	000 ⇄ 255	0–100%
65	Blue 7	000 ⇄ 255	0–100%
66	Blue Fine 7	000 ⇄ 255	0–100%
67	Amber 7	000 ⇄ 255	0–100%
68	Amber Fine 7	000 ⇄ 255	0–100%
69	White 7	000 ⇄ 255	0–100%
70	White Fine 7	000 ⇄ 255	0–100%
71	Red 8	000 ⇄ 255	0–100%
72	Red Fine 8	000 ⇄ 255	0–100%
73	Green 8	000 ⇄ 255	0–100%
74	Green Fine 8	000 ⇄ 255	0–100%
75	Blue 8	000 ⇄ 255	0–100%
76	Blue Fine 8	000 ⇄ 255	0–100%
77	Amber 8	000 ⇄ 255	0–100%
78	Amber Fine 8	000 ⇄ 255	0–100%
79	White 8	000 ⇄ 255	0–100%
80	White Fine 8	000 ⇄ 255	0–100%
81	Red 9	000 ⇄ 255	0–100%
82	Red Fine 9	000 ⇄ 255	0–100%
83	Green 9	000 ⇄ 255	0–100%
84	Green Fine 9	000 ⇄ 255	0–100%
85	Blue 9	000 ⇄ 255	0–100%
86	Blue Fine 9	000 ⇄ 255	0–100%
87	Amber 9	000 ⇄ 255	0–100%
88	Amber Fine 9	000 ⇄ 255	0–100%
89	White 9	000 ⇄ 255	0–100%
90	White Fine 9	000 ⇄ 255	0–100%
91	Red 10	000 ⇄ 255	0–100%
92	Red Fine 10	000 ⇄ 255	0–100%
93	Green 10	000 ⇄ 255	0–100%
94	Green Fine 10	000 ⇄ 255	0–100%
95	Blue 10	000 ⇄ 255	0–100%
96	Blue Fine 10	000 ⇄ 255	0–100%
97	Amber 10	000 ⇄ 255	0–100%
98	Amber Fine 10	000 ⇄ 255	0–100%
99	White 10	000 ⇄ 255	0–100%
100	White Fine 10	000 ⇄ 255	0–100%
101	Red 11	000 ⇄ 255	0–100%
102	Red Fine 11	000 ⇄ 255	0–100%

Channel	Function	Value	Percent/Setting
103	Green 11	000 ⇄ 255	0–100%
104	Green Fine 11	000 ⇄ 255	0–100%
105	Blue 11	000 ⇄ 255	0–100%
106	Blue Fine 11	000 ⇄ 255	0–100%
107	Amber 11	000 ⇄ 255	0–100%
108	Amber Fine 11	000 ⇄ 255	0–100%
109	White 11	000 ⇄ 255	0–100%
110	White Fine 11	000 ⇄ 255	0–100%
111	Red 12	000 ⇄ 255	0–100%
112	Red Fine 12	000 ⇄ 255	0–100%
113	Green 12	000 ⇄ 255	0–100%
114	Green Fine 12	000 ⇄ 255	0–100%
115	Blue 12	000 ⇄ 255	0–100%
116	Blue Fine 12	000 ⇄ 255	0–100%
117	Amber 12	000 ⇄ 255	0–100%
118	Amber Fine 12	000 ⇄ 255	0–100%
119	White 12	000 ⇄ 255	0–100%
120	White Fine 12	000 ⇄ 255	0–100%

12-Cell RGBAW EXT 99 CH

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇄ 255	0–100%
2	Dimmer Fine	000 ⇄ 255	0–100%
3	Red 1	000 ⇄ 255	0–100%
4	Green 1	000 ⇄ 255	0–100%
5	Blue 1	000 ⇄ 255	0–100%
6	Amber 1	000 ⇄ 255	0–100%
7	White 1	000 ⇄ 255	0–100%
8	Color Macros 1	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
9	Color Temperature 1	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
10	Strobe 1	000 ⇄ 009 010 ⇄ 099 100 ⇄ 109 110 ⇄ 179 180 ⇄ 189 190 ⇄ 255	No function Slow to fast No function Lighting effect, slow to fast No function Random
11	Red 2	000 ⇄ 255	0–100%
12	Green 2	000 ⇄ 255	0–100%
13	Blue 2	000 ⇄ 255	0–100%
14	Amber 2	000 ⇄ 255	0–100%
15	White 2	000 ⇄ 255	0–100%
16	Color Macros 2	000 ⇄ 010 011 ⇄ 209 210 ⇄ 255	No function Color Macro White
17	Color Temperature 2	000 ⇄ 009 010 ⇄ 099 100 ⇄ 109 110 ⇄ 179 180 ⇄ 189 190 ⇄ 255	No function Slow to fast No function Lighting effect, slow to fast No function Random
18	Strobe 2	000 ⇄ 009 010 ⇄ 099 100 ⇄ 109 110 ⇄ 179 180 ⇄ 189 190 ⇄ 255	No function Slow to fast No function Lighting effect, slow to fast No function Random

DMX CHART



www.chauvetprofessional.com

Channel	Function	Value	Percent/Setting
19	Red 3	000 ⇄ 255	0–100%
20	Green 3	000 ⇄ 255	0–100%
21	Blue 3	000 ⇄ 255	0–100%
22	Amber 3	000 ⇄ 255	0–100%
23	White 3	000 ⇄ 255	0–100%
24	Color Macros 3	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
25	Color Temperature 3	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
26	Strobe 3	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
27	Red 4	000 ⇄ 255	0–100%
28	Green 4	000 ⇄ 255	0–100%
29	Blue 4	000 ⇄ 255	0–100%
30	Amber 4	000 ⇄ 255	0–100%
31	White 4	000 ⇄ 255	0–100%
32	Color Macros 4	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
33	Color Temperature 4	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
34	Strobe 4	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
35	Red 5	000 ⇄ 255	0–100%
36	Green 5	000 ⇄ 255	0–100%
37	Blue 5	000 ⇄ 255	0–100%
38	Amber 5	000 ⇄ 255	0–100%
39	White 5	000 ⇄ 255	0–100%
40	Color Macros 5	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
41	Color Temperature 5	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
42	Strobe 5	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
43	Red 6	000 ⇄ 255	0–100%
44	Green 6	000 ⇄ 255	0–100%
45	Blue 6	000 ⇄ 255	0–100%
46	Amber 6	000 ⇄ 255	0–100%
47	White 6	000 ⇄ 255	0–100%
48	Color Macros 6	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
49	Color Temperature 6	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
50	Strobe 6	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random

Channel	Function	Value	Percent/Setting
51	Red 7	000 ⇄ 255	0–100%
52	Green 7	000 ⇄ 255	0–100%
53	Blue 7	000 ⇄ 255	0–100%
54	Amber 7	000 ⇄ 255	0–100%
55	White 7	000 ⇄ 255	0–100%
56	Color Macros 7	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
57	Color Temperature 7	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
58	Strobe 7	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
59	Red 8	000 ⇄ 255	0–100%
60	Green 8	000 ⇄ 255	0–100%
61	Blue 8	000 ⇄ 255	0–100%
62	Amber 8	000 ⇄ 255	0–100%
63	White 8	000 ⇄ 255	0–100%
64	Color Macros 8	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
65	Color Temperature 8	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
66	Strobe 8	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
67	Red 9	000 ⇄ 255	0–100%
68	Green 9	000 ⇄ 255	0–100%
69	Blue 9	000 ⇄ 255	0–100%
70	Amber 9	000 ⇄ 255	0–100%
71	White 9	000 ⇄ 255	0–100%
72	Color Macros 9	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
73	Color Temperature 9	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
74	Strobe 9	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
75	Red 10	000 ⇄ 255	0–100%
76	Green 10	000 ⇄ 255	0–100%
77	Blue 10	000 ⇄ 255	0–100%
78	Amber 10	000 ⇄ 255	0–100%
79	White 10	000 ⇄ 255	0–100%
80	Color Macros 10	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
81	Color Temperature 10	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
82	Strobe 10	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random

DMX CHART



www.chauvetprofessional.com

Channel	Function	Value	Percent/Setting
83	Red 11	000 ⇄ 255	0–100%
84	Green 11	000 ⇄ 255	0–100%
85	Blue 11	000 ⇄ 255	0–100%
86	Amber 11	000 ⇄ 255	0–100%
87	White 11	000 ⇄ 255	0–100%
88	Color Macros 11	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
89	Color Temperature 11	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
90	Strobe 11	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
91	Red 12	000 ⇄ 255	0–100%
92	Green 12	000 ⇄ 255	0–100%
93	Blue 12	000 ⇄ 255	0–100%
94	Amber 12	000 ⇄ 255	0–100%
95	White 12	000 ⇄ 255	0–100%
96	Color Macros 12	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
97	Color Temperature 12	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
98	Strobe 12	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
99	Strobe All	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random

12-Cell RGBA EXT 87 CH

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇄ 255	0–100%
2	Dimmer Fine	000 ⇄ 255	0–100%
3	Red 1	000 ⇄ 255	0–100%
4	Green 1	000 ⇄ 255	0–100%
5	Blue 1	000 ⇄ 255	0–100%
6	Amber 1	000 ⇄ 255	0–100%
7	Color Macros 1	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
8	Color Temperature 1	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
9	Strobe 1	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
10	Red 2	000 ⇄ 255	0–100%
11	Green 2	000 ⇄ 255	0–100%
12	Blue 2	000 ⇄ 255	0–100%
13	Amber 2	000 ⇄ 255	0–100%

Channel	Function	Value	Percent/Setting
14	Color Macros 2	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
15	Color Temperature 2	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
16	Strobe 2	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
17	Red 3	000 ⇄ 255	0–100%
18	Green 3	000 ⇄ 255	0–100%
19	Blue 3	000 ⇄ 255	0–100%
20	Amber 3	000 ⇄ 255	0–100%
21	Color Macros 3	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
22	Color Temperature 3	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
23	Strobe 3	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
24	Red 4	000 ⇄ 255	0–100%
25	Green 4	000 ⇄ 255	0–100%
26	Blue 4	000 ⇄ 255	0–100%
27	Amber 4	000 ⇄ 255	0–100%
28	Color Macros 4	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
29	Color Temperature 4	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
30	Strobe 4	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
31	Red 5	000 ⇄ 255	0–100%
32	Green 5	000 ⇄ 255	0–100%
33	Blue 5	000 ⇄ 255	0–100%
34	Amber 5	000 ⇄ 255	0–100%
35	Color Macros 5	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
36	Color Temperature 5	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
37	Strobe 5	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
38	Red 6	000 ⇄ 255	0–100%
39	Green 6	000 ⇄ 255	0–100%
40	Blue 6	000 ⇄ 255	0–100%
41	Amber 6	000 ⇄ 255	0–100%
42	Color Macros 6	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
43	Color Temperature 6	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values

DMX CHART



www.chauvetprofessional.com

Channel	Function	Value	Percent/Setting
44	Strobe 6	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
45	Red 7	000 ⇄ 255	0–100%
46	Green 7	000 ⇄ 255	0–100%
47	Blue 7	000 ⇄ 255	0–100%
48	Amber 7	000 ⇄ 255	0–100%
49	Color Macros 7	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
50	Color Temperature 7	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
51	Strobe 7	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
52	Red 8	000 ⇄ 255	0–100%
53	Green 8	000 ⇄ 255	0–100%
54	Blue 8	000 ⇄ 255	0–100%
55	Amber 8	000 ⇄ 255	0–100%
56	Color Macros 8	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
57	Color Temperature 8	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
58	Strobe 8	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
59	Red 9	000 ⇄ 255	0–100%
60	Green 9	000 ⇄ 255	0–100%
61	Blue 9	000 ⇄ 255	0–100%
62	Amber 9	000 ⇄ 255	0–100%
63	Color Macros 9	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
64	Color Temperature 9	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
65	Strobe 9	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
66	Red 10	000 ⇄ 255	0–100%
67	Green 10	000 ⇄ 255	0–100%
68	Blue 10	000 ⇄ 255	0–100%
69	Amber 10	000 ⇄ 255	0–100%
70	Color Macros 10	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
71	Color Temperature 10	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values

Channel	Function	Value	Percent/Setting
72	Strobe 10	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
73	Red 11	000 ⇄ 255	0–100%
74	Green 11	000 ⇄ 255	0–100%
75	Blue 11	000 ⇄ 255	0–100%
76	Amber 11	000 ⇄ 255	0–100%
77	Color Macros 12	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
78	Color Temperature 12	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
79	Strobe 12	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
80	Red 12	000 ⇄ 255	0–100%
81	Green 12	000 ⇄ 255	0–100%
82	Blue 12	000 ⇄ 255	0–100%
83	Amber 12	000 ⇄ 255	0–100%
84	Color Macros 12	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
85	Color Temperature 12	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
86	Strobe 12	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
87	Strobe All	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random

12-Cell HSIC 85 CH

Channel	Function	Value	Percent/Setting
1	Dimmer 1	000 ⇄ 255	0–100%
2	Hue 1	000 ⇄ 255	0–100%
3	Hue Fine 1	000 ⇄ 255	0–100%
4	Saturation 1	000 ⇄ 255	0–100%
5	Strobe 1	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
6	Color Macros 1	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
7	Color Temperature 1	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
8	Dimmer 2	000 ⇄ 255	0–100%
9	Hue 2	000 ⇄ 255	0–100%
10	Hue Fine 2	000 ⇄ 255	0–100%

DMX CHART



www.chauvetprofessional.com

Channel	Function	Value	Percent/Setting
11	Saturation 2	000 ⇄ 255	0–100%
12	Strobe 2	000 ⇄ 009 010 ⇄ 099 100 ⇄ 109 110 ⇄ 179 180 ⇄ 189 190 ⇄ 255	No function Slow to fast No function Lighting effect, slow to fast No function Random
13	Color Macros 2	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
14	Color Temperature 2	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
15	Dimmer 3	000 ⇄ 255	0–100%
16	Hue 3	000 ⇄ 255	0–100%
17	Hue Fine 3	000 ⇄ 255	0–100%
18	Saturation 3	000 ⇄ 255	0–100%
19	Strobe 3	000 ⇄ 009 010 ⇄ 099 100 ⇄ 109 110 ⇄ 179 180 ⇄ 189 190 ⇄ 255	No function Slow to fast No function Lighting effect, slow to fast No function Random
20	Color Macros 3	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
21	Color Temperature 3	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
22	Dimmer 4	000 ⇄ 255	0–100%
23	Hue 4	000 ⇄ 255	0–100%
24	Hue Fine 4	000 ⇄ 255	0–100%
25	Saturation 4	000 ⇄ 255	0–100%
26	Strobe 4	000 ⇄ 009 010 ⇄ 099 100 ⇄ 109 110 ⇄ 179 180 ⇄ 189 190 ⇄ 255	No function Slow to fast No function Lighting effect, slow to fast No function Random
27	Color Macros 4	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
28	Color Temperature 4	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
29	Dimmer 5	000 ⇄ 255	0–100%
30	Hue 5	000 ⇄ 255	0–100%
31	Hue Fine 5	000 ⇄ 255	0–100%
32	Saturation 5	000 ⇄ 255	0–100%
33	Strobe 5	000 ⇄ 009 010 ⇄ 099 100 ⇄ 109 110 ⇄ 179 180 ⇄ 189 190 ⇄ 255	No function Slow to fast No function Lighting effect, slow to fast No function Random
34	Color Macros 5	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
35	Color Temperature 5	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
36	Dimmer 6	000 ⇄ 255	0–100%
37	Hue 6	000 ⇄ 255	0–100%
38	Hue Fine 6	000 ⇄ 255	0–100%
39	Saturation 6	000 ⇄ 255	0–100%

Channel	Function	Value	Percent/Setting
40	Strobe 6	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
41	Color Macros 6	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
42	Color Temperature 6	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
43	Dimmer 7	000 ⇄ 255	0–100%
44	Hue 7	000 ⇄ 255	0–100%
45	Hue Fine 7	000 ⇄ 255	0–100%
46	Saturation 7	000 ⇄ 255	0–100%
47	Strobe 7	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
48	Color Macros 7	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
49	Color Temperature 7	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
50	Dimmer 8	000 ⇄ 255	0–100%
51	Hue 8	000 ⇄ 255	0–100%
52	Hue Fine 8	000 ⇄ 255	0–100%
53	Saturation 8	000 ⇄ 255	0–100%
54	Strobe 8	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
55	Color Macros 8	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
56	Color Temperature 8	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
57	Dimmer 9	000 ⇄ 255	0–100%
58	Hue 9	000 ⇄ 255	0–100%
59	Hue Fine 9	000 ⇄ 255	0–100%
60	Saturation 9	000 ⇄ 255	0–100%
61	Strobe 9	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
62	Color Macros 9	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
63	Color Temperature 9	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
64	Dimmer 10	000 ⇄ 255	0–100%
65	Hue 10	000 ⇄ 255	0–100%
66	Hue Fine 10	000 ⇄ 255	0–100%
67	Saturation 10	000 ⇄ 255	0–100%

DMX CHART



www.chauvetprofessional.com

Channel	Function	Value	Percent/Setting
68	Strobe 10	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
69	Color Macros 10	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
70	Color Temperature 10	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
71	Dimmer 11	000 ⇄ 255	0–100%
72	Hue 11	000 ⇄ 255	0–100%
73	Hue Fine 11	000 ⇄ 255	0–100%
74	Saturation 11	000 ⇄ 255	0–100%
75	Strobe 11	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
76	Color Macros 11	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
77	Color Temperature 11	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
78	Dimmer 12	000 ⇄ 255	0–100%
79	Hue 12	000 ⇄ 255	0–100%
80	Hue Fine 12	000 ⇄ 255	0–100%
81	Saturation 12	000 ⇄ 255	0–100%
82	Strobe 12	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
83	Color Macros 12	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
84	Color Temperature 12	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
85	Dimmer Speed	000 ⇄ 051	Preset dimmer speed from display menu
		052 ⇄ 101	Dimmer speed mode off
		102 ⇄ 152	Dimmer speed mode 1 (fastest)
		153 ⇄ 203	Dimmer speed mode 2
		204 ⇄ 255	Dimmer speed mode 3 (slowest)

12-Cell RGB EXT 75 CH

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇄ 255	0–100%
2	Dimmer Fine	000 ⇄ 255	0–100%
3	Red 1	000 ⇄ 255	0–100%
4	Green 1	000 ⇄ 255	0–100%
5	Blue 1	000 ⇄ 255	0–100%
6	Color Macros 1	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
7	Color Temperature 1	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values

Channel	Function	Value	Percent/Setting
8	Strobe 1	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
9	Red 2	000 ⇄ 255	0–100%
10	Green 2	000 ⇄ 255	0–100%
11	Blue 2	000 ⇄ 255	0–100%
12	Color Macros 2	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
13	Color Temperature 2	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
14	Strobe 2	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
15	Red 3	000 ⇄ 255	0–100%
16	Green 3	000 ⇄ 255	0–100%
17	Blue 3	000 ⇄ 255	0–100%
18	Color Macros 3	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
19	Color Temperature 3	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
20	Strobe 3	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
21	Red 4	000 ⇄ 255	0–100%
22	Green 4	000 ⇄ 255	0–100%
23	Blue 4	000 ⇄ 255	0–100%
24	Color Macros 4	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
25	Color Temperature 4	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
26	Strobe 4	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
27	Red 5	000 ⇄ 255	0–100%
28	Green 5	000 ⇄ 255	0–100%
29	Blue 5	000 ⇄ 255	0–100%
30	Color Macros 5	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
31	Color Temperature 5	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
32	Strobe 5	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
33	Red 6	000 ⇄ 255	0–100%
34	Green 6	000 ⇄ 255	0–100%
35	Blue 6	000 ⇄ 255	0–100%

DMX CHART



www.chauvetprofessional.com

Channel	Function	Value	Percent/Setting
36	Color Macros 6	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
37	Color Temperature 6	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
38	Strobe 6	000 ⇄ 009 010 ⇄ 099 100 ⇄ 109 110 ⇄ 179 180 ⇄ 189 190 ⇄ 255	No function Slow to fast No function Lighting effect, slow to fast No function Random
39	Red 7	000 ⇄ 255	0–100%
40	Green 7	000 ⇄ 255	0–100%
41	Blue 7	000 ⇄ 255	0–100%
42	Color Macros 7	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
43	Color Temperature 7	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
44	Strobe 7	000 ⇄ 009 010 ⇄ 099 100 ⇄ 109 110 ⇄ 179 180 ⇄ 189 190 ⇄ 255	No function Slow to fast No function Lighting effect, slow to fast No function Random
45	Red 8	000 ⇄ 255	0–100%
46	Green 8	000 ⇄ 255	0–100%
47	Blue 8	000 ⇄ 255	0–100%
48	Color Macros 8	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
49	Color Temperature 8	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
50	Strobe 8	000 ⇄ 009 010 ⇄ 099 100 ⇄ 109 110 ⇄ 179 180 ⇄ 189 190 ⇄ 255	No function Slow to fast No function Lighting effect, slow to fast No function Random
51	Red 9	000 ⇄ 255	0–100%
52	Green 9	000 ⇄ 255	0–100%
53	Blue 9	000 ⇄ 255	0–100%
54	Color Macros 9	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
55	Color Temperature 9	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
56	Strobe 9	000 ⇄ 009 010 ⇄ 099 100 ⇄ 109 110 ⇄ 179 180 ⇄ 189 190 ⇄ 255	No function Slow to fast No function Lighting effect, slow to fast No function Random
57	Red 10	000 ⇄ 255	0–100%
58	Green 10	000 ⇄ 255	0–100%
59	Blue 10	000 ⇄ 255	0–100%
60	Color Macros 10	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
61	Color Temperature 10	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values

Channel	Function	Value	Percent/Setting
62	Strobe 10	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
63	Red 11	000 ⇄ 255	0–100%
64	Green 11	000 ⇄ 255	0–100%
65	Blue 11	000 ⇄ 255	0–100%
66	Color Macros 12	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
67	Color Temperature 12	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
68	Strobe 12	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
69	Red 12	000 ⇄ 255	0–100%
70	Green 12	000 ⇄ 255	0–100%
71	Blue 12	000 ⇄ 255	0–100%
72	Color Macros 12	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
73	Color Temperature 12	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
74	Strobe 12	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
75	Strobe All	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random

12-Cell RGBAW 60 CH

Channel	Function	Value	Percent/Setting
1	Red 1	000 ⇄ 255	0–100%
2	Green 1	000 ⇄ 255	0–100%
3	Blue 1	000 ⇄ 255	0–100%
4	Amber 1	000 ⇄ 255	0–100%
5	White 1	000 ⇄ 255	0–100%
6	Red 2	000 ⇄ 255	0–100%
7	Green 2	000 ⇄ 255	0–100%
8	Blue 2	000 ⇄ 255	0–100%
9	Amber 2	000 ⇄ 255	0–100%
10	White 2	000 ⇄ 255	0–100%
11	Red 3	000 ⇄ 255	0–100%
12	Green 3	000 ⇄ 255	0–100%
13	Blue 3	000 ⇄ 255	0–100%
14	Amber 3	000 ⇄ 255	0–100%
15	White 3	000 ⇄ 255	0–100%
16	Red 4	000 ⇄ 255	0–100%
17	Green 4	000 ⇄ 255	0–100%

DMX CHART



www.chauvetprofessional.com

Channel	Function	Value	Percent/Setting
18	Blue 4	000 ⇄ 255	0–100%
19	Amber 4	000 ⇄ 255	0–100%
20	White 4	000 ⇄ 255	0–100%
21	Red 5	000 ⇄ 255	0–100%
22	Green 5	000 ⇄ 255	0–100%
23	Blue 5	000 ⇄ 255	0–100%
24	Amber 5	000 ⇄ 255	0–100%
25	White 5	000 ⇄ 255	0–100%
26	Red 6	000 ⇄ 255	0–100%
27	Green 6	000 ⇄ 255	0–100%
28	Blue 6	000 ⇄ 255	0–100%
29	Amber 6	000 ⇄ 255	0–100%
30	White 6	000 ⇄ 255	0–100%
31	Red 7	000 ⇄ 255	0–100%
32	Green 7	000 ⇄ 255	0–100%
33	Blue 7	000 ⇄ 255	0–100%
34	Amber 7	000 ⇄ 255	0–100%
35	White 7	000 ⇄ 255	0–100%
36	Red 8	000 ⇄ 255	0–100%
37	Green 8	000 ⇄ 255	0–100%
38	Blue 8	000 ⇄ 255	0–100%
39	Amber 8	000 ⇄ 255	0–100%
40	White 8	000 ⇄ 255	0–100%
41	Red 9	000 ⇄ 255	0–100%
42	Green 9	000 ⇄ 255	0–100%
43	Blue 9	000 ⇄ 255	0–100%
44	Amber 9	000 ⇄ 255	0–100%
45	White 9	000 ⇄ 255	0–100%
46	Red 10	000 ⇄ 255	0–100%
47	Green 10	000 ⇄ 255	0–100%
48	Blue 10	000 ⇄ 255	0–100%
49	Amber 10	000 ⇄ 255	0–100%
50	White 10	000 ⇄ 255	0–100%
51	Red 11	000 ⇄ 255	0–100%
52	Green 11	000 ⇄ 255	0–100%
53	Blue 11	000 ⇄ 255	0–100%
54	Amber 11	000 ⇄ 255	0–100%
55	White 11	000 ⇄ 255	0–100%
56	Red 12	000 ⇄ 255	0–100%
57	Green 12	000 ⇄ 255	0–100%
58	Blue 12	000 ⇄ 255	0–100%
59	Amber 12	000 ⇄ 255	0–100%
60	White 12	000 ⇄ 255	0–100%

12-Cell RGBA 48 CH

Channel	Function	Value	Percent/Setting
1	Red 1	000 ⇄ 255	0–100%
2	Green 1	000 ⇄ 255	0–100%
3	Blue 1	000 ⇄ 255	0–100%
4	Amber 1	000 ⇄ 255	0–100%
5	Red 2	000 ⇄ 255	0–100%
6	Green 2	000 ⇄ 255	0–100%
7	Blue 2	000 ⇄ 255	0–100%
8	Amber 2	000 ⇄ 255	0–100%

Channel	Function	Value	Percent/Setting
9	Red 3	000 ⇄ 255	0–100%
10	Green 3	000 ⇄ 255	0–100%
11	Blue 3	000 ⇄ 255	0–100%
12	Amber 3	000 ⇄ 255	0–100%
13	Red 4	000 ⇄ 255	0–100%
14	Green 4	000 ⇄ 255	0–100%
15	Blue 4	000 ⇄ 255	0–100%
16	Amber 4	000 ⇄ 255	0–100%
17	Red 5	000 ⇄ 255	0–100%
18	Green 5	000 ⇄ 255	0–100%
19	Blue 5	000 ⇄ 255	0–100%
20	Amber 5	000 ⇄ 255	0–100%
21	Red 6	000 ⇄ 255	0–100%
22	Green 6	000 ⇄ 255	0–100%
23	Blue 6	000 ⇄ 255	0–100%
24	Amber 6	000 ⇄ 255	0–100%
25	Red 7	000 ⇄ 255	0–100%
26	Green 7	000 ⇄ 255	0–100%
27	Blue 7	000 ⇄ 255	0–100%
28	Amber 7	000 ⇄ 255	0–100%
29	Red 8	000 ⇄ 255	0–100%
30	Green 8	000 ⇄ 255	0–100%
31	Blue 8	000 ⇄ 255	0–100%
32	Amber 8	000 ⇄ 255	0–100%
33	Red 9	000 ⇄ 255	0–100%
34	Green 9	000 ⇄ 255	0–100%
35	Blue 9	000 ⇄ 255	0–100%
36	Amber 9	000 ⇄ 255	0–100%
37	Red 10	000 ⇄ 255	0–100%
38	Green 10	000 ⇄ 255	0–100%
39	Blue 10	000 ⇄ 255	0–100%
40	Amber 10	000 ⇄ 255	0–100%
41	Red 11	000 ⇄ 255	0–100%
42	Green 11	000 ⇄ 255	0–100%
43	Blue 11	000 ⇄ 255	0–100%
44	Amber 11	000 ⇄ 255	0–100%
45	Red 12	000 ⇄ 255	0–100%
46	Green 12	000 ⇄ 255	0–100%
47	Blue 12	000 ⇄ 255	0–100%
48	Amber 12	000 ⇄ 255	0–100%

12-Cell RGB 36 CH

Channel	Function	Value	Percent/Setting
1	Red 1	000 ⇄ 255	0–100%
2	Green 1	000 ⇄ 255	0–100%
3	Blue 1	000 ⇄ 255	0–100%
4	Red 2	000 ⇄ 255	0–100%
5	Green 2	000 ⇄ 255	0–100%
6	Blue 2	000 ⇄ 255	0–100%
7	Red 3	000 ⇄ 255	0–100%
8	Green 3	000 ⇄ 255	0–100%
9	Blue 3	000 ⇄ 255	0–100%
10	Red 4	000 ⇄ 255	0–100%
11	Green 4	000 ⇄ 255	0–100%

DMX CHART



www.chauvetprofessional.com

Channel	Function	Value	Percent/Setting
12	Blue 4	000 ⇄ 255	0–100%
13	Red 5	000 ⇄ 255	0–100%
14	Green 5	000 ⇄ 255	0–100%
15	Blue 5	000 ⇄ 255	0–100%
16	Red 6	000 ⇄ 255	0–100%
17	Green 6	000 ⇄ 255	0–100%
18	Blue 6	000 ⇄ 255	0–100%
19	Red 7	000 ⇄ 255	0–100%
20	Green 7	000 ⇄ 255	0–100%
21	Blue 7	000 ⇄ 255	0–100%
22	Red 8	000 ⇄ 255	0–100%
23	Green 8	000 ⇄ 255	0–100%
24	Blue 8	000 ⇄ 255	0–100%
25	Red 9	000 ⇄ 255	0–100%
26	Green 9	000 ⇄ 255	0–100%
27	Blue 9	000 ⇄ 255	0–100%
28	Red 10	000 ⇄ 255	0–100%
29	Green 10	000 ⇄ 255	0–100%
30	Blue 10	000 ⇄ 255	0–100%
31	Red 11	000 ⇄ 255	0–100%
32	Green 11	000 ⇄ 255	0–100%
33	Blue 11	000 ⇄ 255	0–100%
34	Red 12	000 ⇄ 255	0–100%
35	Green 12	000 ⇄ 255	0–100%
36	Blue 12	000 ⇄ 255	0–100%

3-Cell Personalities

3-Cell RGBAW FULL 43 CH

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇄ 255	0–100%
2	Dimmer Fine	000 ⇄ 255	0–100%
3	Red 1	000 ⇄ 255	0–100%
4	Red Fine 1	000 ⇄ 255	0–100%
5	Green 1	000 ⇄ 255	0–100%
6	Green Fine 1	000 ⇄ 255	0–100%
7	Blue 1	000 ⇄ 255	0–100%
8	Blue Fine 1	000 ⇄ 255	0–100%
9	Amber 1	000 ⇄ 255	0–100%
10	Amber Fine 1	000 ⇄ 255	0–100%
11	White 1	000 ⇄ 255	0–100%
12	White Fine 1	000 ⇄ 255	0–100%
13	Color Macros 1	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
14	Color Temperature 1	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
15	Strobe 1	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
16	Red 2	000 ⇄ 255	0–100%
17	Red Fine 2	000 ⇄ 255	0–100%
18	Green 2	000 ⇄ 255	0–100%
19	Green Fine 2	000 ⇄ 255	0–100%

Channel	Function	Value	Percent/Setting
20	Blue 2	000 ⇄ 255	0–100%
21	Blue Fine 2	000 ⇄ 255	0–100%
22	Amber 2	000 ⇄ 255	0–100%
23	Amber Fine 2	000 ⇄ 255	0–100%
24	White 2	000 ⇄ 255	0–100%
25	White Fine 2	000 ⇄ 255	0–100%
26	Color Macros 2	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
27	Color Temperature 2	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
28	Strobe 2	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
29	Red 3	000 ⇄ 255	0–100%
30	Red Fine 3	000 ⇄ 255	0–100%
31	Green 3	000 ⇄ 255	0–100%
32	Green Fine 3	000 ⇄ 255	0–100%
33	Blue 3	000 ⇄ 255	0–100%
34	Blue Fine 3	000 ⇄ 255	0–100%
35	Amber 3	000 ⇄ 255	0–100%
36	Amber Fine 3	000 ⇄ 255	0–100%
37	White 3	000 ⇄ 255	0–100%
38	White Fine 3	000 ⇄ 255	0–100%
39	Color Macros 3	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
40	Color Temperature 3	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
41	Strobe 3	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
42	Strobe All	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
43	Dimmer Speed	000 ⇄ 051	Preset dimmer speed from display menu
		052 ⇄ 101	Dimmer speed mode off
		102 ⇄ 152	Dimmer speed mode 1 (fastest)
		153 ⇄ 203	Dimmer speed mode 2
		204 ⇄ 255	Dimmer speed mode 3 (slowest)

3-Cell RGBAW Fine 30 CH

Channel	Function	Value	Percent/Setting
1	Red 1	000 ⇄ 255	0–100%
2	Red Fine 1	000 ⇄ 255	0–100%
3	Green 1	000 ⇄ 255	0–100%
4	Green Fine 1	000 ⇄ 255	0–100%
5	Blue 1	000 ⇄ 255	0–100%
6	Blue Fine 1	000 ⇄ 255	0–100%
7	Amber 1	000 ⇄ 255	0–100%
8	Amber Fine 1	000 ⇄ 255	0–100%

DMX CHART



www.chauvetprofessional.com

Channel	Function	Value	Percent/Setting
9	White 1	000 ⇄ 255	0–100%
10	White Fine 1	000 ⇄ 255	0–100%
11	Red 2	000 ⇄ 255	0–100%
12	Red Fine 2	000 ⇄ 255	0–100%
13	Green 2	000 ⇄ 255	0–100%
14	Green Fine 2	000 ⇄ 255	0–100%
15	Blue 2	000 ⇄ 255	0–100%
16	Blue Fine 2	000 ⇄ 255	0–100%
17	Amber 2	000 ⇄ 255	0–100%
18	Amber Fine 2	000 ⇄ 255	0–100%
19	White 2	000 ⇄ 255	0–100%
20	White Fine 2	000 ⇄ 255	0–100%
21	Red 3	000 ⇄ 255	0–100%
22	Red Fine 3	000 ⇄ 255	0–100%
23	Green 3	000 ⇄ 255	0–100%
24	Green Fine 3	000 ⇄ 255	0–100%
25	Blue 3	000 ⇄ 255	0–100%
26	Blue Fine 3	000 ⇄ 255	0–100%
27	Amber 3	000 ⇄ 255	0–100%
28	Amber Fine 3	000 ⇄ 255	0–100%
29	White 3	000 ⇄ 255	0–100%
30	White Fine 3	000 ⇄ 255	0–100%

3-Cell RGBAW EXT 27 CH

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇄ 255	0–100%
2	Dimmer Fine	000 ⇄ 255	0–100%
3	Red 1	000 ⇄ 255	0–100%
4	Green 1	000 ⇄ 255	0–100%
5	Blue 1	000 ⇄ 255	0–100%
6	Amber 1	000 ⇄ 255	0–100%
7	White 1	000 ⇄ 255	0–100%
8	Color Macros 1	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
9	Color Temperature 1	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
10	Strobe 1	000 ⇄ 009 010 ⇄ 099 100 ⇄ 109 110 ⇄ 179 180 ⇄ 189 190 ⇄ 255	No function Slow to fast No function Lighting effect, slow to fast No function Random
11	Red 2	000 ⇄ 255	0–100%
12	Green 2	000 ⇄ 255	0–100%
13	Blue 2	000 ⇄ 255	0–100%
14	Amber 2	000 ⇄ 255	0–100%
15	White 2	000 ⇄ 255	0–100%
16	Color Macros 2	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
17	Color Temperature 2	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
18	Strobe 2	000 ⇄ 009 010 ⇄ 099 100 ⇄ 109 110 ⇄ 179 180 ⇄ 189 190 ⇄ 255	No function Slow to fast No function Lighting effect, slow to fast No function Random

Channel	Function	Value	Percent/Setting
19	Red 3	000 ⇄ 255	0–100%
20	Green 3	000 ⇄ 255	0–100%
21	Blue 3	000 ⇄ 255	0–100%
22	Amber 3	000 ⇄ 255	0–100%
23	White 3	000 ⇄ 255	0–100%
24	Color Macros 3	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
25	Color Temperature 3	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
26	Strobe 3	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
27	Strobe All	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random

3-Cell RGBA EXT 24 CH

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇄ 255	0–100%
2	Dimmer Fine	000 ⇄ 255	0–100%
3	Red 1	000 ⇄ 255	0–100%
4	Green 1	000 ⇄ 255	0–100%
5	Blue 1	000 ⇄ 255	0–100%
6	Amber 1	000 ⇄ 255	0–100%
7	Color Macros 1	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
8	Color Temperature 1	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
9	Strobe 1	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
10	Red 2	000 ⇄ 255	0–100%
11	Green 2	000 ⇄ 255	0–100%
12	Blue 2	000 ⇄ 255	0–100%
13	Amber 2	000 ⇄ 255	0–100%
14	Color Macros 2	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
15	Color Temperature 2	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
16	Strobe 2	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
17	Red 3	000 ⇄ 255	0–100%
18	Green 3	000 ⇄ 255	0–100%
19	Blue 3	000 ⇄ 255	0–100%
20	Amber 3	000 ⇄ 255	0–100%

DMX CHART



www.chauvetprofessional.com

Channel	Function	Value	Percent/Setting
21	Color Macros 3	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
22	Color Temperature 3	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
23	Strobe 3	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
24	Strobe All	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random

3-Cell HSIC 22 CH

Channel	Function	Value	Percent/Setting
1	Dimmer 1	000 ⇄ 255	0–100%
2	Hue 1	000 ⇄ 255	0–100%
3	Hue Fine 1	000 ⇄ 255	0–100%
4	Saturation 1	000 ⇄ 255	0–100%
5	Strobe 1	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
6	Color Macros 1	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
7	Color Temperature 1	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
8	Dimmer 2	000 ⇄ 255	0–100%
9	Hue 2	000 ⇄ 255	0–100%
10	Hue Fine 2	000 ⇄ 255	0–100%
11	Saturation 2	000 ⇄ 255	0–100%
12	Strobe 2	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
13	Color Macros 2	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
14	Color Temperature 2	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
15	Dimmer 3	000 ⇄ 255	0–100%
16	Hue 3	000 ⇄ 255	0–100%
17	Hue Fine 3	000 ⇄ 255	0–100%
18	Saturation 3	000 ⇄ 255	0–100%
19	Strobe 3	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
20	Color Macros 3	000 ⇄ 255	Refer to the Color Macro Chart section for specific values

Channel	Function	Value	Percent/Setting
21	Color Temperature 3	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
22	Dimmer Speed	000 ⇄ 051 052 ⇄ 101 102 ⇄ 152 153 ⇄ 203 204 ⇄ 255	Preset dimmer speed from display menu Dimmer speed mode off Dimmer speed mode 1 (fastest) Dimmer speed mode 2 Dimmer speed mode 3 (slowest)

3-Cell RGB EXT 21 CH

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇄ 255	0–100%
2	Dimmer Fine	000 ⇄ 255	0–100%
3	Red 1	000 ⇄ 255	0–100%
4	Green 1	000 ⇄ 255	0–100%
5	Blue 1	000 ⇄ 255	0–100%
6	Color Macros 1	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
7	Color Temperature 1	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
8	Strobe 1	000 ⇄ 009 010 ⇄ 099 100 ⇄ 109 110 ⇄ 179 180 ⇄ 189 190 ⇄ 255	No function Slow to fast No function Lighting effect, slow to fast No function Random
9	Red 2	000 ⇄ 255	0–100%
10	Green 2	000 ⇄ 255	0–100%
11	Blue 2	000 ⇄ 255	0–100%
12	Color Macros 2	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
13	Color Temperature 2	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
14	Strobe 2	000 ⇄ 009 010 ⇄ 099 100 ⇄ 109 110 ⇄ 179 180 ⇄ 189 190 ⇄ 255	No function Slow to fast No function Lighting effect, slow to fast No function Random
15	Red 3	000 ⇄ 255	0–100%
16	Green 3	000 ⇄ 255	0–100%
17	Blue 3	000 ⇄ 255	0–100%
18	Color Macros 3	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
19	Color Temperature 3	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
20	Strobe 3	000 ⇄ 009 010 ⇄ 099 100 ⇄ 109 110 ⇄ 179 180 ⇄ 189 190 ⇄ 255	No function Slow to fast No function Lighting effect, slow to fast No function Random
21	Strobe All	000 ⇄ 009 010 ⇄ 099 100 ⇄ 109 110 ⇄ 179 180 ⇄ 189 190 ⇄ 255	No function Slow to fast No function Lighting effect, slow to fast No function Random

DMX CHART



www.chauvetprofessional.com

3-Cell RGBAW 15 CH

Channel	Function	Value	Percent/Setting
1	Red 1	000 ⇄ 255	0–100%
2	Green 1	000 ⇄ 255	0–100%
3	Blue 1	000 ⇄ 255	0–100%
4	Amber 1	000 ⇄ 255	0–100%
5	White 1	000 ⇄ 255	0–100%
6	Red 2	000 ⇄ 255	0–100%
7	Green 2	000 ⇄ 255	0–100%
8	Blue 2	000 ⇄ 255	0–100%
9	Amber 2	000 ⇄ 255	0–100%
10	White 2	000 ⇄ 255	0–100%
11	Red 3	000 ⇄ 255	0–100%
12	Green 3	000 ⇄ 255	0–100%
13	Blue 3	000 ⇄ 255	0–100%
14	Amber 3	000 ⇄ 255	0–100%
15	White 3	000 ⇄ 255	0–100%

3-Cell RGBA 12 CH

Channel	Function	Value	Percent/Setting
1	Red 1	000 ⇄ 255	0–100%
2	Green 1	000 ⇄ 255	0–100%
3	Blue 1	000 ⇄ 255	0–100%
4	Amber 1	000 ⇄ 255	0–100%
5	Red 2	000 ⇄ 255	0–100%
6	Green 2	000 ⇄ 255	0–100%
7	Blue 2	000 ⇄ 255	0–100%
8	Amber 2	000 ⇄ 255	0–100%
9	Red 3	000 ⇄ 255	0–100%
10	Green 3	000 ⇄ 255	0–100%
11	Blue 3	000 ⇄ 255	0–100%
12	Amber 3	000 ⇄ 255	0–100%

3-Cell RGB 9 CH

Channel	Function	Value	Percent/Setting
1	Red 1	000 ⇄ 255	0–100%
2	Green 1	000 ⇄ 255	0–100%
3	Blue 1	000 ⇄ 255	0–100%
4	Red 2	000 ⇄ 255	0–100%
5	Green 2	000 ⇄ 255	0–100%
6	Blue 2	000 ⇄ 255	0–100%
7	Red 3	000 ⇄ 255	0–100%
8	Green 3	000 ⇄ 255	0–100%
9	Blue 3	000 ⇄ 255	0–100%

2-Cell Personalities

2-Cell RGBAW FULL 30 CH

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇄ 255	0–100%
2	Dimmer Fine	000 ⇄ 255	0–100%
3	Red 1	000 ⇄ 255	0–100%
4	Red Fine 1	000 ⇄ 255	0–100%
5	Green 1	000 ⇄ 255	0–100%
6	Green Fine 1	000 ⇄ 255	0–100%
7	Blue 1	000 ⇄ 255	0–100%

Channel	Function	Value	Percent/Setting
8	Blue Fine 1	000 ⇄ 255	0–100%
9	Amber 1	000 ⇄ 255	0–100%
10	Amber Fine 1	000 ⇄ 255	0–100%
11	White 1	000 ⇄ 255	0–100%
12	White Fine 1	000 ⇄ 255	0–100%
13	Color Macros 1	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
14	Color Temperature 1	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
15	Strobe 1	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
16	Red 2	000 ⇄ 255	0–100%
17	Red Fine 2	000 ⇄ 255	0–100%
18	Green 2	000 ⇄ 255	0–100%
19	Green Fine 2	000 ⇄ 255	0–100%
20	Blue 2	000 ⇄ 255	0–100%
21	Blue Fine 2	000 ⇄ 255	0–100%
22	Amber 2	000 ⇄ 255	0–100%
23	Amber Fine 2	000 ⇄ 255	0–100%
24	White 2	000 ⇄ 255	0–100%
25	White Fine 2	000 ⇄ 255	0–100%
26	Color Macros 2	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
27	Color Temperature 2	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
28	Strobe 2	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
29	Strobe All	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
30	Dimmer Speed	000 ⇄ 051	Preset dimmer speed from display menu
		052 ⇄ 101	Dimmer speed mode off
		102 ⇄ 152	Dimmer speed mode 1 (fastest)
		153 ⇄ 203	Dimmer speed mode 2
		204 ⇄ 255	Dimmer speed mode 3 (slowest)

2-Cell RGBAW Fine 20 CH

Channel	Function	Value	Percent/Setting
1	Red 1	000 ⇄ 255	0–100%
2	Red Fine 1	000 ⇄ 255	0–100%
3	Green 1	000 ⇄ 255	0–100%
4	Green Fine 1	000 ⇄ 255	0–100%
5	Blue 1	000 ⇄ 255	0–100%
6	Blue Fine 1	000 ⇄ 255	0–100%
7	Amber 1	000 ⇄ 255	0–100%
8	Amber Fine 1	000 ⇄ 255	0–100%
9	White 1	000 ⇄ 255	0–100%

DMX CHART



www.chauvetprofessional.com

Channel	Function	Value	Percent/Setting
10	White Fine 1	000 ⇄ 255	0–100%
11	Red 2	000 ⇄ 255	0–100%
12	Red Fine 2	000 ⇄ 255	0–100%
13	Green 2	000 ⇄ 255	0–100%
14	Green Fine 2	000 ⇄ 255	0–100%
15	Blue 2	000 ⇄ 255	0–100%
16	Blue Fine 2	000 ⇄ 255	0–100%
17	Amber 2	000 ⇄ 255	0–100%
18	Amber Fine 2	000 ⇄ 255	0–100%
19	White 2	000 ⇄ 255	0–100%
20	White Fine 2	000 ⇄ 255	0–100%

2-Cell RGBAW EXT 19 CH

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇄ 255	0–100%
2	Dimmer Fine	000 ⇄ 255	0–100%
3	Red 1	000 ⇄ 255	0–100%
4	Green 1	000 ⇄ 255	0–100%
5	Blue 1	000 ⇄ 255	0–100%
6	Amber 1	000 ⇄ 255	0–100%
7	White 1	000 ⇄ 255	0–100%
8	Color Macros 1	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
9	Color Temperature 1	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
10	Strobe 1	000 ⇄ 009 010 ⇄ 099 100 ⇄ 109 110 ⇄ 179 180 ⇄ 189 190 ⇄ 255	No function Slow to fast No function Lighting effect, slow to fast No function Random
11	Red 2	000 ⇄ 255	0–100%
12	Green 2	000 ⇄ 255	0–100%
13	Blue 2	000 ⇄ 255	0–100%
14	Amber 2	000 ⇄ 255	0–100%
15	White 2	000 ⇄ 255	0–100%
16	Color Macros 2	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
17	Color Temperature 2	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
18	Strobe 2	000 ⇄ 009 010 ⇄ 099 100 ⇄ 109 110 ⇄ 179 180 ⇄ 189 190 ⇄ 255	No function Slow to fast No function Lighting effect, slow to fast No function Random
19	Strobe All	000 ⇄ 009 010 ⇄ 099 100 ⇄ 109 110 ⇄ 179 180 ⇄ 189 190 ⇄ 255	No function Slow to fast No function Lighting effect, slow to fast No function Random

2-Cell RGBA EXT 17 CH

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇄ 255	0–100%
2	Dimmer Fine	000 ⇄ 255	0–100%

Channel	Function	Value	Percent/Setting
3	Red 1	000 ⇄ 255	0–100%
4	Green 1	000 ⇄ 255	0–100%
5	Blue 1	000 ⇄ 255	0–100%
6	Amber 1	000 ⇄ 255	0–100%
7	Color Macros 1	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
8	Color Temperature 1	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
9	Strobe 1	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
10	Red 2	000 ⇄ 255	0–100%
11	Green 2	000 ⇄ 255	0–100%
12	Blue 2	000 ⇄ 255	0–100%
13	Amber 2	000 ⇄ 255	0–100%
14	Color Macros 2	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
15	Color Temperature 2	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
16	Strobe 2	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
17	Strobe All	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random

2-Cell HSIC 15 CH

Channel	Function	Value	Percent/Setting
1	Dimmer 1	000 ⇄ 255	0–100%
2	Hue 1	000 ⇄ 255	0–100%
3	Hue Fine 1	000 ⇄ 255	0–100%
4	Saturation 1	000 ⇄ 255	0–100%
5	Strobe 1	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
6	Color Macros 1	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
7	Color Temperature 1	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
8	Dimmer 2	000 ⇄ 255	0–100%
9	Hue 2	000 ⇄ 255	0–100%
10	Hue Fine 2	000 ⇄ 255	0–100%
11	Saturation 2	000 ⇄ 255	0–100%

DMX CHART



www.chauvetprofessional.com

Channel	Function	Value	Percent/Setting
12	Strobe 2	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
13	Color Macros 2	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
14	Color Temperature 2	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
15	Dimmer Speed	000 ⇄ 051	Preset dimmer speed from display menu
		052 ⇄ 101	Dimmer speed mode off
		102 ⇄ 152	Dimmer speed mode 1 (fastest)
		153 ⇄ 203	Dimmer speed mode 2
		204 ⇄ 255	Dimmer speed mode 3 (slowest)

2-Cell RGB EXT 15 CH

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇄ 255	0–100%
2	Dimmer Fine	000 ⇄ 255	0–100%
3	Red 1	000 ⇄ 255	0–100%
4	Green 1	000 ⇄ 255	0–100%
5	Blue 1	000 ⇄ 255	0–100%
6	Color Macros 1	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
7	Color Temperature 1	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
8	Strobe 1	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
9	Red 2	000 ⇄ 255	0–100%
10	Green 2	000 ⇄ 255	0–100%
11	Blue 2	000 ⇄ 255	0–100%
12	Color Macros 2	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
13	Color Temperature 2	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
14	Strobe 2	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
15	Strobe All	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random

2-Cell RGBAW 10 CH

Channel	Function	Value	Percent/Setting
1	Red 1	000 ⇄ 255	0–100%
2	Green 1	000 ⇄ 255	0–100%
3	Blue 1	000 ⇄ 255	0–100%

Channel	Function	Value	Percent/Setting
4	Amber 1	000 ⇄ 255	0–100%
5	White 1	000 ⇄ 255	0–100%
6	Red 2	000 ⇄ 255	0–100%
7	Green 2	000 ⇄ 255	0–100%
8	Blue 2	000 ⇄ 255	0–100%
9	Amber 2	000 ⇄ 255	0–100%
10	White 2	000 ⇄ 255	0–100%

2-Cell RGBA 8 CH

Channel	Function	Value	Percent/Setting
1	Red 1	000 ⇄ 255	0–100%
2	Green 1	000 ⇄ 255	0–100%
3	Blue 1	000 ⇄ 255	0–100%
4	Amber 1	000 ⇄ 255	0–100%
5	Red 2	000 ⇄ 255	0–100%
6	Green 2	000 ⇄ 255	0–100%
7	Blue 2	000 ⇄ 255	0–100%
8	Amber 2	000 ⇄ 255	0–100%

2-Cell RGB 6 CH

Channel	Function	Value	Percent/Setting
1	Red 1	000 ⇄ 255	0–100%
2	Green 1	000 ⇄ 255	0–100%
3	Blue 1	000 ⇄ 255	0–100%
4	Red 2	000 ⇄ 255	0–100%
5	Green 2	000 ⇄ 255	0–100%
6	Blue 2	000 ⇄ 255	0–100%

1-Cell Personalities

1-Cell RGBAW FULL 16 CH

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇄ 255	0–100%
2	Dimmer Fine	000 ⇄ 255	0–100%
3	Red	000 ⇄ 255	0–100%
4	Red Fine	000 ⇄ 255	0–100%
5	Green	000 ⇄ 255	0–100%
6	Green Fine	000 ⇄ 255	0–100%
7	Blue	000 ⇄ 255	0–100%
8	Blue Fine	000 ⇄ 255	0–100%
9	Amber	000 ⇄ 255	0–100%
10	Amber Fine	000 ⇄ 255	0–100%
11	White	000 ⇄ 255	0–100%
12	White Fine	000 ⇄ 255	0–100%
13	Color Macros	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
14	Color Temperature	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
15	Strobe	000 ⇄ 009 010 ⇄ 099 100 ⇄ 109 110 ⇄ 179 180 ⇄ 189 190 ⇄ 255	No function Slow to fast No function Lighting effect, slow to fast No function Random

DMX CHART



www.chauvetprofessional.com

Channel	Function	Value	Percent/Setting
16	Dimmer Speed	000 ⇄ 051	Preset dimmer speed from display menu
		052 ⇄ 101	Dimmer speed mode off
		102 ⇄ 152	Dimmer speed mode 1 (fastest)
		153 ⇄ 203	Dimmer speed mode 2
		204 ⇄ 255	Dimmer speed mode 3 (slowest)

1-Cell RGBAW Fine 10 CH

Channel	Function	Value	Percent/Setting
1	Red	000 ⇄ 255	0–100%
2	Red Fine	000 ⇄ 255	0–100%
3	Green	000 ⇄ 255	0–100%
4	Green Fine	000 ⇄ 255	0–100%
5	Blue	000 ⇄ 255	0–100%
6	Blue Fine	000 ⇄ 255	0–100%
7	Amber	000 ⇄ 255	0–100%
8	Amber Fine	000 ⇄ 255	0–100%
9	White	000 ⇄ 255	0–100%
10	White Fine	000 ⇄ 255	0–100%

1-Cell RGBAW EXT 10 CH

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇄ 255	0–100%
2	Dimmer Fine	000 ⇄ 255	0–100%
3	Red	000 ⇄ 255	0–100%
4	Green	000 ⇄ 255	0–100%
5	Blue	000 ⇄ 255	0–100%
6	Amber	000 ⇄ 255	0–100%
7	White	000 ⇄ 255	0–100%
8	Color Macros	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
9	Color Temperature	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
10	Strobe	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random

1-Cell RGBA EXT 9 CH

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇄ 255	0–100%
2	Dimmer Fine	000 ⇄ 255	0–100%
3	Red	000 ⇄ 255	0–100%
4	Green	000 ⇄ 255	0–100%
5	Blue	000 ⇄ 255	0–100%
6	Amber	000 ⇄ 255	0–100%
7	Color Macros	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
8	Color Temperature	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values

Channel	Function	Value	Percent/Setting
9	Strobe	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random

1-Cell HSIC 8 CH

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇄ 255	0–100%
2	Hue	000 ⇄ 255	0–100%
3	Hue Fine	000 ⇄ 255	0–100%
4	Saturation	000 ⇄ 255	0–100%
5	Strobe	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random
6	Color Macros	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
7	Color Temperature	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
8	Dimmer Speed	000 ⇄ 051	Preset dimmer speed from display menu
		052 ⇄ 101	Dimmer speed mode off
		102 ⇄ 152	Dimmer speed mode 1 (fastest)
		153 ⇄ 203	Dimmer speed mode 2
		204 ⇄ 255	Dimmer speed mode 3 (slowest)

1-Cell RGB EXT 8 CH

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇄ 255	0–100%
2	Dimmer Fine	000 ⇄ 255	0–100%
3	Red	000 ⇄ 255	0–100%
4	Green	000 ⇄ 255	0–100%
5	Blue	000 ⇄ 255	0–100%
6	Color Macros	000 ⇄ 255	Refer to the Color Macro Chart section for specific values
7	Color Temperature	000 ⇄ 255	Refer to the Color Temperature Chart section for specific values
8	Strobe	000 ⇄ 009	No function
		010 ⇄ 099	Slow to fast
		100 ⇄ 109	No function
		110 ⇄ 179	Lighting effect, slow to fast
		180 ⇄ 189	No function
		190 ⇄ 255	Random

1-Cell RGBAW 5 CH

Channel	Function	Value	Percent/Setting
1	Red	000 ⇄ 255	0–100%
2	Green	000 ⇄ 255	0–100%
3	Blue	000 ⇄ 255	0–100%
4	Amber	000 ⇄ 255	0–100%
5	White	000 ⇄ 255	0–100%

DMX CHART



www.chauvetprofessional.com

1-Cell RGBA 4 CH

Channel	Function	Value	Percent/Setting
1	Red	000 ⇄ 255	0–100%
2	Green	000 ⇄ 255	0–100%
3	Blue	000 ⇄ 255	0–100%
4	Amber	000 ⇄ 255	0–100%

1-Cell RGB 3 CH

Channel	Function	Value	Percent/Setting
1	Red	000 ⇄ 255	0–100%
2	Green	000 ⇄ 255	0–100%
3	Blue	000 ⇄ 255	0–100%